



MOTOROLA

GM950E/GM950i

Mobile Radio


Service Manual

680411J39-B

<http://www.myradio168.net>

<http://www.myradio168.net>

CAUTION



ELECTROSTATIC SENSITIVE DEVICES

PRECAUTIONS SHOULD BE TAKEN TO MINIMIZE THE RISK OF DAMAGE BY ELECTROSTATIC DISCHARGE TO ELECTROSTATIC SENSITIVE DEVICES (ESDs).


ANY DEVICES EMPLOYING METAL OXIDE SILICON (MOS) TECHNOLOGY ARE PARTICULARLY SUSCEPTIBLE.

CIRCUIT DIAGRAMS MARKED WITH THE ABOVE SYMBOL INDICATE ELECTRONIC CIRCUITS (PECs) FOR WHICH ESD HANDLING PRECAUTIONS ARE NECESSARY.

THE USER SHOULD REFER TO BS5783, 1984: HANDLING OF ELECTROSTATIC SENSITIVE DEVICES. THIS BRITISH STANDARD SUPERSEDES DEF STAN 59-98, ISSUE 2.

<http://www.myradio168.net>

SAFETY WARNINGS



THE ELECTRICAL POWER USED IN THIS EQUIPMENT IS AT A VOLTAGE HIGH ENOUGH TO ENDANGER LIFE.

BEFORE CARRYING OUT MAINTENANCE OR REPAIR, PERSONS CONCERNED MUST ENSURE THAT THIS EQUIPMENT IS ISOLATED FROM THE ELECTRICAL SUPPLY AND TESTS ARE MADE TO ENSURE THAT ISOLATION IS COMPLETE.

WHEN THE SUPPLY CANNOT BE ISOLATED, MAINTENANCE AND REPAIR MUST BE UNDERTAKEN BY PERSONS WHO ARE FULLY AWARE OF THE DANGERS INVOLVED AND WHO HAVE TAKEN ADEQUATE PRECAUTIONS TO PROTECT THEMSELVES.

COMPONENTS CONTAINING BERYLLIUM OXIDE ARE USED IN THIS EQUIPMENT. DUST FROM THIS MATERIAL IS A HEALTH HAZARD IF INHALED OR ALLOWED TO COME INTO CONTACT WITH THE SKIN.

GREAT CARE MUST BE TAKEN WHEN HANDLING THESE COMPONENTS WHICH MUST NOT BE BROKEN OR SUBJECTED TO EXCESSIVE HEATING. DEFECTIVE COMPONENTS MUST BE DISPOSED OF IN ACCORDANCE WITH CURRENT INSTRUCTIONS.

LEAD ACID BATTERIES MAY BE FITTED AS THE STANDBY BATTERY. CARE MUST BE TAKEN WHEN REMOVING OR INSTALLING THESE BATTERIES TO:

1. ENSURE THAT THE TERMINALS ARE NOT SHORTED TOGETHER.
2. PREVENT SPILLAGE OF THE CORROSIVE ELECTROLYTE.

<http://www.myradio168.net>

Service Manual

Contents

Chapter

1.0 Introduction

Gives a brief introduction into the manual and the service policy.

2.0 Model Chart and Accessories

Provides list of models and accessories available for the mobile radio.

3.0 Maintenance

Describes how to disassemble/assemble the radio for maintenance purposes and gives details on safety precautions. There is also information on testing/servicing the radio using the front panel and diagnostics test modes.

4.0 Theory Of Operation

Gives a detailed description about the operation of the radio. The information is supplied to circuit reference detail.

5.0 Schematic Diagrams and Parts Lists

Provides component location diagrams, schematic diagrams and associated parts lists.

6.0 216-246MHz Band Specific Information

Provides all information concerning 216-246MHz band split including component location diagrams, schematic diagrams and associated parts lists.

Appendix

A.0 PL (CTCSS) Codes

B.0 External Device Connectors

C.0 Radio Conversions

<http://www.myradio168.net>

Chapter 1

Introduction

Table of Contents

Paragraph	Page
1.0 Introduction	1
2.0 Scope of Manual	1
3.0 How to Use This Manual	1
4.0 Warranty and Service Support	1
4.1 Warranty Period	1
4.2 After Warranty Period	1
4.3 Piece Parts	2
4.4 Technical Support	2
5.0 GM950E/GM950i Technical Specification	2
5.1 General	2
5.2 Transmitter	3
5.3 Receiver	3

<http://www.myradio168.net>

1.0 Introduction

This chapter outlines the scope and use of the service manual and provides an overview of the warranty and service support. The radio specifications are also supplied in this chapter.

2.0 Scope of Manual

This manual is intended for use by experienced technicians familiar with similar types of equipment. It contains service information required for the equipment described and is current as of the printing date. Changes which occur after the printing date are incorporated by a complete Service Manual revision to your Product Manual.

3.0 How to Use This Manual

This manual contains introductory material such as overview, model charts, specifications and accessories and the remaining chapters deal with specific service aspects of the radio. Refer to the Table of Contents for a general overview of the manual.

4.0 Warranty and Service Support

Motorola offers long term support for its products. This support includes full exchange and/or repair of the product during the warranty period, and service/ repair or spare parts support out of warranty. Any "return-for-exchange" or "return-for-repair" by an authorised Motorola Dealer must be accompanied by a Warranty Claim Form. Warranty Claim Forms are obtained by contacting an Authorised Motorola Dealer.

4.1 Warranty Period

The terms and conditions of warranty are defined fully in the Motorola Dealer or Distributor or Reseller contract. These conditions may change from time to time and the following notes are for guidance purposes only.

In instances where the product is covered under a "return for replacement" or "return for repair" warranty, a check of the product should be performed prior to shipping the unit back to Motorola. To ensure the product has been correctly programmed or has not been subjected to damage outside the terms of the warranty.

Prior to shipping any radios back to the appropriate Motorola warranty depot, please contact Customer Services. All returns must be accompanied by a Warranty Claim Form, available from your Customer Services representative. Products should be shipped back in the original packaging, or correctly packaged to ensure no damage occurs in transit.

4.2 After Warranty Period

After the Warranty period, Motorola continues to support its products in two ways.

1. Motorola's Accessories and Aftermarket Division (AAD) offers a repair service to both end users and dealers at competitive prices.
2. AAD supplies individual parts and modules that can be purchased by dealers who are technically capable of performing fault analysis and repair.

4.3 Piece Parts

Some replacement parts, spare parts, and/or product information can be ordered directly. If a complete Motorola part number is assigned to the part, it is available from Motorola's Accessories and Aftermarket Division (AAD). If a generic part is listed or only a part description is listed, the part is not normally available from Motorola. If a parts list is not included, this generally means that no user-serviceable parts are available for that kit or assembly. All orders for parts/information should include the complete Motorola identification number. All part orders should be directed to your local AAD office.

Singapore Regional Service Centre

10 Ang Mo Kio Street 65
 #01-01 Techpoint Building
 Ang Mo Kio Industrial Park 3
 Singapore 569059
 Tel: 65-4815560
 Fax: 65-4846123

4.4 Technical Support

Motorola Product Services is available to assist the dealer/distributors in resolving any malfunctions which may be encountered. Initial contact should be by telephone whenever possible. When contacting Motorola Technical Support, be prepared with the product model number and the unit's serial number.

5.0 GM950E/GM950i Technical Specification

5.1 General

SPECIFICATION ITEM	TYPICAL VALUE
Frequency Range	VHF: 136-174 MHz UHF: 403-470 MHz
Channel Spacing	12.5 or 20/25 kHz
Frequency Stability	±2ppm(UHF); ±5ppm (VHF)
Power Supply	10.8 to 15.6V dc, negative earth
Dimensions	44x168x160 mm (HxWxD)
Weight	1030g
Operational Temperature	- 25°C to + 55°C
Storage Temperature	- 40°C to + 85°C
Antenna Connection	50Ω BNC
Environmental - Mechanical	Vibration IEC 68/2/27 and Shock IEC 28/2/6 European Dust & Water protection IP54
- Electrical	ETS300-086 RF Specifications ETS300-113 Cyclic Keying Requirements ETS300-279 EMC Requirements ETS300-219 Signalling

5.2 Transmitter

SPECIFICATION ITEM	TYPICAL VALUE
Channel Spacing	12.5 or 20/25 kHz
Output Power	5-25W
Modulation Limiting	<±2.5kHz (12.5kHz); <±4kHz (20kHz); <±5kHz (25kHz)
FM hum & noise (CCITT)	>40dB (12.5kHz); >45dB (25kHz) CCITT
Conducted/Radiated Emission	<0.25uW (0.1...1000MHz); <1uW (1..4GHz)
Adjacent Channel Power	<-60dB (12.5kHz); <-70dB (25kHz)
Audio Response (300 - 3000 Hz)	Flat or pre-emphasised
Audio Distortion	<5% @ 1kHz, 60% deviation
Transmit turn on time	<25msec

5.3 Receiver

SPECIFICATION ITEM	TYPICAL VALUE
Channel Spacing	12.5 or 20/25 kHz
Sensitivity @ 12.5 kHz	< 0.35uV (12dB SINAD)
Sensitivity @ 25 kHz	< 0.35uV (12dB SINAD)
Intermodulation	>65dB ETS; >70dB with Base Option
Adjacent Channel Selectivity	>60dB (12.5kHz); >70dB (20/25kHz) ETS
Spurious Rejection	>70dB ETS
Audio Distortion @ Rated Audio	<5%
Hum and Noise (CCITT)	>40dB (12.5kHz); >45dB (20/25kHz) CCITT
Audio Response (300 - 3000 Hz)	Flat or De-Emphasised
Co-channel Rejection	<12dB (12.5kHz) , <8dB (20/25kHz) ETS
Conducted /Radiated Emission	<2nW (0,1..1000MHz); <20nW (1..4GHz)
Receive after transmit time	<25msec
Audio Output Power	4W (internal speaker); <13W external

<http://www.myradio168.net>

Chapter 2

Model Chart and Accessories

Table of Contents

Paragraph		Page
1.0	Overview	1
2.0	Model Chart	1
3.0	Accessories	2
3.1	Mechanical Hardware Kits:	2
3.2	Microphones:	2
3.3	Speakers:	2
3.4	Cables:	2
3.5	Other:	2

<http://www.myradio168.net>

<http://www.myradio168.net>

1.0 Overview

This chapter lists the models and accessories available for the GM950E/GM950i mobile radio.

2.0 Model Chart

Description		Model	
GM950E	136-174 MHz 12.5 kHz 25W	AZM08JHE4AA2AA	
GM950i	136-174 MHz 12.5 kHz 25W D	AZM08JHF4AA3AA	
GM950E	136-174 MHz 20/25 kHz 25W	AZM08JHE6AA2AA	
GM950i	136-174 MHz 20/25 kHz 25W D	AZM08JHF6AA3AA	
GM950E	403-470 MHz 12.5 kHz 25W	AZM08RHE4AA2AA	
GM950i	403-470 MHz 12.5 kHz 25W D	AZM08RRHF4AA3AA	
GM950E	403-470 MHz 20/25 kHz 25W	AZM08RHE6AA2AA	
GM950i	403-470 MHz 20/25 kHz 25W D	AZM08RRHF6AA3AA	
GM950E	136-174 MHz 12.5 kHz 5W 4CH	AZM08JDE4AA2AA	
GM950i	136-174 MHz 12.5 kHz 10W 64CH	AZM08JFF4AA3AA	
GM950E	403-470 MHz 12.5 kHz 5W 4CH	AZM08RDE4AA2AA	
GM950i	403-470 MHz 12.5 kHz 10W 64CH	AZM08RFF4AA3AA	

GM950E/GM950i 136-174 MHz VHF 403-470 MHz UHF	
X = Indicates one of each required	
Item	Description
X	PMBN4039_ Packaging Kit
X	GCN6103_ Control Head Model A2 Non-Display
X	GCN6105_ Control Head Model A3 Display
X	GLN7324_ Low Profile Trunnion Kit
X	GMN6146_ Enhanced Compact Microphone
	PMUE1619_ GM950E UHF 12.5kHz Tanapa
	PMUE1621_ GM950E UHF 20/25kHz Tanapa
X	PMUD1616_ GM950E VHF 12.5kHz Tanapa
	PMUD1618_ GM950E VHF 20/25kHz Tanapa
	PMUE1618_ GM950i UHF 12.5kHz Tanapa
	PMUE1620_ GM950i UHF 20/25kHz Tanapa
X	PMUD1615_ GM950i VHF 12.5kHz Tanapa
	PMUD1617_ GM950i VHF 20/25kHz Tanapa
	PMUE1718_ GM950i UHF 12.5kHz S/T 10W D
	PMUE1719_ GM950E UHF 12.5kHz S/T 5W N
	PMUD1686_ GM950i VHF 12.5 kHz S/T 10W D
	PMUD1687_ GM950E VHF 12.5kHz S/T 5W N
X	GKN6270_ Power Cable
	6804111J97 GM950E/GM950i User Guide (Korean)
X	6804111J35 GM950E/GM950i User Guide

3.0 Accessories

3.1 Mechanical Hardware Kits:

GLN7324	Low Profile Trunnion kit (Standard)
GLN7317	High Profile Trunnion kit
GLN7320	In-Dash Mount, DIN installation kit
HLN9457	Accessory Connector Facility Kit
GLN7325	IP54 seal, Accessory Connector

3.2 Microphones:

GMN6146	Enhanced Compact Microphone (Standard)
GMN6148	DTMF Microphone
HMN3141	Handset, low cost with Hang-up cup
HMN3000	Desk Microphone

3.3 Speakers:

All speaker connecting cables have 16-pin accessory connector plug.

GSN6059	13W External Speaker, square
---------	------------------------------

3.4 Cables:

GKN6270	Battery power cable 3m, 10A fuse (Standard)
GKN6271	Ignition switch cable

3.5 Other:

GKN6272	External Alarm, Relay and Cable Kit
GLN7323	External PTT
GLN7318	Base Tray
GPN6126	24/12V DC Converter, 6A
GPN6127	24/12V DC Converter, 15A
GPN6133	EMC approved Power Supply
HPN4002	Non-EMC approved Power Supply
HPN8393	Non-EMC approved Power Supply

Chapter 3

Maintenance

Table of Contents

Paragraph		Page
1.0	Overview	1
2.0	Disassemble the Radio	1
2.1	Remove the Control Head	1
2.2	Remove the Top Cover	1
2.3	Remove the Transceiver Board	2
2.4	Disassemble the Control Head	2
3.0	Assemble Radio	3
3.1	Assemble the Control Head	3
3.2	Replace the Transceiver Board	3
3.3	Replace the Top Cover and Control Head	3
4.0	Exploded View Diagrams and Parts	4
5.0	Service Aids	6
6.0	Test Equipment	7
7.0	Radio Tuning Procedure	8
7.1	General	8
7.2	PA Bias Voltage	9
7.3	Battery Threshold	10
7.4	Transmitter Power	10
7.5	Reference Oscillator	11
7.6	Front-End Pre-Selector	11
7.7	Rated Volume	12
7.8	Squelch	12
7.9	Transmit Deviation Limit	13
7.10	Transmit Modulation Balance (Compensation)	14

<http://www.myradio168.net>

1.0 Overview

This chapter explains, step by step, how to disassemble and assemble the radio, to transceiver board level. The chapter also contains a list of test equipment required to service the radio. The procedure for radio alignment and the test setup is also available in this chapter.

2.0 Disassemble the Radio

2.1 Remove the Control Head




Figure 3-1 Control Head Removal.

1. Insert a small flat blade screw driver, or similar, in the recess between the control head and the transceiver (to minimise cosmetic damage to the radio cover start from the bottom side).
2. Press until the side of the control head releases and then repeat the operation on the opposite side of the radio.
3. Pull the control head away from the transceiver.
4. Remove the flex from the socket on the control head board.

2.2 Remove the Top Cover



Figure 3-2 Top Cover Removal.

1. Insert a small flat blade screw driver in the side recess of the radio chassis.
2. Lift the top cover over the chassis.

2.3 Remove the Transceiver Board




Figure 3-3 Transceiver Board Removal.

1. Remove the power and antenna connector retaining clips by inserting a small flat blade screw driver between the clip and the top of the chassis wall and gently prying the clip upwards.
2. Remove 13 screws from the transceiver board using a T8 TORX driver.
3. Carefully remove the transceiver board by rotating it out of the chassis:
Slowly lift the board on the front edge, the side with the connector that mates with the control head, and pull gently toward the front of the radio.

CAUTION: The thermal grease can act as an adhesive and cause the leads of the heat dissipating devices to be overstressed if the board is lifted too quickly.



2.4 Disassemble the Control Head

1. To pull out the printed circuit board from the control head housing, insert a small blade screw driver in the side groove near the four protruding tabs. Remove the board from the control head housing.
2. Disconnect the board from the speaker by removing from the socket.
3. Remove the keypad from the control head housing by lifting up the rubber keypad. Care should be taken not to touch or get other contaminants on the conductive pads on the under side of the keypad or conductive contacts on the printed circuit board.

3.0 Assemble Radio

3.1 Assemble the Control Head




Figure 3-4 Control Head Assembly.

1. Place the keypad onto the board assembly, making sure the keypad is flush with the board.
2. Make sure the speaker including the gasket is well positioned.
3. Connect the printed circuit board to the speaker.
4. During the installation of the printed circuit board, ensure the four protruding tabs snap into the recesses.

3.2 Replace the Transceiver Board

1. Inspect and if necessary, reapply thermal grease to the heatsinking pads in the chassis.
2. Before installing the connector retaining clips, ensure that the board is sitting flush on the chassis mounting surface.
3. Install the 13 screws with 0.4 -07 NM (4-6 in lbs) of torque using a T8 TORX driver.

3.3 Replace the Top Cover and Control Head

1. Position the top cover over the chassis and replace. Ensure that the cross snaps into the recesses.
2. Connect the control head to the radio by the flex.
3. Press the control head onto the radio chassis until the protruding tabs on the chassis snap into the recesses inside the control housing, see Figure 3-5.




Figure 3-5 Control Head Replacement.

4.0 Exploded View Diagrams and Parts




Figure 3-6 Radio Exploded View Diagram.





Figure 3-7 Control Head Model A2.



GEPD5493

Figure 3-8 Control Head Model A3.

5.0 Service Aids

The list in table 3-1 includes service aids recommended for working on the GM950E/GM950i radio.

Table 3-1 Service Aids.

PART No.	DESCRIPTION	APPLICATION
GTF376	Test Box Cable	Connects radio to GTF180 test box.
GTF374	Combined Interface Cable	Connects radio to RLN4008 RIB.
GPN6133	Power Supply	Used to supply power to the radio.
GKN6266	DC Power Cable for radio	Interconnects radio to power supply.
GTF180	Test Box	Enables connection to the universal connector. Allows switching for radio testing.
RLN4008	Radio Interface Box	Enables communications between the radio and the computer's serial communications adapter.
EPN4040	Power Supply	Used to supply power to the RIB (240 VAC).
EPN4041	Power Supply	Used to supply power to the RIB (220 VAC).
3080369B72	Computer Interface Cable	Connects the computer's serial communications adapter (9 pin) to the RIB.
3080369B71	Computer Interface Cable	Connects the computer's serial communications adapter (25 pin) to the RIB.

6.0 Test Equipment

The list in table 3-2 includes all standard test equipment required for servicing two-way mobile radios, as well as several unique items designed specifically for servicing the GM950E/GM950i radio. Battery-operated test equipment is recommended when available. The "Characteristics" column is included so that equivalent equipment may be substituted; however, when no information is provided in this column, the specific Motorola model listed is either a unique item or no substitution is recommended.

Table 3-2 Recommended Test Equipment.

MODEL No.	DESCRIPTION	CHARACTERISTICS	APPLICATION
R2000 Series	System Analyser	This monitor will substitute for items with an asterisk (*)	Frequency/deviation meter and signal generator for wide-range troubleshooting and alignment.
*R1150C	Code Synthesizer		Injection of audio and digital signaling codes
*S1053D	220 VAC Voltmeter	1mV to 300V, 10-Mohm	
*HM-203-7	110 VAC Voltmeter		
*SKN6008A	Power Cable for Meter	Input impedance	Audio voltage measurements
*SKN6001A	Test Leads for Meter		
*S1350C	Watt Meter	50 ohm, $\pm 5\%$ accuracy	Transmitter power o/p measurements
*ST1213B (VHF)	Plug-in Element	10 Watts, maximum	
*ST1223B (UHF)	RF Dummy Load	0-1000 MHz, 300W	
R1065A	Load Resistor	10-watt Broadband	For use with Wattmeter
S1339A	RF Millivolt Meter 10kHz to 1.2 GHz	100 μ V to 3V rf	RF level measurements
*R1013A	SINAD Meter		Receiver sensitivity measurements
S1347D or S1348D (programmable)	DC Power Supply	0-20Vdc, 0-5 Amps	Bench supply for 13.2Vdc current limited

* Any of the R2000 Series system analysers will substitute for items with an asterisk (*)

7.0 Radio Tuning Procedure

7.1 General

The recommended hardware platform is a 386 or 486 DX 33 PC (personal computer) with 8 MBytes RAM, MS DOS 5.0, Windows 3.1, and RSS (Radio Service Software). These are required to align the radio. Refer to your RSS Installation Manual for installation and setup procedures for the required software; the user manual is accessed (and can be printed if required) via the RSS.

To perform the alignment procedures, the radio must be connected to the PC, RIB (Radio Interface Box), and Universal Test Set as shown in figure 3-9.



Figure 3-9 Radio Alignment Test Setup.

All tuning procedures are performed from the Service menu.

Before going into the Service menu, the radio must first be read using the File / Read Radio menu (if the radio has just been programmed with data loaded from disk or from a newly created codeplug, then it must still be read so that the RSS will have the radio's actual tuning values).

All Service windows read and program the radio codeplug directly; you do NOT have to use the RSS Read Radio / Write Radio functions to program new tuning values.

CAUTION: **DO NOT** switch radios in the middle of any Service procedure. Always use the Program or Cancel key to close the tuning window before disconnecting the radio. Improper exits from the Service window may leave the radio in an improperly configured state and result in seriously degraded radio or system performance.



The Service windows introduce the concept of the “Softpot”, an analog SOFTWARE controlled POTentiometer used for adjusting all transceiver alignment controls. A softpot can be selected by clicking with the mouse at the value or the slider or by hitting the TAB key until the value or the slider is highlighted.

Each Service window provides the capability to increase or decrease the ‘softpot’ value with the mouse, the arrow keys or by entering a value with the keyboard. The window displays the minimum, maximum, and step value of the softpot. In addition transmitter tuning windows indicate the transmitter frequency and whether the radio is keyed.

Adjusting the softpot value sends information to the radio to increase (or decrease) a DC voltage in the corresponding circuit. For example, increasing the value in the Reference Oscillator tune window instructs the radio microprocessor to increase the voltage across a varactor in the reference oscillator to increase the frequency. Pressing the Program button stores all the softpot values of the current window permanently in the radio.

In ALL cases, the softpot value is just a relative number corresponding to a D/A (Digital-to-Analog) generated voltage in the radio. All standard measurement procedures and test equipment are similar to previous radios.

Refer to the RSS on-line help for information on the tuning software.

Perform the following procedures in the sequence indicated.

Note: All tuning procedures must be performed at a supply voltage of 13.2V unless otherwise stated. The Modulation Analyser to measure the deviation should be set to frequency modulation with de-emphasis switched off and all high pass filters switched off.

7.2 PA Bias Voltage

Adjustment of the PA Bias is critical for proper radio operation. Improper adjustment will result in poor operation and may damage the PA FET device. For this reason, the PA bias must be set before the transmitter is keyed the first time.

1. From the Service menu, select Tx Alignment.
2. Select Bias Voltage to open the bias voltage tuning window. If the control voltage is out of range, an error message will be displayed. In this case the radio hardware has a problem and tuning must be stopped immediately.
3. Press the Toggle Bias button to set the quiescent current temporarily to 0 mA. The status bar will indicate that the bias is switched off.
4. Measure the DC current of the radio. Note the measured value and add the specified quiescent current shown in table 3-3. The result is the tuning target.
5. Press the Toggle Bias button to switch on the quiescent current again.
6. Adjust the current per the target calculated in step 4.
7. Press Program to store the softpot value.

Table 3-3 Quiescent Current Alignment.

RF-Band	Target
UHF	440mA±10%
VHF	150mA±15%

7.3 Battery Threshold

The radio uses 2 battery threshold levels Tx High and Tx Low to determine the battery condition.

1. From the Service menu, select Tx Alignment.
2. Select Battery Thresholds to open the battery thresholds tuning window.
3. Set the supply voltage to the value indicated for Tx High.
4. Press the Tx High Program button to store the softpot value for Tx High.
5. Set the supply voltage to the value indicated for Tx Low.
6. Press the Tx Low Program button to store the softpot value for Tx Low.
7. Close the window by pressing Cancel.

7.4 Transmitter Power

IMPORTANT: To set the transmitter power for customer applications use the Per Radio window under the Edit menu and set the "Level 1" and "Level 2" powers to the desired values. Only if the transmitter components have been changed should the following procedure be performed.

The advanced power setting technology employed in the GM950E/GM950i makes use of two reference power level settings along with parameters describing the circuit behaviour. To set the reference points requires tuning on two power level settings, a high power level setting, and a low power level setting.

1. From the Service menu, select Tx Alignment.
2. Select RF Power to open the RF power tuning window. The window will indicate the transmit test frequencies to be used.
3. Select Point 1 value of the first frequency.
4. Press Toggle PTT to key the radio. The status bar will indicate that the radio is transmitting.
5. Measure the transmitter power on your power meter.
6. Enter the measured value in the box Point 1.
7. Select Point 2 value of the first frequency.
8. Measure the transmitter power on your power meter.
9. Enter the measured value in the box Point 2.
10. Press Toggle PTT to dekey the radio.
11. Repeat steps 3 - 10 for all test frequencies shown in the window.
12. Press Program to store the softpot values.

7.5 Reference Oscillator

Adjustment of the reference oscillator is critical for proper radio operation. Improper adjustment will not only result in poor operation, but also a misaligned radio that will interfere with other users operating on adjacent channels. For this reason, the reference oscillator should be checked every time the radio is serviced. The frequency counter used for this procedure must have a stability of 0.1 ppm (or better).

1. From the Service menu, select Tx Alignment.
2. Select Reference Oscillator to open the reference oscillator tuning window.
3. Press Toggle PTT to key the radio. The status bar will indicate that the radio is transmitting.
4. Measure the transmit frequency on your frequency counter.
5. Adjust the reference oscillator softpot on the RSS screen to achieve a frequency as measured on the frequency counter to be within the limits shown in table 3-4 of the target frequency displayed on the RSS window.
6. Press Toggle PTT again to dekey the radio and then press Program to store the softpot value.

Table 3-4 Reference Oscillator Alignment.

RF-Band	Target
UHF	± 150 Hz
VHF	± 150 Hz

7.6 Front-End Pre-Selector

Alignment of the front-end pre-selector is normally not required on these radios. Only if the radio has poor receiver sensitivity or the pre-selector parts have been replaced the following procedure should be performed. The softpot value sets the control voltage of the pre-selector. Its value needs to be set at 7 frequencies across the frequency range.

1. Set the test box (GTF-180B) meter selection switch to the "Audio PA" position and connect a SINAD meter to the "METER" port.
2. From the Service menu, select Rx Alignment.
3. Select Front End Filter to open the pre-selector tuning window. The window will indicate the receive test frequencies to be used.
4. Select the first test frequency shown, and set the corresponding value to the start value shown in Table 3-5.
5. Set the RF test generator to the receive test frequency, and set the RF level to $10\mu\text{V}$ modulated with a 1kHz tone at the normal test deviation shown in table 3-6.
6. Measure the RSSI voltage at accessory connector pin 15 with a dc voltmeter capable of 1 mV resolution. The RSSI output is available on A2, 4 channel, radios but it is unbuffered. Therefore a high impedance ($1\text{ M}\Omega$) voltmeter must be used.
7. Decrease/increase the softpot value and note the RSSI voltage. The target softpot value is achieved when the voltage change between 2 softpot steps is lower than 0.75% of the RSSI voltage for the first time. Set test box (GTF-180B) audio switch to the "SPKR" position. The 1kHz tone must be audible at the target value to make sure the radio is receiving.
8. Repeat steps 4 - 7 for all test frequencies shown in the window.
9. Press Program to store the softpot values.

Table 3-5 Start Value for Front-End Pre-selector Tuning.

RF-Band	Start Value
UHF	Maximum
VHF	Minimum

Table 3-6 Normal Test Deviation.

Channel Spacing	Deviation
12.5 kHz	1.5 kHz
20 kHz	2.4 kHz
25 kHz	3 kHz

7.7 Rated Volume

The rated volume softpot sets the volume at normal test modulation.

1. Set test box (GTF180B) meter selection switch to the "AUDIO PA" position and the speaker load switch to the "MAXAR" position. Connect an AC voltmeter to the test box meter port.
2. From the Service menu, select Rx Alignment.
3. Select Rated Volume to open the rated volume tuning window. The screen will indicate the receive test frequency to be used.
4. Set the RF test generator to the receive test frequency, and set the RF level to 1mVolt modulated with a 1kHz tone at the normal test deviation shown in table 3-6. Set test box (GTF180B) audio switch to the "SPKR" position. The 1kHz tone must be audible to make sure the radio is receiving.
5. Adjust the value of the softpot to obtain rated audio volume (as close to 3.74 Vrms)
Note: The voltage at the meter port of the test box GTF180B is only half the voltage at the speaker.
6. Press Program to store the softpot value.

7.8 Squelch

The squelch softpots set the signal to noise ratio at which the squelch opens. The squelch value needs to be set at 7 frequencies across the frequency range. For 20/25kHz radios, the radio stores separate tuning data for 20kHz and 25kHz channel spacing. Therefore, both sets of tuning data should be set independently.

1. Set the test box (GTF180B) meter selection switch to the "Audio PA" position and connect a SINAD meter to the "METER" port.
2. From the Service menu, select Rx Alignment.
3. Select 'Squelch' to open the squelch tuning window. This window is used to set the values for 12.5kHz radios and the 25kHz data for 20/25kHz radios. The window will indicate the receive test frequencies to be used.
4. Select the first test frequency shown, and set the corresponding value to 0.
5. Set the RF test generator to the test frequency and modulate the signal generator at the normal test deviation shown in table 3-6, with 1kHz tone. Adjust the generator for a 8-10 dB SINAD level (weighted with psophometric filter).

6. Adjust the softpot value until the squelch just closes.
7. Monitor for squelch chatter; if chatter is present, repeat step 6.
8. When no chatter is detected, select the next softpot and repeat steps 4 - 7 for all test frequencies shown in the window.
9. Press Program to store the softpot values.
10. If the radio is a 20/25kHz channel spacing model, repeat steps 1 - 10 for 20kHz channel spacing using the 'Squelch (20kHz)' window.

7.9 Transmit Deviation Limit

The transmit deviation limit softpot sets the maximum deviation of the carrier. Unlike other radios, the deviation limit for GM950E/GM950i is set using low frequency (PL) rather than the usual 1kHz tone. The deviation value needs to be set at 7 frequencies across the frequency range. No audio signals need to be injected, as the radio generates a 82.5Hz tone while the deviation limit alignment window is open. This tone is used to set the maximum deviation. For 20/25kHz radios, the radio stores separate tuning data for 20kHz and 25kHz channel spacing. Therefore, both sets of tuning data should be set independently.

1. From the Service menu, select Tx Alignment.
2. Select Reference Deviation to open the reference deviation tuning window.
3. Set the value to 7 and press Program to store the softpot value.
4. From the Service menu, select Tx Alignment.
5. Select 'Deviation Limit' to open the deviation limit tuning window. This window is used to set the values for 12.5kHz radios and the 25kHz data for 20/25kHz radios. The window will indicate the transmit test frequencies to be used.
6. Select the first test frequency shown in the window.
7. Press Toggle PTT to key the radio. The status bar will indicate that the radio is transmitting.
8. Adjust the transmitter deviation to the value shown in table 3-7.
9. Press Toggle PTT to dekey the radio.
10. Repeat steps 6 - 9 for the remaining test frequencies.
11. Press Program to store the softpot values.
12. If the radio is a 20/25kHz channel spacing model, repeat steps 1 - 11 for 20kHz channel spacing using the 'Deviation Limit (20kHz)' window.

Table 3-7 Transmitter Deviation Limit Alignment Target.

Channel Spacing	Deviation
12.5 kHz	375 Hz
20 kHz	600 Hz
25 kHz	750 Hz

7.10 Transmit Modulation Balance (Compensation)

Compensation alignment balances the modulation sensitivity of the VCO and reference modulation (synthesizer low frequency port) lines. Compensation algorithm is critical to the operation of signalling schemes that have very low frequency components (e.g. PL) and could result in distorted waveforms if improperly adjusted. The compensation value needs to be set at 7 frequencies across the frequency range. For 20/25kHz radios, the radio stores separate tuning data for 20kHz and 25kHz channel spacing. Therefore, both sets of tuning data should be set independently.

1. From the Service menu, select Tx Alignment.
2. Select 'Modulation Balance' to open the deviation balance tuning window. This window is used to set the values for 12.5kHz radios and the 25kHz data for 20/25kHz radios. The window will indicate the transmit test frequencies to be used.
3. Set the Test Box (GTF180B) meter selector switch to the "GEN" position, and inject a 2kHz (two kilohertz) tone at 800 mVrms (eight-hundred millivolts) into the "Audio In" port.
4. Connect an AC meter to the meter port to insure the proper input signal level.
5. Select the first test frequency shown in the window.
6. Press Toggle PTT to key the radio. The status bar will indicate that the radio is transmitting.
7. Measure the transmitter deviation.
8. Adjust the transmitter deviation using the appropriate softpot to the value shown in Table 3-8.
9. Press Toggle PTT to dekey the radio.
10. Repeat steps 5- 9 for the remaining test frequencies.
11. Press Program to store the softpot values.
12. If the radio is a 20/25kHz channel spacing model, repeat steps 1 - 11 for 20kHz channel spacing using the 'Modulation Balance (20kHz)' window.

Table 3-8 Transmitter Deviation.

Channel Spacing	Deviation
12.5 kHz	2.1-2.2 kHz
20 kHz	3.4-3.5 kHz
25 kHz	4.3-4.5 kHz

7.11 Transmit Control Voltage Limit

The transmit control voltage limit softpot sets the maximum power control voltage. All 7 voltage limit softpots are tuned and programmed automatically when the Program button is pressed.

1. From the Service menu, select Tx Alignment.
2. Select Control Voltage Limit to open the control voltage limit tuning window.
3. Set the Power Factor to 1.3.
4. Press Program to store the softpot values.

Chapter 4

Theory of Operation

Table of Contents

Paragraph		Page
1.0	Overview	1
2.0	Controller	2
2.1	General	2
2.2	Voltage Regulators	2
2.3	Electronic On/Off	3
2.4	Mechanical On/Off	3
2.5	Ignition	3
2.6	Hook	4
2.7	Microprocessor Clock Synthesizer	4
2.8	Serial Peripheral Interface (SPI)	4
2.9	SBEP Serial Interface	5
2.10	General Purpose Input/Output	5
2.11	Normal Microprocessor Operation	5
2.12	Control Head Model A2 or A3	6
3.0	General	7
3.1	Audio Filter IC (AFIC)	7
3.2	Audio Ground	7
4.0	Transmit Audio Circuits	7
4.1	Mic Input Path	7
4.2	External Mic Path	8
4.3	PTT Sensing and TX Audio Processing	8
4.4	Option Board Audio (GM950i only)	9
5.0	Transmit Signalling Circuits	10
5.1	Sub-audible Data (PL/DPL)	10
5.2	High Speed Data and DTMF	11

6.0	Receive Audio Circuits	12
6.1	Squelch Detect	12
6.2	Audio Processing and Digital Volume Control.....	13
6.3	Audio Amplification Speaker (+) Speaker (-)	13
6.4	Handset Audio	14
6.5	Filtered Audio	14
6.6	Discriminator Audio (Unfiltered).....	14
6.7	Option Board Audio	14
7.0	Receive Signalling Circuits	15
7.1	Sub-audible Data Decoder (PL/DPL)	15
7.2	High Speed Data Decoder.....	15
7.3	Alert Tone Circuits	16
8.0	Receiver Front-End	17
8.1	Front-End Band-Pass Filter & Pre-Amplifier	17
8.2	Mixer and Intermediate Frequency (IF) Section	17
8.3	IF IC (U5201).....	18
9.0	Power Amplifier (PA) 5-25W	18
9.1	Power Controlled Stage.....	18
9.2	PA Stages.....	19
9.3	Directional Coupler	19
9.4	Antenna Switch.....	19
9.5	Harmonic Filter	20
9.6	Power Control.....	20
10.0	Frequency Synthesis	21
10.1	Reference Oscillator	21
10.2	Fractional-N Synthesizer (U7501)	21
10.3	Voltage Controlled Oscillator (VCO).....	22
10.4	Synthesizer Operation	22
11.0	Receiver Front-End	24
11.1	Front-End Band-Pass Filter and Pre-Amplifier	24
11.2	Mixer and Intermediate Frequency (IF) Section	24
11.3	IF IC (U5201).....	25

12.0	Power Amplifier (PA) 5-25W	25
12.1	Power Controlled Stage	25
12.2	PA Stages	26
12.3	Directional Coupler	26
12.4	Antenna Switch	26
12.5	Harmonic Filter	27
12.6	Power Control	27
13.0	Frequency Synthesis	28
13.1	Reference Oscillator	28
13.2	Fractional-N Synthesizer (U3701)	28
13.3	Voltage Controlled Oscillator (VCO)	29
13.4	Synthesizer Operation	29

<http://www.myradio168.net>

<http://www.myradio168.net>

1.0 Overview

This section provides a detailed theory of operation for the radio and its components.

The main radio is designed to accept one additional option board. This may provide functions such as secure voice/or a signalling decoder.

The control head is mounted directly on the front of the radio. The control head contains a speaker, LED indicators, a microphone connector, buttons and dependant of radio type, a display. These provide the user with interface control over the various features of the radio.

In addition to the power cable and antenna cable, an accessory cable can be attached to a connector on the rear of the radio. The accessory cable provides the necessary connections for items such as external speaker, foot operated PTT, ignition sensing, etc.

<http://www.myradio168.net>

2.0 Controller

2.1 General

The radio controller consists of 4 main subsections:

- Digital Control
- Audio Processing
- Power Control
- Voltage Regulation

The digital control section of the radio board is based upon a closed architecture controller configuration.

The digital section consists of a microprocessor, support memory, support logic, signal MUX ICs, the On/Off circuit, and general purpose Input/Output circuitry.

The closed architecture controller uses the Motorola 68HC11E9 (U010i) for a GM950E radio and the 68HC11E20 for a GM950i radio. In this configuration RAM and ROM are contained within the microprocessor itself. The only external memory device in the closed architecture controller is an EEPROM (2KByte for GM950i).

Note: From this point on the 68HC11E9 or E20 microprocessor will be referred to as E9/20 μ P or μ P. References to a Control Head will be to radio model A3 (Display radio).

2.2 Voltage Regulators

Voltage regulation for the controller is provided by 3 separate devices; U0631 (LP2951CM) +5V, U0601 (LM2941T) +9.3V, and UNSW 5V (a combination of R0621 and VR0621). An additional regulator is located in the RF section.

Voltage regulation providing 5V for the digital circuitry is done by U0631. Input and output capacitors (C0631/0632 and C0633-0635) are used to reduce high frequency noise and provide proper operation during battery transients. This regulator provides a reset output (pin 5) that goes to 0 volts if the regulator output goes out of regulation. This is used to reset the controller to prevent improper operation. Diode D0631 prevents discharge of C0632 by negative spikes on the 9V3 voltage

Regulator U0601 is used to generate the 9.3 volts required by some audio circuits, the RF circuitry and power control circuitry. Input and output capacitors (C0601-0603 and C0604/0605) are used to reduce high frequency noise. R0602/R0603 sets the output voltage of the regulator. If the voltage at pin 1 is greater than 1.3 volts the regulator output decreases and if the voltage is less than 1.3 volts the regulator output increases. This regulator output is electronically disabled by a 0 volt signal on pin 2. Q0601 and associated circuitry (R0601/0604/0605 and C0606) are used to disable the regulator when the radio is turned off.

UNSW 5V is only used in a few areas which draw low current and requires 5 V while the radio is off.

UNSW 5V CL is used to buffer the internal RAM. C0622 allows the battery voltage to be disconnected for a couple of seconds without losing RAM parameters. Diode D0621 prevents radio circuitry from discharging this capacitor.

The voltage 9V3 SUPP is only used in the VHF radio to supply the drain current for the RF MOS FET in the PA.

The voltage SW B+ is monitored by the μ P through the voltage divider R0641/R0642. Diode VR0641 limits the divided voltage to 5.1V to protect the μ P.

Diode D5601 (UHF) / D3601 (VHF) located on the PA section acts as protection against transients and wrong polarity of the supply voltage.

2.3 Electronic On/Off

The radio has circuitry which allows radio software and/or external triggers to turn the radio on or off without direct user action. For example, automatic turn on when ignition is sensed and off when ignition is off.

Q0611 is used to provide SW B+ to the various radio circuits. Q0611 acts as an electronic on/off switch controlled by Q0612. The switch is on when the collector of Q0612 is low. When the radio is off Q0612 is cutoff and the voltage at Q0611-base is at A+. This effectively prevents current flow through Q0611 from emitter to collector. When the radio is turned on the voltage at the base of Q0612 is high (about 0.6V) and Q0612 switches on (saturation) and pulls down the voltage at Q0611-base. With Transistor Q0611 now enabled current flows through the device. This path has a very low impedance (less than 1 ohm) from emitter to collector. This effectively provides the same voltage level at SWB+ as at A+.

The electronic on/off circuitry can be enabled by the microprocessor (through AFIC port GCB1, line B+ CONTROL), the mechanical On/Off button on the control head (line ON OFF CONTROL), or the ignition sense circuitry (line IGNITION CONTROL). If any of the 3 paths cause a low at the collector of Q0612, the electronic ON is engaged.

2.4 Mechanical On/Off

This refers to the on/off button, located on the control head, and which turns the radio on and off. If the radio is turned off and the on/off button is pressed, line ON OFF CONTROL goes high and switches the radio on as long as the button is pressed. The microprocessor is alerted through line ANALOG 3 which is pulled to low by Q0925 (Control Head Model A3) while the on/off button is pressed. If the software detects a low state it asserts B+ CONTROL via AFIC pin 39 low which keeps Q0612 and Q0611, and in turn the radio switched on.

If the on/off button is pressed and held while the radio is on, the software detects the line ANALOG 3 changing to low and switches the radio off by setting B+ CONTROL to low.

2.5 Ignition

Ignition sense is used to prevent the radio from draining the vehicle's battery because the engine is not running.

When the IGNITION input (J0400- 10) goes above 6 volts Q0421 and Q0612 turn on. This turns on SW B+ by turning on Q0611 via line IGNITION CONTROL and Q0612 and the microprocessor starts execution. The software reads the line IGNITION SENSE, determines from the level that the IGNITION input is active and sets the B+ CONTROL output of the AFIC pin 39 to high to latch on SW B+.

When the IGNITION input goes below 6 volts, Q0421 switches off and R0426, R0427 pull line IGNITION SENSE high. The software is alerted by line IGNITION SENSE to switch off the radio by setting B+ CONTROL to low. The next time the IGNITION input goes above 6 volts the above process will be repeated.

2.6 Hook

The HOOK input is used to inform the μ P when the Microphone's hang-up switch is engaged. The signal is routed from J0101-3 and transistor Q0137 to the E9/20 μ P U0101-56. The voltage range of HOOK in normal operating mode is 0-5V. If a rear GP input line is set as HOOK then the front HOOK signal is overridden.

2.7 Microprocessor Clock Synthesizer

The controller uses the oscillator in the microprocessor E9/20 μ P along with some external components (C0115-C0117, L0114, R0115, Y0114) to generate the clock. Q0114 is used to alter the clock frequency slightly under software control if there is a possibility of harmonics of this clock source interfering with the desired radio receive frequency.

2.8 Serial Peripheral Interface (SPI)

The μ P communicates to many of the IC's through its SPI port. This port consists of SPI TRANSMIT DATA (MOSI) (E9/20 μ P:U0101-52), SPI RECEIVE DATA (MISO) (E9/20 μ P:U0101-51), SPI CLK (E9/20 μ P:U0101-53) and chip select lines going to the various IC's, connected on the SPI PORT (BUS). This BUS is a synchronous bus, in that the timing clock signal CLK is sent while SPI data (SPI TRANSMIT DATA or SPI RECEIVE DATA) is sent. Therefore, whenever there is activity on either SPI TRANSMIT DATA or SPI RECEIVE DATA there should be a uniform signal on CLK. The SPI TRANSMIT DATA is used to send serial from a μ P to a device, and SPI RECEIVE DATA is used to send data from a device to a μ P. The only device from which data can be received via SPI RECEIVE DATA is the EEPROM (U0108).

On the controller there are three IC's on the SPI BUS, AFIC (U103-33), EEPROM (U0108-1) and D/A (U0731-6). In the RF sections there is one IC on the SPI BUS, the FRAC-N Synthesizer. The SPI TRANSMIT DATA and CLK lines going to the RF section are filtered by L0194/L0195 to minimize noise. The chip select lines for the IC's are decoded by the address decoder U102.

The SPI BUS is also used for the control head. U0104-1,2 buffer the SPI TRANSMIT DATA and CLK lines to the control head. U0104-3 switches off the CLK signal for the LCD display if it is not selected via LCD CE.

When the μ P needs to program any of these IC's it brings the chip select line for that IC to a logic 0 and then sends the proper data and clock signals. The amount of data sent to the various IC's are different, for example the FRAC-N can receive up to 13 bytes (97 bits) while the DAC can receive up to 3 bytes (24 bits). After the data has been sent the chip select line is returned to a logic 1.

The Option board interfaces are different in that the μ P can also read data back from devices connected.

The timing and operation of this interface is specific to the option connected, but generally follows the pattern:

- 1) an option board device generates the interrupt,
- 2) main board asserts a chip select for that option board device,
- 3) the main board μ P generates the CLK, and
- 4) when data transfer is complete the main board terminates the chip select and CLK activity.

2.9 SBEP Serial Interface

The SBEP serial interface allows the radio to communicate with the Radio Service Software (RSS). This interface connects to the Microphone connector (J0903/J0803) via Control Head connector (J0101) and comprises BUS+ (J0101-15). The line is bi-directional, meaning that either the radio or the RSS can drive the line.

When the RSS needs to communicate with the radio, an interrupt is generated by the BUS+ signal through R0104. The μ P then starts serial data communication on BUS+ by sending data from pin 50 through D0101 and receiving data at pin 47 through R0104. While the radio is sending serial data at pin 50 it receives an "echo" of the same data at pin 47.

2.10 General Purpose Input/Output

The Controller provides six general purpose lines (GP1 through GP6) available on the accessory connector J0400 to interface to external options. Lines GP1,4 are inputs, GP2 is an output and GP3,5,6 are bidirectional. The software and the hardware configuration of the radio model define the function of each port. Some ports are not connected on GM950E radio, refer to appendix B.

GP1 can be used as external PTT input or others, set by the RSS.

GP2 can be used as normal output (Q0441 placed) or external alarm output (Q0442 placed). The voltage range can be set by R0442 (0-5V) or R0443 (0 - supply voltage).

GP4 can be used as normal input (D0471, R0477 not placed) or emergency input (D0471, R0477 placed).

GP3,5,6 are bidirectional and use the same circuit configuration. Each port uses an output transistor controlled by μ P port PB5,4,7 and an input transistor read by μ P port PC2,5,3. To use one of the GP's as input the μ P must turn off the corresponding output transistor.

In addition the signals from GP3-6 are fed to the option board connectors J0102, J0103.

The 470pF and 10nF capacitors serve to filter out any AC noise which may ride on the GP lines.

2.11 Normal Microprocessor Operation

The E9/20 μ P (U0101) contains internal 12 (E9) or 20 (E20) Kilobytes ROM, 512 (E9) or 768 (E20) bytes SRAM and 512 bytes EEPROM.

The E9/20 μ P RAM is always powered to maintain parameters such as the last operating mode. This is achieved by maintaining 5V at U0101-25. Under normal conditions, when the radio is off UNSW +5V is formed by FLT A+ running to D0621.

C0622 allows the battery voltage to be disconnected for a couple of seconds without losing RAM parameters. Diode D0621 prevents radio circuitry from discharging this capacitor.

U0101-22 is the high reference voltage for the A/D ports on the E9/20 μ P. Resistor R0105 and capacitor C0105 filter the +5V reference. If this voltage is lower than +5V the A/D readings will be incorrect. Likewise U0101-21 is the low reference for the A/D ports. This line is normally tied to ground. If this line is not connected to ground, the A/D readings will be incorrect.

The MODB (U0101-25) input of the E9/20 μ P must be at a logic 1 for it to start executing correctly. The XIRQ (U0101-45) and the IRQ (U0101-46) pins should also be at a logic 1.

Optional external EEPROM (U0108) is available on some radio models. The external EEPROM is accessed through a serial connection. The E9/20 μ P generates SPI CLK (U0101-53), SPI TRANSMIT DATA (MOSI) (U0101-52) and SPI RECEIVE DATA (MISO) (U0101-51) to read or write EEPROM. On a read of EEPROM the E9/20 μ P continues generating the clock and the EEPROM places the requested data on the SPI RECEIVE DATA (MISO) line. On a write the message is followed by the data to be written to the EEPROM.

2.12 Control Head Model A2 or A3

Two Control Head versions (A2 or A3) are available for user interface. Both Control Heads contain the internal speaker, the microphone connector, several buttons to operate the radio and several indicator LEDs to inform the user about the radio status. Additionally the Control Head model A3 uses a 3 digit, 7 segment, LCD display for the channel number.

The On/Off button when pressed switches the voltage regulators on by pulling ON OFF CONTROL to high and connects the base of Q0925(A3), Q0825(A2) to FLT A+. This transistor pulls the line ANALOG 3 to low to inform the μ P that the On/Off button is pressed. If the radio is switched off, the μ P will switch it on and vice versa. All other buttons work the same way. If a button is pressed, it will connect one of the 3 lines ANALOG 1,2,3 to a resistive voltage divider connected to +5V. The voltages of the lines are A/D converted inside the μ P and specify the pressed button.

All the back light and indicator LEDs are driven by current sources and controlled by the μ P via SERIAL PERIPHERAL INTERFACE (SPI) interface. The LED status is stored in shiftregister U0941(A3), U0841(A2). Line LED CE enables the serial write process via Q0941(A3), Q0841(A2) while line LED CLCK BUF shifts the data of line SPI DATA BUF into the shiftregister.

In addition Control Head Model A3 contains the LCD display H0931. The display data of line SPI DATA BUF is shifted into the display driver by clock signal LCD CLCK BUF.

CONTROLLER BOARD AUDIO AND SIGNALLING CIRCUITS

3.0 General

3.1 Audio Filter IC (AFIC)

The AFIC (U0103) used in the controller performs RX/TX audio shaping, i.e. filtering, amplification, attenuation.

The AFIC is programmable through the SPI BUS (U0103-30/31/33), normally receiving 6 bytes. This programming sets up various paths within the AFIC to route audio signals through the appropriate filtering, gain and attenuator blocks. The AFIC also has 4 General Control Bits: GCB1,3-5 which are CMOS level outputs. GCB1 is used to switch the radio on and off under μ P control via line B+ CONTROL. GCB3 is used to switch the audio PA on and off (AUDIO PA ENABLE). GCB4 selects between the UNATTEN RX OUT audio signal and the unfiltered DET AUDIO signal. GCB5 HIGH LOW BAND can be used to switch between band splits.

3.2 Audio Ground

VAG is the dc bias used as an audio ground for the op-amps that are external to the Audio Filter IC (AFIC). U0105-1 forms this bias by dividing 9.3V with resistors R0171, R0172 and buffering the 4.65V result with a voltage follower. VAG emerges at pin 1 of U0105-1. C0172 is a bypass capacitor for VAG. The AFIC generates its own 2.5 V bias for its internal circuitry. C0153 is the bypass for the AFIC's audio ground dc bias. Note that while there are AFIC VAG, and BOARD VAG (U0105-1) each of these are separate. They do not connect together.

4.0 Transmit Audio Circuits

Refer to Figure 4-1 for reference for the following sections.


4.1 Mic Input Path

The radio supports 2 distinct microphone paths known as internal and external mic and an auxiliary path (FLAT TX AUDIO). The microphones used for the radio require a DC biasing voltage provided by a resistive network.

These two microphone audio inputs are connected together. Following the internal mic path; the microphone is plugged into the radio control head and is connected to the controller board via J0101-16. From here the signal is routed to C0142. R0141 and R0142 provide the 9.3VDC bias. R0142 and C0141 provide a 1k Ω AC path to ground that sets the input impedance for the microphone and determines the gain based on the emitter resistor in the microphone's amplifier circuit.

The MIC signal is routed to the AFIC's TX IN input (U0103-10) through R0146 and R0145 (4 channel radio) or through op-amp buffer U0106-2 and option board connector J0103-3,1 (128 channel radio). The audio signal at the output of U0106-2 should be approximately 80mV deviation with 25kHz channel spacing.

The FLAT TX AUDIO signal from accessory connector U0400-5 is buffered by op-amp U0106-1 and fed to the AFIC U0103-13 through gate U0107-1. Gate U0107-1 is controlled by the μ P port PC7 (U0101-42) and selects between FLAT TX AUDIO or signalling signal created by the μ P.



GEPD 5427

Figure 4-1 Transmit Audio Paths

4.2 External Mic Path

The external microphone signal enters the radio on accessory connector J0400 pin 2 and connects to the standard microphone input through R0421.

4.3 PTT Sensing and TX Audio Processing

Mic PTT is sensed by the μ P U0101 pin 22. An external PTT can be generated by grounding pin 3 on the accessory connector if this input is programmed for PTT.

The MIC signal is routed to the AFIC (U0103) through R0146 and R0145 (4 channel radio) or through op-amp buffer U0106-2 and option board connector J0103-3,1 (128 channel radio). R0145, C0145, the amplifier inside the AFIC (pins 9,10) and gain setting resistor R0147 pre-emphasise the MIC audio signal. After further limiting and filtering the modulation signal emerges from the AFIC at U0103-19/20. Both signals are weighted by resistors R0181, R0182 and add up to signal MOD IN.

4.4 Option Board Audio (GM950i only)

The audio coming from the microphone (J0101-16) or the external microphone (J0400-2) is routed through op-amp buffer U0106-2 (128ch only) to the option board connector J0103-3. After option board processing the signal emerges at J0103-1. The source resistor of the option board output and C0145, the amplifier inside the AFIC (U0103-9,10) and gain setting resistor R0147 pre-emphasise the signal. Inside the AFIC the signal follows a path identical to conventional transmit audio. The modulation signal emerges from the AFIC at J0103-19/20. Both signals are weighted by resistors R0181, R0182 and add up to signal MOD IN.


<http://www.myradio168.net>

5.0 Transmit Signalling Circuits

Refer to Figure 4-2 for reference for the following sections. From a hardware point of view, there are three types of signalling:

1. Sub-audible data (PL / DPL / Connect Tone) that gets summed with transmit voice or signalling,
2. DTMF data for telephone communication in trunked and conventional systems, and
3. Audible signalling including Select 5, MPT-1327, MDC, Single Tones.

All three types are supported by the hardware while the radio software determines which signalling type is available. Currently only PL/DPL and Single tones are supported in the software.



GEPD 5432

Figure 4-2 Transmit Signalling Paths

5.1 Sub-audible Data (PL/DPL)

Sub-audible data implies signalling whose frequency is below 300Hz. Although it is referred to as "sub-audible data," the actual frequency spectrum of these waveforms may be as high as 250 Hz, which is audible to the human ear. However, the radio receiver filters out any audio below 300Hz, so these tones are never heard in the actual system.

Only one type of sub-audible data can be generated by U0103 (AFIC) at any one time. The process is as follows. using the SPI BUS, the μP programs the AFIC to set up the proper low-speed data deviation and select the PL or DPL filters. The μP then generates a square wave which strobes the AFIC PL / DPL encode input PL CLOCK STROBE U0103-32 at twelve times the desired data rate. For example, for a PL frequency of 103Hz, the frequency of the square wave would be 1236Hz.

This drives a tone generator inside U0103 which generates a staircase approximation to a PL sine wave or DPL data pattern. This internal waveform is then low-pass filtered and summed with voice or data. The resulting summed waveform then appears on U0103-19,20 (MOD IN), where it is sent to the RF board as previously described for transmit audio.


5.2 High Speed Data and DTMF

The High Speed Data and DTMF waveforms are created by the μ P U0101 using summer U0105-3. Op-amp U0105-3 and resistors R0121-R0124 add up the three signals coming from the μ P pins 58, 59 and 62. The output signal of U0105-3 is routed to the AFIC (U0103-13) through gate U0107-1. Inside the AFIC the signal enters the conventional transmitter audio path at the splatter filter input. Gate U0107-1 controlled by μ P port PC7 (U0101-42) selects between data signal and FLAT TX AUDIO signal. Microphone audio is muted during High Speed Data signalling.

<http://www.myradio168.net>

6.0 Receive Audio Circuits

Refer to Figure 4-3 for reference for the following sections.



GEPD 5429

Figure 4-3 Receive Audio Paths.

6.1 Squelch Detect

The IF IC controls the squelch characteristics of the radio. With a few external parts (R5222, C5229, C5230, R5223) the squelch tail, hysteresis, attack and delay are optimized for the radio. To set the squelch threshold the signal from IF IC pin 23 (line SQ ATT IN) is routed to the squelch attenuator input of the AFIC (U0103-16). The attenuated signal (line SQ ATT OUT) from the AFIC (U0103-18) enters the IF IC at pin 20 and is used to create a squelch indicator signal available at pin 15 (line CSQ DET).

The microprocessor controlled ADAPT signal at pin 22 activates the fast squelch indicator signal at IF IC pin 18 (FAST SQ). Both squelch indicator signals CSQ DET (pin 15) and FAST SQ (pin 18) are combined, weighted by resistors R0111 / R012 and fed to one of the microprocessor's ADCs (U0101-15) for interpretation. From the voltage weighted by the resistors the μP determines whether CSQ DET, FAST SQ or both are active.

6.2 Audio Processing and Digital Volume Control

The receiver audio signal enters the controller section from the IF IC (U5201-28) on DET AUDIO. The signal is AC coupled by C0181 and enters the AFIC via the RX IN pin U0103-7.

Inside the AFIC the signal entering RX IN (U0103-7) goes through the audio path while the signal entering PL DPL IN (U0103-8) via C0182 goes through the PL/DPL path.

The audio path has a programmable amplifier, whose setting is based on the channel bandwidth being received, then a LPF filter to remove any frequency components above 3000Hz and then an HPF to remove any sub-audible data below 300Hz. Next, the recovered audio passes through a de-emphasis filter if it is enabled (to compensate for Pre-emphasis which is used to reduce the effects of FM noise). The IC then passes the audio through the 8-bit programmable attenuator whose level is set depending on the value of the volume control. Finally, the filtered audio signal passes through an output buffer within the AFIC. The audio signal exits the AFIC at RX AUDIO U0103-23.

The μ P programs the attenuator, using the SPI BUS, based on the volume setting. The minimum/maximum settings of the attenuator are set by codeplug parameters.

Since sub-audible signalling is summed with voice information on transmit, it must be separated from the voice information before processing. Any sub-audible signalling enters the AFIC from the IF IC at PL DPL IN U0103-8. Once inside it goes through the PL/DPL path. The signal first passes through one of 2 low pass filters, either PL low pass filter or DPL/LST low pass filter. Either signal is then filtered and goes through a limiter and exits the AFIC at PL DPL DECODER OUT U0103-27. At this point the signal will appear as a square wave version of the sub-audible signal which the radio received. The microprocessor (U0101-64) will decode the signal directly to determine if it is the tone/code which is currently active on that mode.

6.3 Audio Amplification Speaker (+) Speaker (-)

The output of the AFIC's digital volume pot, U0103-23 is routed through a voltage divider formed by R0401 and R0402 to set the correct input level to the audio PA (U0401). This is necessary because the gain of the audio PA is 46 dB, and the AFIC output is capable of overdriving the PA unless the maximum volume is limited.

The audio then passes through C0401 which provides AC coupling and low frequency roll-off. C0402 provides high frequency roll-off as the audio signal is routed to pins 1 and 9 of the audio power amplifier U0401.

The audio power amplifier has one inverted and one non-inverted output that produces the differential audio output SPK+ / SPK- (U0401-4/6). The inputs for each of these amplifiers are pins 1 and 9 respectively; these inputs are both tied to the received audio. The audio PA's DC biases are not activated until the audio PA is enabled at pin 8.

The audio PA is enabled via AUDIO PA ENABLE signal from the AFIC (U0103-40). When the base of Q0401 is low, the transistor is off and U0401-8 is high, using pull up resistor R0406, and the Audio PA is ON. The voltage at U0401-8 must be above 8.5VDC to properly enable the device. If the voltage is between 3.3 and 6.4V, the device will be active but has its input (U0401-1/9) off. R0404 ensures that the base of Q0401 is high on power up. Otherwise there may be an audio pop due to R0406 pulling U0401-8 high before the software can switch on Q0401.

The SPK+ and SPK- outputs of the audio PA have a DC bias which varies proportionately with FLT A+ (U0401-7). FLT A+ of 11V yields DC offset of 5V, and FLT A+ of 17V yields a DC offset of 8.5V. If either of these lines is shorted to ground, it is possible that the audio PA will be damaged. SPK+ and SPK- are routed to the accessory connector (J400-16 and 1) and to the control head (connector J0101-1 and 2).

6.4 Handset Audio

Certain hand held accessories have a speaker within them which require a different voltage level than that provided by U0401. For those devices HANDSET AUDIO is available at J0101-14.

The received audio from the output of the AFIC's digital volume attenuator is also routed to U0105-4 pin 9 where it is amplified 15 dB; this is set by the 10k/68k combination of R0154 and R0155. This signal is routed from the output of the op amp U0105-4 pin 8 to J0101-14. The control head sends this signal directly out to the microphone jack. The maximum value of this output is 6.6Vp-p.

6.5 Filtered Audio

The AFIC has an audio whose output at U0103-22 has been filtered and de-emphasized, but has not gone through the digital volume attenuator. From AFIC U0103-22 the signal is routed through gate U0107-2 and AC coupled to U0106-4. The gate controlled by AFIC port GCB4 (U0103-2) selects between the filtered audio signal from the AFIC or the unfiltered discriminator signal from the IF IC U5201. The output at U0106-4 is then routed to J0400-11. Note that any volume adjustment of the signal on this path must be done by the accessory.

6.6 Discriminator Audio (Unfiltered)

Note that discriminator audio DET AUDIO from the IF IC U5201, in addition to being routed to the AFIC, is also routed to the option connector J0103-5 (See Secure Rx description blocks for further information).

6.7 Option Board Audio

Discriminator or filtered audio, enters the option board at connector J0103-5 and J0103-4. On the option board, the signal may be processed and then fed back through (J0103-2) to AUX RX IN of the AFIC (U0103-6). From then on it follows a path identical to conventional receive audio, where it is filtered (0.3 - 3kHz) and de-emphasized.

7.0 Receive Signalling Circuits

Refer to Figure 4-4 for reference for the following sections.




Figure 4-4 Receive Signalling Path.

7.1 Sub-audible Data Decoder (PL/DPL)

The receiver audio signal entering the AFIC U0103 at pin 8 first passes through the Tone PL filter or the Digital PL filter, depending on the PL option selected for the current operating mode. Filtered PL is then coupled to the PL detector circuit, with detected PL output at U0103-27. At this point the signal will appear as a square wave version of the sub-audible signal which the radio received. The microprocessor U0101-64 will decode the signal directly to determine if it is the tone / code which is currently active on that mode.

7.2 High Speed Data Decoder

The unattenuated receiver audio signal from U0103-22 is AC coupled to the input of centre slicer circuit U0105-2. The non-inverting input of op-amp U0105-2 is fed through resistor R0162. Capacitor C0164 sets a low-pass corner frequency of 3.3kHz. The inverting input of op-amp U0105-2 is fed through resistor R0163. Capacitor C0163 sets a low-pass corner frequency of 16Hz.

During operation, R0163 / C0163 establish an average DC offset level at U0105-2 pin 6 dependent on the average DC level of the undetected signal to set the "trigger" threshold of U0105-2. R0162 / C0164 provide high audio frequency roll-off to improve falsing immunity, but passes 600 or 1200 baud signals. The detected output from the centre slicer circuit is buffered and inverted by Q0161 and then coupled to the μ P U0101-1 where algorithms perform the final decoding.

7.3 Alert Tone Circuits

When the software determines that it needs to give the operator an audible feedback (for a good key press, or for a bad key press), or radio status , it sends an alert tone to the speaker.

It does so by sending SPI BUS data to U0103 which sets up the audio path to the speaker for alert tones. The alert tone itself is generated by the AFIC.

The allowable internal alert tones are 410, 820, and 1640Hz. In this case a code contained within the SPI BUS load to the AFIC sets up the path and determines the tone frequency, and at what volume level to generate the tone. (It does not have to be related to the voice volume setting).

Inside the AFIC, this signal is routed to the alert tone generator; the output of the generator is summed into the audio chain just after the RX audio de-emphasis block. Inside U0103 the tone is amplified and filtered, then passed through the 8-bit digital volume attenuator, which is typically loaded with a special value for alert tone audio. The tone exits at U0103-23 and is routed to the audio PA like receive audio.

<http://www.myradio168.com>

UHF SPECIFIC CIRCUIT DESCRIPTION

8.0 Receiver Front-End

The receiver is able to cover the UHF range from 403 to 470 MHz. It consists of four major blocks: front-end, mixer, first IF section and IF IC. Antenna signal pre-selection is performed by two varactor tuned bandpass filters. A double balanced schottky diode mixer converts the signal to the first IF at 45.1 MHz.

Two crystal filters in the first IF section and two ceramic filters in the second IF section provide the required selectivity. The second IF at 455 kHz is mixed, amplified and demodulated in the IF IC. The processing of the demodulated audio signal is performed by an audio processing IC located in the controller section.

8.1 Front-End Band-Pass Filter & Pre-Amplifier

A two pole pre-selector filter tuned by the varactor diodes D5301 and D5302 pre-selects the incoming signal (PA RX) from the antenna switch to reduce spurious effects to following stages. The tuning voltage (FE CNTL VLTG) ranging from 2 volts to 3 volts is controlled by a Digital to Analog (D/A) converter (U0731-11) in the controller section. A dual hot carrier diode (D5303) limits any inband signal to 0 dBm to prevent damage to the pre-amplifier.

The RF pre-amplifier is an SMD device (Q5301) with collector base feedback to stabilize gain, impedance, and intermodulation. The collector current of approximately 11-16 mA is drawn from the voltage 9V3.

A second two pole varactor tuned bandpass filter provides additional filtering to the amplified signal. The varactor diodes D5304 and D5305 are controlled by the same signal which controls the pre-selector filter. A following 3 dB pad (R5310, R5314, R5316) stabilizes the output impedance and intermodulation performance.

If the UHF radio is configured for a base station application, R5319 is not placed and TP5301 and TP5302 are shorted.

8.2 Mixer and Intermediate Frequency (IF) Section

The signal coming from the front-end is converted to the first IF (45.1 MHz) using a double balanced schottky diode mixer (D5401). Its ports are matched for incoming UHF signal conversion to the 45.1 MHz IF using low side injection. The injection signal (VCO MIXER) coming from the mixer buffer (Q5771) is filtered by the lowpass consisting of (L5403, L5404, C5401 - C5403) and has a level of approximately 10 dBm.

The mixer IF output signal (RX IF) from transformer T5401 pin 2 is fed to the first two pole crystal filter Y5201. The filter output in turn is matched to the following IF amplifier.

The IF amplifier Q5201 is actively biased by a collector base feedback (R5201, R5202) to a current drain of approximately 5 mA drawn from the voltage 5V STAB. Its output impedance is matched to the second two pole crystal filter Y5202. A dual hot carrier diode (D5201) limits the filter output voltage swing to reduce overdrive effects at RF input levels above -27 dBm.

8.3 IF IC (U5201)

The first IF signal from the crystal filters feeds the IF IC (U5201) at pin 6. Within the IF IC the 45.1MHz first IF signal mixes with the second local oscillator (LO) at 44.645MHz to the second IF at 455 kHz. The second LO uses the external crystal Y5211. The second IF signal is amplified and filtered by two external ceramic filters (FL5201, FL5202). Back in the IF IC the signal is demodulated in a phase-lock detector and fed from IF IC pin 28 to the audio processing circuit AFIC U0103 located in the controller section (line DET AUDIO).

The IF IC also controls the squelch characteristics of the radio. With a few external parts (R5222, C5229, C5230, R5223) the squelch tail, hysteresis, attack and delay were optimized for the radio. To set the squelch threshold the signal from IF IC pin 23 (line SQ ATT IN) is attenuated by a microprocessor controlled audio processing IC AFIC (U0103) located in the controller section. The attenuated signal from the AFIC (line SQ ATT OUT) enters the IF IC at pin 20 and is used to create a squelch indicator signal available at pin 15 (CSQ DET).

The microprocessor controlled ADAPT signal at pin 22 activates the fast squelch indicator signal at IF IC pin 18 (FAST SQ). Both squelch indicator signals CSQ DET (pin 15) and FAST SQ (pin 18) are combined, weighted by R0111 / R0112 and fed to the microprocessor U0101 pin 15 for interpretation. From the voltage weighted by the resistors the μ P determines whether CSQ DET, FAST SQ or both are active.

At IF IC pin 11 an RSSI signal is available with a dynamic range of 70 dB. The RSSI signal is buffered by op-amp U0106-3 and available at accessory connector J0400-15.

9.0 Power Amplifier (PA) 5-25W.

The radio's 5-25 W PA is a four stage amplifier used to amplify the output from the exciter to the radio transmit level. It consists of four stages in the line-up. The first (Q5510) is a bipolar stage that is controlled via the PA control line. It is followed by another bipolar stage (Q5520), a MOS FET stage (Q5530) and a final bipolar stage (Q5536).

Devices Q5510 and Q5520 are surface mounted. MOS FET Q5530 and bipolar Transistor Q5536 are directly attached to the heat sink.

9.1 Power Controlled Stage

The first stage (Q5510) amplifies the RF signal from the VCO (line EXCITER PA) and controls the output power of the PA. The output power of the transistor Q5510 is proportional to its collector current which is adjusted by a voltage controlled current source consisting of Q5612 and Q5621. The whole stage operates off the K9V1 source which is 9.1V in transmit mode and nearly 0V in receive mode.

The collector current of Q5510 causes a voltage drop across the resistors R5623 and R5624. Transistor Q5612 adjusts the voltage drop across R5621 through PA control line (PWR CNTL). The current source Q5621 adjusts the collector current of Q5510 by modifying its base voltage until the voltage drop across R5623 and R5624 plus VBE (0.6V) equals the voltage drop across R5621 plus VBE (0.6V) of Q5611. If the voltage of PWR CNTL is raised, the base voltage of Q5612 will also rise causing more current to flow to the collector of Q5612 and a higher voltage drop across R5621. This in turn results in more current driven into the base of Q5510 by Q5621 so that the current of Q5510 is increased. The collector current settles when the voltage over the series configuration of R5623 and R5624 plus VBE of Q5621 equals the voltage over R5621 plus VBE (0.6V) of Q5611.

By controlling the output power of Q5510 and in turn the input power of the following stages the ALC loop is able to regulate the output power of the transmitter.

9.2 PA Stages

The bipolar transistor Q5520 is driven by Q5510. To reduce the collector - emitter voltage and in turn the power dissipation of Q5510 its collector current is drawn from the antenna switch circuit.

In transmit mode the base of Q5520 is slightly positive biased by a divided K9V1 signal to allow a collector current to be drawn from the antenna switch circuit and in turn switches the antenna switch to transmit while in receive mode the low K9V1 signal cuts off the collector current and in turn switches the antenna switch to receive.

The following stage uses an enhancement mode N-Channel MOS FET device (Q5530) and requires a positive gate bias and a quiescent current flow for proper operation. The voltage of the line BIAS VLTG is set in transmit mode by a Digital to Analog (D/A) converter (U0731-4) and fed to the gate of Q5530 via a resistive divider. The bias voltage is tuned in the factory. If the transistor is replaced, the bias voltage must be tuned with the Radio Service Software (RSS). Care must be taken, not to damage the device by exceeding the maximum allowed bias voltage. The collector current is drawn from the supply voltage A+.

The final stage uses the bipolar device Q5536 and operates off the A+ supply voltage. For class C operation the base is DC grounded by two series inductors (L5533, L5534). A matching network consisting of C5542-C5544 and two striplines transform the impedance to 50 Ohms and feed the directional coupler.

9.3 Directional Coupler

The directional coupler is a microstrip printed circuit which couples a small amount of the forward power off the RF power from Q5536. The coupled signal is rectified to an output power proportional negative DC voltage by the diode D5553 and sent to the power control circuit in the controller section via the line PWR DETECT for output power control. The power control circuit holds this voltage constant, thus ensuring the forward power out of the radio to be held to a constant value.

9.4 Antenna Switch

The antenna switch is switched synchronously with the K9V1 voltage and feeds either the antenna signal coming through the harmonic filter to the receiver or the transmitter signal coming from the PA to the antenna via the harmonic filter.

In transmit mode, this K9V1 voltage is high and biases Q5520 to allow a collector current to be drawn. The collector current of Q5520 drawn from A+ flows via L5542, L5541, directional coupler, D5551, L5551, D5631, L5631, R5616, R5617 and L5611 and switches the PIN diodes D5551 and D5631 to the low impedance state. D5551 leads the RF signal from the directional coupler to the harmonic filter. The low impedance of D5631 is transformed to a high impedance at the input of the harmonic filter by the resonant circuit formed by L5551, C5633 and the input capacitance of the harmonic filter.

In receive mode the low K9V1 turns off the current through the PIN diodes and switches them to the high impedance state. The antenna signal, coming through the harmonic filter, is channelled to the receiver via L5551, C5634 and line PA RX.

A high impedance resonant circuit formed by D5551 in off state and L5554, C5559 prevents an influence of the receive signal by the PA stages. The high impedance of D5631 in off state doesn't influence the receiver signal.

9.5 Harmonic Filter

The transmitter signal from the antenna switch is channelled through the harmonic filter to the antenna connector J5501. The harmonic filter is formed by inductors L5552, L5553, and capacitors C5557, C5552 through C5555. This network forms a low-pass filter to attenuate harmonic energy of the transmitter to specifications level. R5550 is used for electro - static protection.

9.6 Power Control

The power control loop regulates transmitter power with an automatic level control (ALC) loop and provides protection features against excessive control voltage and high operating temperatures.

MOS FET device bias, power and control voltage limit are adjusted under microprocessor control using a Digital to Analog (D/A) converter (U0731). The microprocessor writes the data into the D/A converter via serial interface (SRL) composed of the lines SPI CLCK SRC (clock), SPI DATA SRC (data) and DAC CE (chip enable). The D/A adjustable control voltage limit increases transmitter rise time and reduces adjacent channel splatter as it is adjusted closer to the actual operating control voltage.

The microprocessor controls K9V1 ENABLE (U0101-6) to switch on the first and the second PA stage via K9V1. The antenna switch is turned on by the collector current of the second PA stage. PA DISABLE, also microprocessor controlled (U0101-54), sets BIAS VLTG (U0731-4) and VLTG LIMIT SET (U0731-13) in receive mode to low to switch off the bias of the MOS FET device Q5530 and to switch off the power control voltage (PWR CNTL).

Through an Analog to Digital (A/D) input (VLTG LIMIT) the microprocessor can read the PA control voltage (PWR CNTL) during the tuning process.

The ALC loop regulates power by adjusting the PA control line PWR CNTL to keep the forward power voltage PWR DETECT at a constant level.

Opamp U0701-2 and resistors R0701 to R0703 and R0731 subtract the negative PWR DETECT voltage from the PWR SET D/A output U0731 pin 2. The result is connected to opamp inverting input U0701-4 pin 9. This voltage which is compared with a 4.6 volt reference VAG present at noninverting input U0701-4 pin 10 and controls the output power of the PA via pin 8 and control line PWR CNTL. The 4.6 volt reference VAG is set by a resistive divider circuit (R0171, R0172) which is connected to ground and 9.3 volts and buffered by opamp U0105-1.

During normal transmitter operation the voltages at the opamp inputs U0701-4 pins 9 and 10 should be equal to 4.6 volts and the PA control voltage output at pin 8 should be between 4 and 7 volts. If power falls below the desired setting, PWR DETECT increases, causing the output at U0701-2 pin 7 to decrease and the opamp output U0701-4 pin 8 to increase.

A comparator formed by U0701-4 increases the PA control voltage PA CNTL until PWR DETECT is at the desired level. The power set D/A output voltage PWR SET (U0731-2) at U0701-2 pin 5 adjusts power in steps by adjusting the required value of PWR DETECT. As PWR SET (U0731-2) decreases, transmitter power must increase to make PWR DETECT larger and keep the inverting input U0701-4 pin 9 at 4.6 volts.

Loop frequency response is controlled by opamp feedback components R0712 and C0711. Opamp U0701-3 compares the power control voltage PWR CNTL divided by resistors R0717 to R0719 with the voltage limit setting VLTG LIMIT SET from the D/A converter (U0731-13) and keeps the control voltage constant via Q0711 if the control voltage, reduced by the resistive divider (R0717 to R0719), approaches the voltage of VLTG LIMIT SET (U0731-13).

Rise and fall time of the output power during transmitter keying and dekeying is controlled by the comparator formed by opamp U0701-3.

During normal transmitter operation the voltage at U701-3 pin 13 is higher than the voltage at pin 12 causing the output at pin 14 being low and switching off transistor Q0711. Diode D0732 reduces the bias voltage BIAS VLTG for low control voltage levels.

The temperature of the PA area is monitored by opamp U0701-1 using thermistor R5641 (located in the PA section). If the temperature increases, the resistance of R5641 decreases, decreasing the voltage PA TEMP. The inverting amplifier formed by U0701-1 amplifies the PA TEMP voltage and if the voltage at opamp pin 1 approaches 4.6 V plus the voltage (ON) across D0721, U0701-1 simulates an increased power which in turn decreases the power control voltage until the voltage at U0701-4 pin 9 is 4.6V again. During normal transmitter operation the output voltage of opamp U0701-1 pin 1 is below 4.6V. Diode D5601 located in the PA section acts as protection against transients and wrong polarity of the supply voltage.

10.0 Frequency Synthesis

The complete synthesizer subsystem consists of the Reference Oscillator (U7502), the Fractional-N synthesizer (U7501), the Voltage Controlled Oscillator (Q5741, Q5751), the RX and TX buffer stages (Q5771, Q5781) and the feedback amplifier (Q5791).

10.1 Reference Oscillator

The Reference Oscillator (Y5702) contains a temperature compensated crystal oscillator with a frequency of 16.8 MHz. An analog to digital (A/D) converter internal to U5701 (FRAC-N) and controlled by the microprocessor via serial interface (SRL) sets the voltage at the warp output of U5701 pin 16 to set the frequency of the oscillator. The output of the oscillator (pin 2 of Y5702) is applied to pin 14 (XTAL1) of U5701 via a RC series combination.

In applications where less frequency stability is required the oscillator inside U5701 is used along with an external crystal Y5701, the varactor diode D5702, C5708, C5710 and R5704.

10.2 Fractional-N Synthesizer (U7501)

The FRAC-N synthesizer IC (U7501) consists of a pre-scaler, a programmable loop divider, control divider logic, a phase detector, a charge pump, an A/D converter for low frequency digital modulation, a balance attenuator to balance the high frequency analog modulation and low frequency digital modulation, a 13V positive voltage multiplier, a serial interface for control, and finally a super filter for the regulated 9.3 volts.

A voltage of 9.3V applied to the super filter input (U7501 pin 22) supplies an output voltage of 8.6 VDC at pin 18. It supplies the VCO (Q5741), VCO modulation bias circuit (via R5714) and the synthesizer charge pump resistor network (R5723, R5724, R5726). The synthesizer supply voltage is provided by the 5V regulator U5801.

In order to generate a high voltage to supply the phase detector (charge pump) output stage at pin VCP (U5701-32), a voltage of 13 VDC is being generated by the positive voltage multiplier circuitry (D5701-1-3, C5716, C5717). This voltage multiplier is basically a diode capacitor network driven by two (1.05MHz) 180 degrees out of phase signals (U5701-9 and -10).

Output LOCK (U5701-2) provides information about the lock status of the synthesizer loop. A high level at this output indicates a stable loop. IC U5701 divides the 16.8 MHz reference frequency down to 2.1 MHz and provides it at pin 11. This signal is used as clock signal by the controller.

The serial interface (SRL) is connected to the microprocessor via the data line SPI DATA (U5701-5), clock line SPI CLK (U5701-6), and chip enable line FRACN CE (U5701-7).

10.3 Voltage Controlled Oscillator (VCO)

The Voltage Controlled Oscillator (VCO) is formed by the colpitts oscillator FET Q5741. Q5741 draws a drain current of 12 mA from the FRAC-N IC super filter output. The oscillator frequency is half of the desired frequency and mainly determined by L5743, C5742, C5743, C5745 - C5748 and varactor diodes D5741 / D5742. Diode D5743 controls the amplitude of the oscillator.

A balanced frequency doubler T5751, D5751 converts the oscillator fundamental to the desired UHF frequency. With a steering voltage from 2.5V to 10.5V at the varactor diodes the full RX and TX frequency range from 357.9 MHz to 470 MHz is covered.

After the doubler a 3-pole bandpass filter rejects unwanted harmonics at the first and third oscillator fundamental frequency and matches the output to the Common VCO Buffer Q5751. Q5751 draws a collector current of 13 mA from the stabilized 5V (U5801) and drives the Pre-scaler Buffer Q5791, the PA Buffer Q5781 (Pout = 13dBm) and Mixer Buffer Q5771 (Pout = 10dBm). Q5791 draws a collector current of 8 mA from the stabilized 5V and Q5771, Q5781 both draw 17mA from the 9V3 source. The buffer stages Q5771, Q5781 and the feedback amplifier Q5791 provide the necessary gain and isolation for the synthesizer loop.

Q5731 is controlled by output AUX3 of U5701 (pin 1) and enables the RX or TX buffer. In RX mode AUX3 is nearly at ground level, in TX mode about 5V DC. In TX mode with R5732 pulled to ground level by Q5731 the modulation signal coming from the FRAC-N synthesizer IC (U5701 pin28) modulates the VCO via varactor diode D5731 while in RX mode the modulation circuit is disabled by pulling R5732 to a higher level through R5772.

10.4 Synthesizer Operation

The complete synthesizer subsystem works as follows. The output signal of the VCO (Q5741) is frequency doubled by doubler D5751 and, buffered by Common VCO Buffer Q5751. To close the synthesizer loop, the collector of Q5791 is connected to the PREIN port of synthesizer U5701 (pin 20). The buffer output (Q5751) also provides signals for the Mixer Buffer Q5771 and the PA Buffer (Q5781).

The pre-scaler in the synthesizer (U5701) is basically a dual modulus pre-scaler with selectable divider ratios. This divider ratio of the pre-scaler is controlled by the loop divider, which in turn receives its inputs via the SRL. The output of the pre-scaler is applied to the loop divider. The output of the loop divider is connected to the phase detector, which compares the loop divider's output signal with the reference signal. The reference signal is generated by dividing down the signal of the reference oscillator (Y5702).

The output signal of the phase detector is a pulsed DC signal which is routed to the charge pump. The charge pump outputs a current at pin 29 (I OUT of U5701). The loop filter (which consists of R5715-R5717, C5723-C5725, C5727) transforms this current into a voltage that is applied to the varactor diodes D5741, D5742 and alters the output frequency of the VCO. The current can be set to a value fixed in the FRAC-N IC or to a value determined by the currents flowing into CPBIAS 1 (U5701-27) or CPBIAS 2 (U5701-26). The currents are set by the value of R5724 or R5726 respectively. The selection of the three different bias sources is done by software programming.

To reduce synthesizer lock time when new frequency data has been loaded into the synthesizer the magnitude of the loop current is increased by enabling the IADAPT line (U5701-31) for a certain software programmable time (Adapt Mode). The adapt mode timer is started by a low to high transient of the FRACN CE line. When the synthesizer is within the lock range the current is determined only by the resistors connected to CPBIAS 1, CPBIAS 2, or the internal current source.

A settled synthesizer loop is indicated by a high level of signal LOCK DET (U5701-2). This signal is routed to uP U0101-17 for further processing.

In order to modulate the PLL the two spot modulation method is utilized. Via pin 8 (MODIN) on U5701 the audio signal is applied to both the A/D converter (low freq path) as well as the balance attenuator (high freq path). The A/D converter converts the low frequency analog modulating signal into a digital code that is applied to the loop divider, thereby causing the carrier to deviate. The balance attenuator is used to adjust the VCO's deviation sensitivity to high frequency modulating signals. The output of the balance attenuator is present at the MODOUT port (U5701-28) and connected to the VCO modulation diode D5731.

<http://www.myradio.com>

VHF SPECIFIC CIRCUIT DESCRIPTION

11.0 Receiver Front-End

The receiver is able to cover the VHF range from 136 to 174 MHz. It consists of four major blocks: front-end, mixer, first IF section and IF IC. Antenna signal pre-selection is performed by two varactor tuned bandpass filters. A double balanced schottky diode mixer converts the signal to the first IF at 45.1 MHz.

Two crystal filters in the first IF section and two ceramic filters in the second IF section provide the required selectivity. The second IF at 455 kHz is mixed, amplified and demodulated in the IF IC. The processing of the demodulated audio signal is performed by an audio processing IC located in the controller section.

11.1 Front-End Band-Pass Filter and Pre-Amplifier

A two pole pre-selector filter tuned by the dual varactor diode D3301 pre-selects the incoming signal (PA RX) from the antenna switch to reduce spurious effects to following stages. The tuning voltage (FE CNTL VLTG) ranging from 2 volts to 8 volts is controlled by a Digital to Analog (D/A) converter (U0731-11) in the controller section. A dual hot carrier diode (D3303) limits any inband signal to 0dBm to prevent damage to the pre-amplifier.

The RF pre-amplifier is an SMD device (Q3301) with collector base feedback to stabilize gain, impedance, and intermodulation. The collector current of approximately 11-16 mA, drawn from the voltage 9V3, is controlled by a current source composed of Q3302, R3302, R3300, and R3311 - R3313. In transmit mode the high K9V1 signal fed through diode D3300 switches off the current source and in turn the pre-amplifier. In receive mode K9V1 must be low to switch on the current source. A 3 dB pad (R3306 - R3308 and R3315 - R3318) stabilizes the output impedance and intermodulation performance.

A second two pole varactor tuned bandpass filter provides additional filtering to the amplified signal. The dual varactor diode D3304 is controlled by the same signal which controls the pre-selector filter.

If the VHF radio is configured for a base station application, R3318 is not placed and TP3301 and TP3302 are shorted.

11.2 Mixer and Intermediate Frequency (IF) Section

The signal coming from the front-end is converted to the first IF (45.1 MHz) using a double balanced schottky diode mixer (D3331). Its ports are matched for incoming VHF signal conversion to the 45.1MHz IF using high side injection. The injection signal (VCO MIXER) coming from the mixer buffer (Q3770) is filtered by the lowpass consisting of (L3333, L3334, C3331 - C3333) and has a level of approximately 10 dBm.

The mixer IF output signal (RX IF) from transformer T3301 pin 2 is fed to the first two pole crystal filter Y5201. The filter output in turn is matched to the following IF amplifier.

The IF amplifier Q5201 is actively biased by a collector base feedback (R5201, R5202) to a current drain of approximately 5 mA drawn from the voltage 5V STAB. The output impedance is matched to the second two pole crystal filter Y5202. A dual hot carrier diode (D5201) limits the filter output voltage swing to reduce overdrive effects at RF input levels above -27 dBm.

11.3 IF IC (U5201)

The first IF signal from the crystal filters feeds the IF IC (U5201) at pin 6. Within the IF IC the 45.1MHz first IF signal mixes with the second local oscillator (LO) at 44.645MHz to the second IF at 455 kHz. The second LO uses the external crystal Y5211. The second IF signal is amplified and filtered by two external ceramic filters (FL5201, FL5202). Back in the IF IC the signal is demodulated in a phase-lock detector and fed from IF IC pin 28 to the audio processing circuit AFIC U0103 located in the controller section (line DET AUDIO).

The IF IC also controls the squelch characteristics of the radio. With a few external parts (R5222, C5229, C5230, R5223) the squelch tail, hysteresis, attack and delay were optimized for the radio. To set the squelch threshold the signal from IF IC pin 23 (line SQ ATT IN) is attenuated by a microprocessor controlled audio processing IC AFIC (U0103) located in the controller section. The attenuated signal from the AFIC (line SQ ATT OUT) enters the IF IC at pin 20 and is used to create a squelch indicator signal available at pin 15 (CSQ DET).

The microprocessor controlled ADAPT signal at pin 22 activates the fast squelch indicator signal at IF IC pin 18 (FAST SQ). Both squelch indicator signals CSQ DET (pin 15) and FAST SQ (pin 18) are combined, weighted by R0111 / R0112 and fed to the microprocessor U0101 pin 15 for interpretation. From the voltage weighted by the resistors the μ P determines whether CSQ DET, FAST SQ or both are active.

At IF IC pin 11 an RSSI signal is available with a dynamic range of 70 dB. The RSSI signal is buffered by op-amp U0106-3 and available at accessory connector J0400-15.

12.0 Power Amplifier (PA) 5-25W

The radio's 5-25 W PA is a three stage amplifier used to amplify the output from the exciter to the radio transmit level. It consists of three stages in the line-up. The first (Q3511) is a bipolar stage that is controlled via the PA control line. It is followed a MOS FET stage (Q3521) and a final bipolar stage (Q3531).

Devices Q3511 and Q3521 are surface mounted. Bipolar Transistor Q3531 is directly attached to the heat sink.

12.1 Power Controlled Stage

The first stage (Q3511) amplifies the RF signal from the VCO (line EXCITER PA) and controls the output power of the PA. The output power of the transistor Q3511 is proportional to its collector current which is adjusted by a voltage controlled current source consisting of Q3641 and Q3642. The current of the whole stage is drawn from the RX-TX Switch through coil L3652.

The collector current of Q3511 causes a voltage drop across the resistors R3645 and R3646. Transistor Q3641 adjusts the voltage drop across R3644 through PA control line (PWR CNTL). The current source Q3642 adjusts the collector current of Q3511 by modifying its base voltage until the voltage drop across R3645 and R3646 plus VBE (0.6V) equals the voltage drop across R3644. If the voltage of PWR CNTL is raised, the base voltage of Q3641 will also rise causing more current to flow to the collector of Q3641 and a higher voltage drop across R3644. This in turn results in more current driven into the base of Q3511 by Q3642 so that the current of Q3511 is increased. The collector current settles when the voltage over the series configuration of R3645 and R3646 plus VBE of Q3642 equals the voltage over R3644. By controlling the output power of Q3511 and in turn the input power of the following stages the ALC loop is able to regulate the output power of the transmitter.

In receive mode the PA control line (PWR CNTL) is at ground level and switches off the collector current of Q3641 which in turn switches off the current source transistor Q3642 and the RF transistor Q3511.

12.2 PA Stages

The following stage uses an enhancement mode N-Channel MOS FET device (Q3521) and requires a positive gate bias and a quiescent current flow for proper operation. The voltage of the line BIAS VLTG is set in transmit mode by a Digital to Analog (D/A) converter (U0731-4) and fed to the gate of Q3521 via the resistive network R3613 - R3615. The bias voltage is tuned in the factory. If the transistor is replaced, the bias voltage must be tuned with the Radio Service Software (RSS). Care must be taken, not to damage the device by exceeding the maximum allowed bias voltage. The collector current is drawn from the supply voltage 9V3 SUPP.

The final stage uses the bipolar device Q3531 and operates off the A+ supply voltage. For class C operation the base is DC grounded by two series inductors (L3521, L3522). A matching network consisting of C3530-C3534, L3532, L3533 and two striplines transform the impedance to 50 Ohms and feed the directional coupler.

12.3 Directional Coupler

The directional coupler is a microstrip printed circuit which couples a small amount of the forward power off the RF power from Q3531. The coupled signal is rectified to an output power proportional negative DC voltage by the diode D3657 and sent to the power control circuit in the controller section via the line PWR DETECT for output power control. The power control circuit holds this voltage constant, thus ensuring the forward power out of the radio to be held to a constant value.

12.4 Antenna Switch

The antenna switch is switched synchronously with the PWR CNTL signal and feeds either the antenna signal coming through the harmonic filter to the receiver or the transmitter signal coming from the PA to the antenna via the harmonic filter.

In transmit mode, this PWR CNTL signal is above 1 V and biases Q3511 through Q3641 and Q3642 to allow a collector current to be drawn. The collector current of Q3511 drawn from A+ flows via L3631, L3531, L3532, L3533, directional coupler, D3551, L3651, D3651, L3652, Resistors R3645, R3646, R3648 and switches the PIN diodes D3551 and D3651 to the low impedance state. D3551 leads the RF signal from the directional coupler to the harmonic filter. The low impedance of D3651 is transformed to a high impedance at the input of the harmonic filter by the resonant circuit formed by L3651, C3652 and the input capacitance of the harmonic filter.

In receive mode the PWR CNTL signal at ground level turns off the current through the PIN diodes and switches them to the high impedance state. The antenna signal, coming through the harmonic filter, is channelled to the receiver via L3651, C3651 and line PA RX. The high impedance of D3651 in off state does not influence the receiver signal.

12.5 Harmonic Filter

The transmitter signal from the antenna switch is channelled through the harmonic filter to the antenna connector J3501. The harmonic filter is formed by inductors L3551, L3552, and capacitors C3551 - C3554. This network forms a low-pass filter to attenuate harmonic energy of the transmitter to specifications level. R3551 is used for electro - static protection.

12.6 Power Control

The power control loop regulates transmitter power with an automatic level control (ALC) loop and provides protection features against excessive control voltage and high operating temperatures.

MOS FET device bias, power and control voltage limit are adjusted under microprocessor control using a Digital to Analog (D/A) converter (U0731). The microprocessor writes the data into the D/A converter via serial interface (SRL) composed of the lines SPI CLCK SRC (clock), SPI DATA SRC (data) and DAC CE (chip enable). The D/A adjustable control voltage limit increases transmitter rise time and reduces adjacent channel splatter as it is adjusted closer to the actual operating control voltage.

The microprocessor controls K9V1 ENABLE (U0101-6) to switch on the first and the second PA stage via K9V1. The antenna switch is turned on by the collector current of the first PA stage. PA DISABLE, also microprocessor controlled (U0101-54), sets BIAS VLTG (U0731-4) and VLTG LIMIT SET (U0731-13) in receive mode to low to switch off the bias of the MOS FET device Q3521 and to switch off the power control voltage (PWR CNTL).

Through an Analog to Digital (A/D) input (VLTG LIMIT) the microprocessor can read the PA control voltage (PWR CNTL) during the tuning process.

The ALC loop regulates power by adjusting the PA control line PWR CNTL to keep the forward power voltage PWR DETECT at a constant level.

Opamp U0701-2 and resistors R0701 to R0703 and R0731 subtract the negative PWR DETECT voltage from the PWR SET D/A output U0731 pin 2. The result is connected to opamp inverting input U0701-4 pin 9. This voltage which is compared with a 4.6 volt reference VAG present at noninverting input U0701-4 pin 10 and controls the output power of the PA via pin 8 and control line PWR CNTL. The 4.6 volt reference VAG is set by a resistive divider circuit (R0171, R0172) which is connected to ground and 9.3 volts and buffered by opamp U0105-1.

During normal transmitter operation the voltages at the opamp inputs U0701-4 pins 9 and 10 should be equal to 4.6 volts and the PA control voltage output at pin 8 should be between 4 and 7 volts. If power falls below the desired setting, PWR DETECT increases, causing the output at U0701-2 pin 7 to decrease and the opamp output U0701-4 pin 8 to increase.

A comparator formed by U0701-4 increases the PA control voltage PA CNTL until PWR DETECT is at the desired level. The power set D/A output voltage PWR SET (U0731-2) at U0701-2 pin 5 adjusts power in steps by adjusting the required value of PWR DETECT. As PWR SET (U0731-2) decreases, transmitter power must increase to make PWR DETECT larger and keep the inverting input U0701-4 pin 9 at 4.6 volts.

Loop frequency response is controlled by opamp feedback components R0712 and C0711. Opamp U0701-3 compares the power control voltage PWR CNTL divided by resistors R0717 to R0719 with the voltage limit setting VLTG LIMIT SET from the D/A converter (U0731-13) and keeps the control voltage constant via Q0711 if the control voltage, reduced by the resistive divider (R0717 to R0719), approaches the voltage of VLTG LIMIT SET (U0731-13).

Rise and fall time of the output power during transmitter keying and dekeying is controlled by the comparator formed by opamp U0701-3.

During normal transmitter operation the voltage at U701-3 pin 13 is higher than the voltage at pin 12 causing the output at pin 14 being low and switching off transistor Q0711. Diode D0732 reduces the bias voltage BIAS VLTG for low control voltage levels.

The temperature of the PA area is monitored by opamp U0701-1 using thermistor R3611 (located in the PA section). If the temperature increases, the resistance of R3611 decreases, decreasing the voltage PA TEMP. The inverting amplifier formed by U0701-1 amplifies the PA TEMP voltage and if the voltage at opamp pin 1 approaches 4.6 V plus the voltage (ON) across D0721, U701-1 simulates an increased power which in turn decreases the power control voltage until the voltage at U0701-4 pin 9 is 4.6V again. During normal transmitter operation the output voltage of opamp U701-1 pin 1 is below 4.6V. Diode D3601 located in the PA section acts as protection against transients and wrong polarity of the supply voltage.

13.0 Frequency Synthesis

The complete synthesizer subsystem consists of the Reference Oscillator (Y3702 or Y3701), the Fractional-N synthesizer (U3701), the Voltage Controlled Oscillator (Q3741, Q3751), the RX and TX buffer stages (Q3760, Q3770, Q3780) and the feedback amplifier (Q3790).

13.1 Reference Oscillator

The Reference Oscillator (Y3702) contains a temperature compensated crystal oscillator with a frequency of 16.8 MHz. An analog to digital (A/D) converter internal to U3701 and controlled by the microprocessor via serial interface (SRL) sets the voltage at the warp output of U3701 pin 16 to set the frequency of the oscillator. The output of the oscillator (pin 2 of Y3702) is applied to pin 14 (XTAL1) of U3701 via a RC series combination.

In applications where less frequency stability is required the oscillator inside U3701 is used along with an external crystal Y3701, the varactor diode D3702, C3708, C3710 and R3704.

13.2 Fractional-N Synthesizer (U3701)

The FRAC-N synthesizer IC (U3701) consists of a pre-scaler, a programmable loop divider, control divider logic, a phase detector, a charge pump, an A/D converter for low frequency digital modulation, a balance attenuator to balance the high frequency analog modulation and low frequency digital modulation, a 13V positive voltage multiplier, a serial interface for control, and finally a super filter for the regulated 9.3 volts.

A voltage of 9.3V applied to the super filter input (U3701 pin 22) supplies an output voltage of 8.6 VDC at pin 18. It supplies the VCO (Q3741 / Q3751), VCO modulation bias circuit (R3714) and the synthesizer charge pump resistor network (R3723, R3724). The synthesizer supply voltage is provided by the 5V regulator U3801.

In order to generate a high voltage to supply the phase detector (charge pump) output stage at pin VCP (U3701-32), a voltage of 13 VDC is being generated by the positive voltage multiplier circuitry (D3701-1-3, C3716, C3717). This voltage multiplier is basically a diode capacitor network driven by two (1.05 MHz) 180 degrees out of phase signals (U3701-9 and -10).

Output LOCK (U3701-2) provides information about the lock status of the synthesizer loop. A high level at this output indicates a stable loop. IC U3701 divides the 16.8 MHz reference frequency down to 2.1 MHz and provides it at pin 11. This signal is used as clock signal by the controller.

The serial interface (SRL) is connected to the microprocessor via the data line SPI DATA (U3701-5), clock line SPI CLK (U3701-6), and chip enable line FRACN CE (U3701-7).

13.3 Voltage Controlled Oscillator (VCO)

The Voltage Controlled Oscillator (VCO) uses 2 colpitts oscillators, FET Q3741 for transmit and FET Q3751 for receive. The appropriate oscillator is switched on or off by FRAC-N IC output AUX3 (U3701-1) using transistors Q3742 and Q3752. In RX mode AUX3 is nearly at ground level and Q3742 enables a current flow from the source of FET Q3751 while Q3752 is switched off. In TX mode AUX3 is about 5V DC and Q3742 is switched off. Q3752 is switched on and enables a current flow from the source of FET Q3741 while Q3751 is switched off. When switched on the FETs draw a drain current of 8 mA from the FRAC-N IC super filter output. The frequency of the receive oscillator is mainly determined by L3752, C3752, C3754 - C3756 and varactor diodes D3751 / D3752. Diode D3754 controls the amplitude of the oscillator. The frequency of the transmit oscillator is mainly determined by L3734, C3736 - C3740 and varactor diodes D3732 / D3733. Diode D3739 controls the amplitude of the oscillator. With a steering voltage from 3V to 10V at the varactor diodes the RX frequency range from 181.1 MHz to 219.1 MHz and the TX frequency range from 136 MHz to 174 MHz are covered. In TX mode the modulation signal coming from the FRAC-N synthesizer IC (U3701 pin 28) modulates the TX VCO via varactor diode D3731.

Both oscillator outputs are combined and buffered by the VCO Buffer Q3760. Q3760 draws a collector current of 13 mA from the stabilized 5V (U3801) and drives the Mixer Buffer Q3770. Q3770 draws a collector current of 17 mA from the 9V3 voltage and drives the PA Buffer Q3780 (Pout = 13dBm) and the Pre-scaler Buffer Q3790. Q3790 draws a collector current of 8 mA from the stabilized 5V (U3801) and drives the pre-scaler internal to the FRAC-N IC. In transmit mode Q3780 is switched on by the K9V1 signal and draws a collector current of 19 mA from the K9V1 voltage. The injection signal VCO MIXER with a level of 10dBm feeds the mixer through R3774. The buffer stages Q3760, Q3770, Q3780 and the feedback amplifier Q3790 provide the necessary gain and isolation for the synthesizer loop.

13.4 Synthesizer Operation

The complete synthesizer subsystem works as follows. The combined output signal of the RX VCO (Q3751) and TX VCO (Q3741) is buffered by VCO Buffer Q3760, Mixer Buffer Q3770 and Pre-scaler Buffer Q3790. To close the synthesizer loop, the collector of Q3790 is connected to the PREIN port of synthesizer U3701 (pin 20). The output of (Q3770) also provides signals for the mixer (via VCO MIXER) and the PA Buffer (Q3780).

The pre-scaler in the synthesizer (U3701) is basically a dual modulus pre-scaler with selectable divider ratios. This divider ratio of the pre-scaler is controlled by the loop divider, which in turn receives its inputs via the SRL. The output of the pre-scaler is applied to the loop divider. The output of the loop divider is connected to the phase detector, which compares the loop divider's output signal with the reference signal. The reference signal is generated by dividing down the signal of the reference oscillator (Y3702).

The output signal of the phase detector is a pulsed DC signal which is routed to the charge pump. The charge pump outputs a current at pin 29 (I OUT of U3701). The loop filter (which consists of R3715 - R3717, C3723 - C3725, C3727) transforms this current into a voltage that is applied to the varactor diodes D3732, D3733 (TX), D3751, D3752 (RX) and alters the output frequency of the TX VCO (Q3741) and RX VCO (Q3751). The current can be set to a value fixed in the FRAC-N IC or to a value determined by the current flowing into CPBIAS 1 (U3701-27). The current is set by the value of R3723 and R3724. The selection of the two different bias sources is done by software programming.

To reduce synthesizer lock time when new frequency data has been loaded into the synthesizer the magnitude of the loop current is increased by enabling the IADAPT line (U3701-31) for a certain software programmable time (Adapt Mode). The adapt mode timer is started by a low to high transient of the FRACN CE line. When the synthesizer is within the lock range the current is determined only by the resistors connected to CPBIAS 1 or the internal current source.

A settled synthesizer loop is indicated by a high level of signal LOCK DET (U3701-2). This signal is routed to μ P U0101-17 for further processing.

In order to modulate the PLL the two spot modulation method is utilized. Via pin 8 (MODIN) on U3701 the audio signal is applied to both the A/D converter (low freq path) as well as the balance attenuator (high freq path). The A/D converter converts the low frequency analog modulating signal into a digital code that is applied to the loop divider, thereby causing the carrier to deviate. The balance attenuator is used to adjust the VCO's deviation sensitivity to high frequency modulating signals. The output of the balance attenuator is present at the MODOUT port (U3701-28) and connected to the VCO modulation diode D3731.


Chapter 5

Diagrams and Parts Lists


Table of Contents

Description	Page
UHF Diagrams and Parts Lists	
Main Board - UHF PCB Layout Component Side	1
Main Board - UHF PCB Layout Solder Side	3
Main Board - UHF GM950i, Controller Schematic Diagram 1 of 2	5
Main Board - UHF GM950i, Controller Schematic Diagram 2 of 2	7
Parts List	9
Main Board - UHF GM950E, Controller Schematic Diagram 1 of 2	13
Main Board - UHF GM950E, Controller Schematic Diagram 2 of 2	15
Parts List	17
Main Board - UHF Supply Voltage Schematic Diagram	21
Parts List	23
Main Board - UHF Power Control Schematic Diagram	25
Parts List	27
Main Board - UHF Power Amplifier 5-25W Schematic Diagram	29
Parts List	31
Main Board - UHF Synthesizer Schematic Diagram	33
Parts List	35
Main Board - UHF Voltage Controlled Oscillator Schematic Diagram	37
Parts List	39
Main Board - UHF RX-FE Schematic Diagram	41
Parts List	43
Main Board - UHF RX-IF Schematic Diagram	45
Parts List	47


Description	Page
VHF Diagrams and Parts Lists	
Main Board - VHF PCB Layout Component Side	49
Main Board - VHF PCB Layout Solder Side	51
Main Board - VHF GM950i, Controller Schematic Diagram 1 of 2	53
Main Board - VHF GM950i, Controller Schematic Diagram 2 of 2	55
Parts List.	57
Main Board - VHF GM950E, Controller Schematic Diagram 1 of 2	61
Main Board - VHF GM950E, Controller Schematic Diagram 2 of 2	63
Parts List.	65
Main Board - VHF Supply Voltage Schematic Diagram	69
Parts List.	71
Main Board - VHF Power Control Schematic Diagram	73
Parts List.	75
Main Board - VHF Power Amplifier 5-25W Schematic Diagram	77
Parts List.	79
Main Board - VHF Synthesizer Schematic Diagram	81
Parts List.	83
Main Board - VHF Voltage Controlled Oscillator Schematic Diagram	85
Parts List.	87
Main Board - VHF RX-FE Schematic Diagram	89
Parts List.	91
Main Board - VHF RX-IF Schematic Diagram	93
Parts List.	95
Control Head Diagrams and Parts Lists	
Control Head - Model K, PCB Layout	97
Control Head - Model K, Schematic Diagram	99
Parts List.	101
Control Head - Model P, PCB Layout	103
Control Head - Model P, Schematic Diagram	105
Parts List.	107



UHF Main Board Component Side
PCB No. 8485668Z01




UHF Main Board Solder Side
PCB No. 8485668Z01



0102725B33_CNTL (64 CHANNEL 12.5kHz) GE PD5459-1
 0102725B39_CNTL (64 CHANNEL 20/25kHz) GE PD5461-1

note 1: values are depending on channel spacing
 changed by: R0157 0102725B33 (128 CHANNEL 12.5kHz) 15k
 0102725B39 (128 CHANNEL 20/25kHz) 30k
 changed by: R0186 0102725B33 (128 CHANNEL 12.5kHz) 27k
 0102725B39 (128 CHANNEL 20/25kHz) 51k

UHF GM950i, Controller Schematic Diagram
 1 of 2



UHF GM950i, Controller_IO Schematic Diagram
2 of 2

UHF GM950i Main Board - Controller

Circuit Ref	Motorola Part No.	Description
C0101	2113743K15	100nF 16V
C0102	2113741F17	470pF 50V
C0103	2311049A42	TANT CP 3.3uF 10% 6V
C0104	2113741F49	10nF 50V
C0105	2113743K15	100nF 16V
C0109	2113741F17	470pF 50V
C0110	2113741F17	470pF 50V
C0111	2113741F17	470pF 50V
C0112	2113741F25	1nF 50V
C0114	2113740A41	33pF 5% 50V
C0115	2113740A37	22pF 5% 50V
C0116	2113740G16	Ceramic Chip 3.6 P
C0117	2113740A41	33pF 5% 50V
C0118	2113741F17	470pF 50V
C0119	2113741F17	470pF 50V
C0121	2113743K05	39nF 16V
C0122	2113741F41	4.7nF 50V
C0125	2113743K15	100nF 16V
C0126	2113743K15	100nF 16V
C0127	2113743K15	100nF 16V
C0131	2113743K15	100nF 16V
C0132	2113743K15	100nF 16V
C0133	2113743K15	100nF 16V
C0134	2113743K15	100nF 16V
C0137	2113741F49	10nF 50V
C0141	2311049J26	TANT CP 10uF 20% 16V
C0142	2113743A19	100nF 16V
C0145	2113741F25	1nF 50V
C0148	2113741F17	470pF 50V

Circuit Ref	Motorola Part No.	Description
C0149	2113740F39	33pF 5% 50V
C0150	2311049A05	TANT CP 470nF 10% 25V
C0151	2113741F17	470pF 50V
C0152	2311049A07	TANT CP 1uF 10% 16V
C0153	2113743K15	100nF 16V
C0154	2113743K15	100nF 16V
C0155	2113740F39	33pF 5% 50V
C0157	2113741F17	470pF 50V
C0161	2113743K15	100nF 16V
C0162	2113743K15	100nF 16V
C0163	2113743K15	100nF 16V
C0164	2113741F41	4.7nF 50V
C0170	2311049A07	TANT CP 1uF 10% 16V
C0171	2311049J23	TANT CP 10uF 10% 6V
C0172	2311049A07	TANT CP 1uF 10% 16V
C0173	2311049A07	TANT CP 1uF 10% 16V
C0174	2113743K15	100nF 16V
C0175	2113741F25	1nF 50V
C0176	2311049A42	TANT CP 3.3 UF 10% 6V
C0181	2113743K15	100nF 16V
C0182	2113743K15	100nF 16V
C0184	2311049A07	TANT CP 1uF 10% 16V
C0185	2113740F51	100pF 5% 50V
C0191	2113743K15	100nF 16V
C0194	2113741F17	470pF 50V
C0196	2113741F17	470pF 50V
C0197	2113741F17	470pF 50V
C0198	2113741F17	470pF 50V
C0199	2113741F17	470pF 50V

UHF GM950i Main Board - Controller

Circuit Ref	Motorola Part No.	Description
C0401	2113743A19	100nF 16V
C0402	2113741F37	3.3nF 50V
C0404	2311049A99	TANT CP 47uF 20% 10V
C0405	2113741F25	1nF 50V
C0406	2113741F25	1nF 50V
C0407	2109720D14	CER LOW DIST 100nF
C0411	2113741F49	10nF 50V
C0412	2113741F17	470pF 50V
C0413	2113741F49	10nF 50V
C0414	2113741F17	470pF 50V
C0419	2113741F25	1nF 50V
C0420	2113741F25	1nF 50V
C0421	2113741F17	470pF 50V
C0422	2113741F17	470pF 50V
C0431	2113741F17	470pF 50V
C0435	2113741F49	10nF 50V
C0436	2113741F17	470pF 50V
C0438	2113741F49	10nF 50V
C0439	2113741F17	470pF 50V
C0441	2113741F49	10nF 50V
C0442	2113741F17	470pF 50V
C0444	2113741F17	470pF 50V
C0445	2311049A05	TANT CP 470nF 10% 25V
C0446	2113741F17	470pF 50V
C0450	2311049A99	TANT CP 47uF 20% 10V
C0451	2113741F17	470pF 50V
C0454	2113741F17	470pF 50V
C0455	2113741F17	470pF 50V
C0461	2113741F49	10nF 50V
C0462	2113741F17	470pF 50V
C0463	2113741F49	10nF 50V
C0464	2113741F17	470pF 50V
C0471	2113741F17	470pF 50V

Circuit Ref	Motorola Part No.	Description
C0472	2113741F17	470pF 50V
D0101	4813833C02	DIODE DUAL SOT MMBD6100
J0101	0902636Y01	Connector Flex Side Entry
J0102	0904424J06	Connector double row 8pin
J0103	0904424J06	Connector double row 8pin
J0400	2804503J01	Accessory Connector 16
L0114	2460578C43	INDUCTOR CHIP 33.0UH
L0170	2462587K26	CHIP IND 33000 NH
L0194	2462587Q40	COIL CHIP 270nH
L0195	2462587Q40	COIL CHIP 270nH
L0401	2484657R01	Ferrite Bead
L0402	2484657R01	Ferrite Bead
Q0114	4880214G02	TSTR NPN 40V .2A
Q0137	4880048M01	TSTR NPN DIG 47k/47k
Q0138	4880048M01	TSTR NPN DIG 47k/47k
Q0161	4880214G02	TSTR NPN 40V .2A
Q0401	4880214G02	TSTR NPN 40V .2A
Q0411	4880214G02	TSTR NPN 40V .2A
Q0412	4880048M01	TSTR NPN DIG 47k/47k
Q0421	4880048M01	TSTR NPN DIG 47k/47k
Q0431	4880048M01	TSTR NPN DIG 47k/47k
Q0432	4880048M01	TSTR NPN DIG 47k/47k
Q0433	4880214G02	TSTR NPN 40V .2A
Q0442	4880052M01	TSTR NPN DRLNGTN
Q0461	4880048M01	TSTR NPN DIG 47k/47k
Q0462	4880214G02	TSTR NPN 40V .2A
Q0471	4880048M01	TSTR NPN DIG 47k/47k
R0101	0662057A73	10k 1/16W 5%
R0102	0662057A65	4k7 1/16W 5%
R0103	0662057A73	10k 1/16W 5%
R0104	0662057A85	33k 1/16W 5%
R0105	0662057A73	10k 1/16W 5%


Circuit Ref	Motorola Part No.	Description
R0106	0662057A57	2k2 1/16W 5%
R0107	0662057A25	100 1/16W 5%
R0108	0662057A89	47k 1/16W 5%
R0109	0662057A89	47k 1/16W 5%
R0110	0662057A73	10k 1/16W 5%
R0111	0662057A85	33k 1/16W 5%
R0112	0662057A93	68k 1/16W 5%
R0113	0662057A73	10k 1/16W 5%
R0114	0662057A65	4k7 1/16W 5%
R0115	0662057B28	1.8M 1/16W 5%
R0116	0662057C61	270 1/16W 5%
R0117	0662057C61	270 1/16W 5%
R0118	0662057A65	4k7 1/16W 5%
R0119	0662057A49	1k 1/16W 5%
R0120	0662057A73	10k 1/16W 5%
R0121	0662057B03	160k 1/16W 5%
R0122	0662057A93	68k 1/16W 5%
R0123	0662057A97	100k 1/16W (not used)
R0124	0662057A69	6k8 1/16W 5%
R0125	0662057B05	200k 1/16W
R0126	0662057B05	200k 1/16W
R0127	0662057B05	200k 1/16W
R0128	0662057A73	10k 1/16W 5%
R0134	0662057A73	10k 1/16W 5%
R0135	0662057A89	47k 1/16W 5%
R0136	0662057A85	33k 1/16W 5%
R0137	0662057A89	47k 1/16W 5%
R0138	0662057A65	4k7 1/16W 5%
R0139	0662057B07	240k 1/16W
R0141	0662057A25	100 1/16W 5%
R0142	0662057A49	1k 1/16W 5%
R0143	0662057A89	47k 1/16W 5%
R0144	0662057A89	47k 1/16W 5%

Circuit Ref	Motorola Part No.	Description
R0145	0662057A84	30k 1/16W 5%
R0147	0662057B04	180k 1/16W 5%
R0148	0662057B14	470k 1/16W 5%
R0149	0662057B47	0 1/16W
R0150	0662057A90	51k 1/16W 5%
R0151	0662057A73	10k 1/16W 5%
R0152	0662057A73	10k 1/16W 5%
R0154	0662057A73	10k 1/16W 5%
R0155	0662057A93	68k 1/16W 5%
R0156	0662057B47	0 1/16W
R0157	0662057A77 0662057A84	15k 1/16W 5% (12.5kHz) 30k 1/16W 5% (20/25kHz)
R0161	0662057A97	100k 1/16W
R0162	0662057A73	10k 1/16W 5%
R0163	0662057A97	100k 1/16W
R0165	0662057A89	47k 1/16W 5%
R0166	0662057A73	10k 1/16W 5%
R0167	0662057A89	47k 1/16W 5%
R0171	0662057R92	47.5k .1W 1%
R0172	0662057R92	47.5k .1W 1%
R0175	0662057B02	150k 1/16W
R0181	0662057A84	30k 1/16W 5%
R0182	0662057A73	10k 1/16W 5%
R0183	0662057A73	10k 1/16W 5%
R0184	0662057A84	30k 1/16W 5%
R0186	0662057A83 0662057A90	27k 1/16W 5% (12.5kHz) 51k 1/16W 5% (20/25kHz)
R0189	0662057A95	82k 1/16W 5%
R0401	0662057A65	4k7 1/16W 5%
R0402	0662057A49	1k 1/16W 5%
R0404	0662057A73	10k 1/16W 5%
R0405	0662057A73	10k 1/16W 5%
R0406	0662057A81	22k 1/16W 5%


UHF GM950i Main Board - Controller

Circuit Ref	Motorola Part No.	Description
R0407	0662057A77	15k 1/16W 5%
R0411	0662057A73	10k 1/16W 5%
R0412	0662057A65	4k7 1/16W 5%
R0413	0662057A89	47k 1/16W 5%
R0414	0662057C61	270 1/16W 5%
R0422	0662057A73	10k 1/16W 5%
R0425	0662057A73	10k 1/16W 5%
R0426	0662057A89	47k 1/16W 5%
R0427	0662057B47	0 1/16W
R0431	0662057A89	47k 1/16W 5%
R0432	0662057A65	4k7 1/16W 5%
R0435	0662057C61	270 1/16W 5%
R0436	0662057A89	47k 1/16W 5%
R0437	0662057A65	4k7 1/16W 5%
R0438	0662057A73	10k 1/16W 5%
R0441	0662057A73	10k 1/16W 5%
R0443	0662057A65	4k7 1/16W 5%
R0444	0662057C61	270 1/16W 5%
R0446	0662057A97	100k 1/16W
R0450	0662057A43	560 1/16W 5%
R0451	0662057A97	100k 1/16W
R0454	0662057A49	1k 1/16W 5%
R0455	0662057B47	0 1/16W
R0461	0662057A89	47k 1/16W 5%
R0462	0662057A65	4k7 1/16W 5%
R0463	0662057C61	270 1/16W 5%
R0464	0662057A73	10k 1/16W 5%
R0472	0662057B47	0 1/16W
R0474	0662057A89	47k 1/16W 5%
R0475	0662057A65	4k7 1/16W 5%
R0476	0662057C61	270 1/16W 5%
U0101	5102898X66	PROC350 PLAT S/W R010000 A3

Circuit Ref	Motorola Part No.	Description
U0102	5113805A30	IC 10F8 DCDR/REMUX 74HC138
U0103	5102227J35	CHIP CAR TEST 27J35
U0104	5105492X36	74AC08 4 AND GATES
U0105	5183222M49	IC QUAD OPAMP_3403_
U0106	5183222M49	IC QUAD OPAMP_3403_
U0107	5184704M60	IC MUX/DEMUX TRIPLE 2-CHNL
U0108	5105462G78	IC FEPR0M 1&K SPEI CMOS
U0401	5109699X01	AUDIO PA TDA1915C
VR0118	4880140L06	DIODE 5.1V 5% 225mW
VR0411	4813830A27	DIODE 14V 5% 225mW
VR0421	4813830A27	DIODE 14V 5% 225mW
VR0422	4880140L06	DIODE 5.1V 5% 225mW
VR0431	4813830A27	DIODE 14V 5% 225mW
VR0435	4813830A27	DIODE 14V 5% 225mW
VR0441	4813830A40	SOC23 AUTO SDN
VR0444	4880140L06	DIODE 5.1V 5% 225mW
VR0445	4813830A27	DIODE 14V 5% 225mW
VR0450	4813830A27	DIODE 14V 5% 225mW
VR0454	4813830A27	DIODE 14V 5% 225mW
VR0464	4813830A27	DIODE 14V 5% 225mW
VR0471	4813830A40	SOC23 AUTO SDN
Y0114	4880113R01	CRYSTAL 7.9488



UHF GM950E, Controller Schematic Diagram
1 of 2



UHF GM950E, Controller_IO Schematic Diagram
2 of 2

UHF GM950E Main Board - Controller

Circuit Ref	Motorola Part No.	Description
C0101	2113743K15	100nF 16V
C0102	2113741F17	470pF 50V
C0103	2311049A42	TANT CP 3.3uF 10% 6V
C0104	2113741F49	10nF 50V
C0105	2113743K15	100nF 16V
C0109	2113741F17	470pF 50V
C0110	2113741F17	470pF 50V
C0111	2113741F17	470pF 50V
C0112	2113741F25	1nF 50V
C0114	2113740A41	33pF 5% 50V
C0115	2113740A37	22pF 5% 50V
C0116	2113740G16	CERAMIC CHIP 3.6 P
C0117	2113740A41	33pF 5% 50V
C0118	2113741F17	470pF 50V
C0119	2113741F17	470pF 50V
C0121	2113743K05	39nF 16V
C0122	2113741F41	47nF 50V
C0125	2113743K15	100nF 16V
C0126	2113743K15	100nF 16V
C0127	2113743K15	100nF 16V
C0131	2113743K15	100nF 16V (not used)
C0132	2113743K15	100nF 16V
C0133	2113743K15	100nF 16V (not used)
C0134	2113743K15	100nF 16V
C0137	2113741F49	10nF 50V
C0141	2311049J26	TANT CP 10uF 20% 16V
C0145	2113741F25	1nF 50V
C0148	2113741F17	470pF 50V
C0149	2113740F39	33pF 5% 50V

Circuit Ref	Motorola Part No.	Description
C0150	2311049A05	TANT CP 470nF 10% 25V
C0151	2113741F17	470pF 50V
C0152	2311049A07	TANT CP 1uF 10% 16V
C0153	2113743K15	100nF 16V
C0154	2113743K15	100nF 16V
C0155	2113740F39	33pF 5% 50V
C0157	2113741F17	470pF 50V
C0161	2113743K15	100nF 16V
C0162	2113743K15	100nF 16V
C0163	2113743K15	100nF 16V
C0164	2113741F41	4.7nF 50V
C0170	2311049A07	TANT CP 1uF 10% 16V
C0171	2311049J23	TANT CP 10uF 10% 6V
C0172	2311049A07	TANT CP 1uF 10% 16V
C0173	2311049A07	TANT CP 1uF 10% 16V
C0174	2113743K15	100nF 16V
C0175	2113741F25	1nF 50V
C0176	2311049A42	TANT CP 3.3 uF 10% 6V
C0181	2113743K15	100nF 16V
C0182	2113743K15	100nF 16V
C0194	2113741F17	470pF 50V
C0196	2113741F17	470pF 50V
C0197	2113741F17	470pF 50V
C0198	2113741F17	470pF 50V
C0199	2113741F17	470pF 50V
C0401	2113743A19	100nF 16V
C0402	2113741F37	3.3nF 50V
C0404	2311049A99	TANT CP 47uF 20% 10V
C0405	2113741F25	1nF 50V

UHF GM950E Main Board - Controller


Circuit Ref	Motorola Part No.	Description
C0406	2113741F25	1nF 50V
C0407	2109720D14	CER LOW DIST 100nF
C0419	2113741F25	1nF 50V
C0420	2113741F25	1nF 50V
C0421	2113741F17	470pF 50V
C0422	2113741F17	470pF 50V
C0431	2113741F17	470pF 50V
C0444	2113741F17	470pF 50V
C0454	2113741F17	470pF 50V
C0455	2113741F17	470pF 50V
D0101	4813833C02	DUAL SOT MMBD6100
J0101	0902636Y01	Connector Flex Side Entry
J0102	0904424J06	Connector double row 8pin
J0103	0904424J06	Connector double row 8pin
J0400	2804503J01	Accessory Connector 16
L0114	2460578C43	Inductor CHIP 33.0UH 1
L0170	2462587K26	CHIP IND 33000 NH
L0194	2462587Q40	COIL CHIP 270nH
L0195	2462587Q40	COIL CHIP 270nH
L0401	2484657R01	Ferrite Bead
L0402	2484657R01	Ferrite Bead
Q0114	4880214G02	NPN 40V
Q0137	4880048M01	NPN DIG 47k/47k
Q0138	4880048M01	NPN DIG 47k/47k
Q0161	4880214G02	NPN 40V
Q0401	4880214G02	NPN 40V
Q0421	4880048M01	NPN DIG 47k/47k
Q0431	4880048M01	NPN DIG 47k/47k
R0101	0662057A73	10k 1/16W 5%
R0102	0662057A65	4k7 1/16W 5%
R0103	0662057A73	10k 1/16W 5%
R0104	0662057A85	33k 1/16W 5%
R0105	0662057A73	10k 1/16W 5%

Circuit Ref	Motorola Part No.	Description
R0106	0662057A57	2k2 1/16W 5%
R0107	0662057A25	100 1/16W 5%
R0108	0662057A89	47k 1/16W 5%
R0109	0662057A89	47k 1/16W 5%
R0110	0662057A73	10k 1/16W 5%
R0111	0662057A85	33k 1/16W 5%
R0112	0662057A93	68k 1/16W 5%
R0113	0662057A73	10k 1/16W 5%
R0114	0662057A65	4k7 1/16W 5%
R0115	0662057B28	1.8M 1/16W 5%
R0116	0662057C61	270 1/16W 5%
R0117	0662057C61	270 1/16W 5%
R0118	0662057A65	4k7 1/16W 5%
R0119	0662057A49	1k 1/16W 5%
R0120	0662057A73	10k 1/16W 5%
R0121	0662057B03	160k 1/16W 5%
R0122	0662057A93	68k 1/16W 5%
R0123	0662057A97	100k 1/16W (not used)
R0124	0662057A69	6k8 1/16W 5%
R0125	0662057B05	200k 1/16W
R0126	0662057B05	200k 1/16W
R0127	0662057B05	200k 1/16W
R0128	0662057A73	10k 1/16W 5%
R0130	0662057B47	0 1/16W
R0134	0662057A73	10k 1/16W 5%
R0137	0662057A89	47k 1/16W 5%
R0138	0662057A65	4k7 1/16W 5%
R0139	0662057B07	240k 1/16W
R0141	0662057A25	100 1/16W 5%
R0142	0662057A49	1k 1/16W 5%
R0145	0662057A84	30k 1/16W 5%
R0146	0662057B47	0 1/16W
R0147	0662057B04	180k 1/16W 5%

Circuit Ref	Motorola Part No.	Description
R0148	0662057B14	470k 1/16W 5%
R0149	0662057B47	0 1/16W
R0150	0662057A90	51k 1/16W 5%
R0153	0662057A65	4k7 1/16W 5%
R0154	0662057A73	10k 1/16W 5%
R0155	0662057A93	68k 1/16W 5%
R0156	0662057B47	0 1/16W
R0157	0662057A77 0662057A84	15k 1/16W 5% (12.5kHz) 30k 1/16W 5% (20/25kHz)
R0161	0662057A97	100k 1/16W
R0162	0662057A73	10k 1/16W 5%
R0163	0662057A97	100k 1/16W
R0165	0662057A89	47k 1/16W 5%
R0166	0662057A73	10k 1/16W 5%
R0167	0662057A89	47k 1/16W 5%
R0171	0662057R92	47.5k .1W 1%
R0172	0662057R92	47.5k .1W 1%
R0175	0662057B02	150k 1/16W
R0181	0662057A84	30k 1/16W 5%
R0182	0662057A73	10k 1/16W 5%
R0183	0662057A73	10k 1/16W 5% (not used)
R0184	0662057A84	30k 1/16W 5%
R0401	0662057A65	4k7 1/16W 5%
R0402	0662057A49	1k 1/16W 5%
R0404	0662057A73	10k 1/16W 5%
R0405	0662057A73	10k 1/16W 5%
R0406	0662057A81	22k 1/16W 5%
R0407	0662057A77	15k 1/16W 5%
R0413	0662057A89	47k 1/16W 5%
R0415	0662057B47	0 1/16W 5%
R0421	0662057B47	0 1/16W (not used)
R0422	0662057A73	10k 1/16W 5%
R0425	0662057A73	10k 1/16W 5%

Circuit Ref	Motorola Part No.	Description
R0426	0662057A89	47k 1/16W 5%
R0427	0662057B47	0 1/16W
R0431	0662057A89	47k 1/16W 5%
R0432	0662057A65	4k7 1/16W 5%
R0436	0662057A89	47k 1/16W 5%
R0439	0662057B47	0 1/16W
R0444	0662057C61	270 1/16W 5%
R0454	0662057A49	1k 1/16W 5%
R0461	0662057A89	47k 1/16W 5%
R0465	0662057B47	0 1/16W
R0471	0662057B47	0 1/16W
R0472	0662057B47	0 1/16W
R0474	0662057A89	47k 1/16W 5%
U0101	5102898X67	PROC350 PLAT S/W R010000 A2
U0102	5113805A30	IC 10F8 DCDR/REMUX 74HC138
U0103	5102227J35	CHIP CAR TEST 27J35
U0104	5105492X36	74AC08 4 AND GATES
U0105	5183222M49	IC QUAD OPAMP __3403__
U0401	5109699X01	AUDIO PA TDA1915C
VR0118	4880140L06	DIODE 5.1V 5% 225mW
VR0421	4813830A27	DIODE 14V 5% 225mW
VR0422	4880140L06	DIODE 5.1V 5% 225mW
VR0431	4813830A27	DIODE 14V 5% 225mW
VR0444	4880140L06	DIODE 5.1V 5% 225mW
VR0454	4813830A27	DIODE 14V 5% 225mW
Y0114	4880113R01	CRYSTAL 7.9488

<http://www.myradio168.net>




0102725B36 Supply Voltage
GEPD5449-1

UHF Main Board - Supply Voltage

Circuit Ref	Motorola Part No.	Description
C0601	2113741F17	470pF 50V
C0602	2109720D14	100nF LOW DIST
C0603	2380090M24	LYT 10uF 50V 20%
C0604	2311049A97	33uF 20% 16V
C0605	2109720D14	100nF LOW DIST
C0611	2311049A99	TANT CP 47uF 20% 10V
C0612	2113743K15	100nF 16V
C0613	2113741F17	470pF 50V
C0621	2113741F17	470pF 50V
C0622	2311049A99	TANT CP 47uF 20% 10V
C0631	2109720D14	100nF LOW DIST
C0632	2311049A97	33uF 20% 16V
C0633	2113743E07	22nF 16V
C0634	2311049A99	47uF 20% 10V
C0635	2109720D14	100nF LOW DIST
C0641	2113743K15	100nF 16V
D0611	4813833C02	DUAL SOT MMBD6100
D0621	4813833C02	DUAL SOT MMBD6100
D0631	4813833C02	DUAL SOT MMBD6100
Q0601	4880214G02	NPN 40V
Q0611	4805123M27	PNP SOT89
Q0612	4880214G02	NPN 40V
R0601	0662057A73	10k 1/16W 5%
R0602	0660076E70	FILM 7500
R0603	0660076E51	FILM 1200
R0604	0662057A49	1k 1/16W 5%
R0605	0662057A69	6k8 1/16W 5%
R0606	0662057B47	0 1/16W
R0611	0662057A51	1k2 1/16W 5%

Circuit Ref	Motorola Part No.	Description
R0612	0662057C87	3300 5 1/8
R0613	0662057C87	3300 5 1/8
R0614	0662057A73	10k 1/16W 5%
R0615	0662057A73	10k 1/16W 5%
R0616	0662057A73	10k 1/16W 5%
R0617	0662057C87	3300 5 1/8
R0621	0662057A57	2k2 1/16W 5%
R0631	0662057A01	10 1/16W 5%
R0632	0662057A01	10 1/16W 5%
R0641	0662057A84	30k 1/16W 5%
R0642	0662057A73	10k 1/16W 5%
U0601	5105625U25	9.3V REG 2941
U0631	5105469E65	VLTG REGLTR LP2951C
VR0621	4880140L06	5.1V 5% 225mW
VR0641	4880140L06	5.1V 5% 225mW

<http://www.myradio168.net>




UHF Power Control Schematic Diagram

UHF Main Board - Power Control

Circuit Ref	Motorola Part No.	Description
C0701	2113740F51	100pF 5% 50V
C0702	2113740F51	100pF 5% 50V
C0703	2113743K15	100nF 16V
C0711	2113741A59	CL2
C0712	2113740F42	43pF 5% 50V
C0713	2113740F51	100pF 5% 50V
C0714	2113743A19	100nF 16V
C0716	2113741A33	3.3nF
C0721	2113740F51	100pF 5% 50V
C0722	2113740F51	100pF 5% 50V
C0723	2113740F51	100pF 5% 50V
C0731	2113743K15	100nF 16V Y5V
C0732	2113740F51	100pF 5% 50V
C0733	2113743A23	220nF 16V
C0741	2113740F51	100pF 5% 50V
D0721	4813833C02	DIODE DUAL SOT MMBD6100
D0731	4813833C02	DIODE DUAL SOT MMBD6100
D0732	4813833C02	DIODE DUAL SOT MMBD6100
Q0711	4880214302	TSTR NPN 40V .2A
Q0731	4880048M01	TSTR NPN DIG 47k/47k
Q0741	4880048M01	TSTR NPN DIG 47k/47k
Q0742	4805128M27	TSTR PNP SOT89 BSR33
R0701	0662057A93	68k 1/16W 5%
R0702	0662057A89	47k 1/16W 5%
R0703	0662057A73	10k 1/16W 5%
R0704	0662057A93	68k 1/16W 5%
R0711	0662057A81	22k 1/16W 5%

Circuit Ref	Motorola Part No.	Description
R0712	0662057A37	330 1/16W 5%
R0713	0662057A61	3k3 1/16W 5%
R0714	0662057A81	22k 1/16W 5%
R0715	0662057A81	22k 1/16W 5%
R0716	0662057B16	560k 1/16W 5%
R0717	0662057A85	33k 1/16W 5%
R0718	0662057A93	68k 1/16W 5%
R0719	0662057A93	68k 1/16W 5%
R0721	0662057A73	10k 1/16W 5%
R0722	0662057A81	22k 1/16W 5%
R0723	0662057A89	47k 1/16W 5%
R0724	0662057A97	100k 1/16W
R0725	0662057A73	10k 1/16W 5%
R0731	0662057A81	22k 1/16W 5%
R0732	0662057A65	4k7 1/16W 5%
R0733	0662057A89	47k 1/16W 5%
R0734	0662057R92	47.5k .1W 1%
R0735	0662057C01	0 1/10W 5%
R0741	0662057A49	1k 1/16W 5%
R0742	0662057A49	1k 1/16W 5%
U0701	5183222M49	IC QUAD OPAMP __3403__
U0731	5113811G02	IC D/A CONV & BIT 4 CHAN

<http://www.myradio168.net>



UHF Power Amplifier 5-25W Schematic Diagram

UHF Main Board - Power Amplifier 5-25W


Circuit Ref	Motorola Part No.	Description
C5501	2113740F27	10pF 5% 50V
C5502	2113741F49	10nF 50V X7R
C5503	2113740F37	27pF 5% 50V
C5512	2113740F33	18pF 5% 50V
C5513	2113740F34	20pF 5% 50V
C5521	2113740A39	27pF 5% 50V
C5522	2113740A44	43pF 5% 50V
C5523	2113741F49	10nF 50V
C5530	2311049A01	TANT CP 100nF 10% 35V
C5531	2113741F49	10nF 50V
C5532	2113740F51	100pF 5% 50V
C5533	2111078B31	HQ 36pF 5%
C5534	2111078B27	HQ 30pF 5%
C5535	2111078B27	HQ 30pF 5%
C5536	2111078B25	HQ 27pF 5%
C5537	2111078B25	HQ 27pF 5%
C5541	2111078B31	HQ 36pF 5%
C5542	2111078B31	HQ 36pF 5%
C5543	2111078B25	HQ 27pF 5%
C5544	2111078B16	HQ 13pF 5%
C5547	2111078B42	HQ 100pF 5%
C5548	2113741F49	10nF 50V
C5551	2111078B42	HQ 100pF
C5552	2111078B12	HQ 9.1pF 5%
C5553	2111078B15	HQ 12pF 5%
C5554	2111078B09	HQ 6.8pF 5%
C5555	2111078B48	HQ 160pF 5%
C5556	2113741F25	1nF 50V
C5558	2113740F20	5.1pF 5% 50V

Circuit Ref	Motorola Part No.	Description
C5559	2113741F25	1nF 50V
C5600	2113740A67	330pF 5% 50V
C5602	2113740F51	100pF 5% 50V
C5603	2113741F25	1nF 50V
C5604	2311049A45	TANT CP 10uF 10% 35V
C5611	2113741F49	10nF 50V
C5612	2113741F49	10nF 50V
C5615	2113741F25	1nF 50V
C5616	2113740A67	330pF 5% 50V
C5617	2113740A67	330pF 5% 50V
C5618	2311049A01	TANT CP 100nF 10% 35V
C5619	2113740F51	100pF 5% 50V
C5621	2113741F25	1nF 50V
C5622	2113741F49	10nF 50V
C5623	2113740F51	100pF 5% 50V
C5631	2113741F25	1nF 50V X7R
C5632	2111078B38	HQ 68pF 5%
C5633	2113740F15	3.3pF 5% 50V
C5634	2113740F51	100pF 5% 50V
C5642	2113741F25	1nF 50V
D5551	4802482J02	DIODE PIN MA/COM
D5553	4813825A05	DIODE CHIP SCHOTTKY
D5601	4813832B35	DIODE TRANSORB
D5631	4802482J02	DIODE PIN MA/COM
L5501	2460591A11	Square Coil 7.66nH 3T
L5503	2462587T38	Coil Chip 22nH 5%
L5532	2484657R01	Ferrite Bead
L5533	2460591C23	Square Coil 16nH 3T
L5534	2484657R01	Ferrite Bead

UHF Main Board - Power Amplifier 5-25W

Circuit Ref	Motorola Part No.	Description
L5541	2460591X01	Coil Square
L5542	2484657R01	Ferrite Bead
L5551	2460591X01	Coil Square
L5552	2460591X01	Coil Square
L5553	2460591X01	Coil Square
L5554	2462587T16	Coil Chip 120nH
L5600	2484657R01	Ferrite Bead
L5601	2484657R01	Ferrite Bead
L5611	2484657R01	Ferrite Bead
L5631	2462587T23	Coil Chip 470nH
Q5510	4813827A26	RF NPN MRF
Q5520	4813827D13	TSTR 870MHz PWR MACRO-X
Q5611	4813824A17	TSTR PNP 40V 0.2A
Q5612	4880214G02	NPN 40V .2A
Q5621	4813824A17	TSTR PNP 40V 0.2A
R5501	0662057C19	4R7 1/10W 5%
R5502	0662057A21	68 1/16W 5%
R5511	0662057A01	10 1/16W 5%
R5512	0662057A01	10 1/16W 5%
R5513	0662057A57	2k2 1/16W 5%
R5521	0662057A49	1k 1/16W 5%
R5522	0662057A49	1k 1/16W 5%
R5523	0662057A89	47k 1/16W 5%
R5525	0662057C19	4R7 1/10W 5%
R5526	0662057C19	4R7 1/10W 5%
R5527	0662057C19	4R7 1/10W 5%
R5531	0680194M01	10 1W 5%
R5541	0680194M01	10 1W 5%
R5550	0662057A73	10k 1/16W 5%
R5551	0662057A73	10k 1/16W 5%
R5552	0662057A18	51 1/16W 5%
R5553	0683962T51	120 1W 5%

Circuit Ref	Motorola Part No.	Description
R5611	0662057A73	10k 1/16W 5%
R5612	0662057A56	2k 1/16W 5%
R5613	0662057A49	1k 1/16W 5%
R5614	0662057A18	51 1/16W 5%
R5615	0662057A65	4k7 1/16W 5%
R5616	0680194M01	10 1W 5%
R5617	0680194M01	10 1W 5%
R5621	0662057A45	680 OHMS 5%
R5623	0662057C19	4R7 1/10W 5%
R5624	0662057C19	4R7 1/10W 5%
R5641	0680149M02	Thermistor Chip 100K @25C




UHF Synthesizer Schematic Diagram

UHF Main Board - Synthesizer

Circuit Ref	Motorola Part No.	Description
C5700	2113743K15	100nF 16V Y5V
C5701	2113740F51	100pF 5% 50V
C5702	2113741F13	330pF 50V
C5703	2113743K15	100nF 16V
C5704	2113741F49	10nF 50V
C5706	2113741F49	10nF 50V
C5707	2113741F49	10nF 50V
C5709	2113743K15	100nF 16V
C5711	2311049A63	TANT CP 10uF 10% 10V
C5712	2311049J26	TANT CP 10uF 20% 16V
C5713	2113741F25	1nF 50V
C5714	2113741F49	10nF 50V
C5715	2113740F39	33pF 5% 50V
C5716	2113743K15	100nF 16V
C5717	2113743K15	100nF 16V
C5718	2113743K15	100nF 16V
C5719	2311049A19	TANT CP 10uF 10% 25V
C5720	2113741F49	10nF 50V
C5721	2113741F49	10nF 50V
C5722	2311049A07	TANT CP 1uF 10% 16V
C5723	2109720D14	CER LOW DIST 100nF
C5725	2109720D14	CER LOW DIST 100nF
C5726	2113741F49	10nF 50V
C5727	0811051A19	MTLZ POLY 1uF 5%
D5701	4802233J09	DIODE TRIPLE SOT143-RH
E5701	2605915V01	SHLD PCB MOUNT 1
R5700	0662057B47	0 1/16W 5%
R5701	0662057C61	270 1/16W 5%


Circuit Ref	Motorola Part No.	Description
R5702	0662057C61	270 1/16W 5%
R5703	0662057A49	1k 1/16W 5%
R5705	0662057A89	47k 1/16W 5%
R5708	0662057A01	10 1/16W 5%
R5710	0662057B47	0 1/16W (not used)
R5711	0662057A15	39 1/16W 5%
R5712	0662057A59	2k7 1/16W 5%
R5713	0662057A59	2k7 1/16W 5% (12.5kHz)
R5714	0662057B02	150k 1/16W
R5715	0662057A41	470 1/16W 5%
R5716	0662057A47	820 1/16W 5%
R5717	0662057A15	39 1/16W 5%
R5718	0662057B16	560k 1/16W 5%
R5723	0662057A73	10k 1/16W 5%
R5724	0662057B16	560k 1/16W 5%
U5701	5105457W72	CC QFP CONT 5105191W59 FRAC-N
VR5701	4813830A23	DIODE 10V 5% 20mA 350mW
Y5702	4809863M01	REF OSC 16.8 MHZ TEMPUS

<http://www.myradio168.net>



0102725B27
GEPD 5453-1

0102725B27



UHF Voltage Controlled Oscillator Schematic Diagram

UHF Main Board - Voltage Controlled Oscillator



Circuit Ref	Motorola Part No.	Description
C5731	2113741F25	1nF 50V
C5732	2113740F37	27pF 5% 50V
C5733	2113741F49	10nF 50V
C5734	2113740F11	2.2pF 5% 50V
C5741	2113741A45	10nF 50V
C5742	2113740F41	39pF 5% 50V
C5743	2113740F39	33pF 5% 50V
C5745	2113740F41	39pF 5% 50V
C5746	2113740F29	12pF 5% 50V
C5747	2113740F29	12pF 5% 50V
C5748	2113740F45	56pF 5% 50V
C5749	2113741F25	1nF 50V
C5750	2113741F25	1nF 50V
C5751	2113741F13	330pF 50V
C5752	2113740F17	3.9pF 5% 50V
C5753	2113740F25	8.2pF 5% 50V
C5754	2113740F25	8.2pF 5% 50V
C5756	2113740F25	8.2pF 5% 50V
C5759	2113740F41	39pF 5% 50V
C5760	0662057A09	22 1/16W 5%
C5761	2113743K15	100nF 16V Y5V
C5762	2113741F49	10nF 50V
C5763	2113740F21	5.6pF 5% 50V
C5771	2113740F51	100pF 5% 50V
C5772	2113741F13	330pF 50V
C5773	2113740F19	4.7pF 5% 50V
C5774	2113741F49	10nF 50V
C5781	2113740F51	100pF 5% 50V
C5782	2113740F45	56pF 5% 50V

Circuit Ref	Motorola Part No.	Description
C5783	2113740F21	5.6pF 5% 50V
C5784	2113740F35	22pF 5% 50V
C5785	2113741F49	10nF 50V
C5786	2113740F18	4.3pF 5%
C5787	2113741F49	10nF 50V
C5791	2113740F51	100pF 5% 50V
C5792	2113741F25	1nF 50V
C5801	2113743A23	220nF 16V
C5802	2113743E07	22nF 16V
C5803	2311049A63	TANT CP 10uF 10% 10V
D5731	4805649Q13	DIODE VCTR 1SV228 SOT23
D5741	4805649Q13	DIODE VCTR 1SV228 SOT23
D5742	4805649Q13	DIODE VCTR 1SV228 SOT23
D5743	4813825A05	DIODE CHIP SCHOTTKY
D5751	4805218N57	DIODE DUAL SCHOTTKY SOT23
E5731	2605915V01	SHLD PCB MOUNT 1
E5732	2602641Y02	SHIELD VCO
L5731	2462587T38	COIL CHIP 22nH 5%
L5741	2462587T18	COIL CHIP 180nH
L5742	2462587T16	COIL CHIP 120nH
L5743	2402686Y01	COIL HEL MOLDED SMD
L5744	2462587T20	COIL CHIP 270nH
L5754	2462587T38	COIL CHIP 22nH 5%
L5771	2462587T38	COIL CHIP 22nH 5%
L5781	2462587T38	COIL CHIP 22nH 5%
Q5731	4805921T09	XSTR DUAL ROHM FMG8

UHF Main Board - Voltage Controlled Oscillator

Circuit Ref	Motorola Part No.	Description
Q5741	4813823A05	TSTR N-CH RF JFET MMBU310LT1
Q5751	4813827A07	TRANSISTOR NPN
Q5771	4813827A07	TRANSISTOR NPN
Q5781	4813827A07	TRANSISTOR NPN
Q5791	4813827A07	TRANSISTOR NPN
R5732	0662057A97	100k 1/16W
R5733	0662057A89	47k 1/16W 5%
R5741	0662057A25	100 1/16W 5%
R5742	0662057A97	100k 1/16W
R5743	0662057A13	33 1/16W 5%
R5744	0662057A13	33 1/16W 5%
R5751	0662057A45	680 OHMS 5%
R5752	0662057A41	470 1/16W 5%
R5753	0662057C61	270 1/16W 5%
R5754	0662057A53	1k5 1/16W 5%
R5755	0662057A41	470 1/16W 5%
R5756	0662057A29	150 1/16W 5%
R5771	0662057A61	3k3 1/16W 5%
R5772	0662057A61	3k3 1/16W 5%
R5773	0662057A73	10k 1/16W 5%
R5774	0662057A73	10k 1/16W 5%
R5775	0662057A25	100 1/16W 5%
R5776	0662057A29	150 1/16W 5%
R5777	0662057A13	33 1/16W 5%
R5778	0662057A29	150 1/16W 5%
R5779	0662057A01	10 1/16W 5%
R5782	0662057A13	33 1/16W 5%
R5783	0662057A29	150 1/16W
R5784	0662057A73	10k 1/16W
R5785	0662057A73	10k 1/16W
R5786	0662057A25	100 1/16W
R5787	0662057A29	150 1/16W

Circuit Ref	Motorola Part No.	Description
R5788	0662057A01	10 1/16W 5%
R5789	0662057A13	33 1/16W 5%
R5791	0662057A41	470 1/16W
R5792	0662057A18	51 1/16W 5%
R5793	0662057A41	470 1/16W
R5794	0662057A59	2k7 1/16W
R5801	0662057A09	22 1/16W 5%
T5751	2505515V03	XFMR JED MIXER SMD 4:1
U5801	5105469E65	IC VLTC REGLTR LP2951C




UHF Main Board - RX-FE

Circuit Ref	Motorola Part No.	Description
C5300	2113740F42	43pF 5% 50V
C5301	2113740F11	2.2pF 5% 50V
C5302	2113740F09	1.8pF 5% 50V
C5303	2113740F39	33pF 5% 50V
C5304	2113740F42	43pF 5% 50V
C5305	2113740F42	43pF 5% 50V
C5306	2113740F40	36pF 5% 50V
C5307	2113741F37	3.3nF 50V
C5308	2113741F25	1nF 50V
C5309	2113740F51	100pF 5% 50V
C5310	2113741F13	330pF 50V
C5311	2113741F37	3.3nF 50V
C5312	2113741F25	1nF 50V
C5313	2113740F09	1.8pF 5% 50V
C5314	2113740F29	12pF 5% 50V
C5315	2113740F40	36pF 5% 50V
C5316	2113740F40	36pF 5% 50V
C5317	2113740F40	36pF 5% 50V
C5318	2113740F27	10pF 5% 50V
C5319	2113741F25	1nF 50V
C5320	2113741F25	1nF 50V
C5321	2113740F40	36pF 5% 50V
C5323	2113740F40	36pF 5% 50V
C5324	2113740F40	36pF 5% 50V
C5325	2113740F17	3.9pF 5% 50V
C5326	2113740F09	1.8pF 5% 50V
C5327	2113740F09	1.8pF 5% 50V
C5328	2113740F09	1.8pF 5% 50V
C5329	2113740F09	1.8pF 5% 50V

Circuit Ref	Motorola Part No.	Description
C5331	2113741F13	330pF 50V
C5401	2113740F22	6.2pF 5% 50V
C5402	2113740F32	16pF 5% 50V
C5403	2113740F32	16pF 5% 50V
C5404	2113740F49	82pF 5% 50V
D5301	4862824C01	VARACTOR CHIP
D5302	4862824C01	VARACTOR CHIP
D5303	4880154K03	DUAL SCHOTTKY SOT23
D5304	4862824C01	DIODE VARACTOR
D5305	4862824C01	DIODE VARACTOR
D5401	4880174R01	QUAD SOIC 8 PIN
L5302	2462587T23	COIL CHIP 470nH
L5401	2462587T23	COIL CHIP 470nH
L5402	2462587T17	COIL CHIP 150nH
L5403	2462587N46	IND CHIP LO-PRO 27.0 N
L5404	2462587N43	IND CHIP LO-PRO 15.0 N
Q5301	4813827A07	TRANSISTOR NPN
R5301	0662057A97	100k 1/16W
R5302	0662057A37	330 1/16W 5%
R5303	0662057A59	2k7 1/16W 5%
R5304	0662057A63	3k9 1/16W 5%
R5305	0662057A73	10k 1/16W 5%
R5306	0662057C61	270 1/16W 5%
R5307	0662057A21	68 1/16W 5%
R5308	0662057C61	270 1/16W 5%
R5309	0662057A97	100k 1/16W
R5310	0662057A01	10 1/16W 5%
R5314	0662057C61	270 1/16W 5%
R5315	0680194M01	10 1W 5%

Circuit Ref	Motorola Part No.	Description
R5317	0662057A29	150 1/16W 5%
R5318	0662057A29	150 1/16W 5%
R5319	0662057A13	33 1/16W 5%
R5401	0662057A18	51 1/16W 5%
T5401	2505515V03	XFMR JEDI MIXER SMD 4:1
T5402	2505515V04	XMFR MIXER 5:1

<http://www.myradio168.net>



* note 1: values are depending on channel spacing Changed by:

	C5226	C5229	R5216	R5221	R5223	R5225
0102725B29	.047 uF	4.7pF	10K	150K	6.8K	100
0102725B30	0.1uF	.001uF	6.8K	200K	3.9K	3.3K

0102725B29	12.5 kHz channel spacing
0102725B30	20/25 kHz channel spacing
GEPD 5442-2	
GEPD 5443-2	


UHF Main Board - RX-IF

Circuit Ref	Motorola Part No.	Description
C5200	2113740F35	22pF 5% 50V
C5201	2113740F19	4.7pF 5% 50V
C5202	2113740F31	15pF 5% 50V
C5203	2113743A19	100nF 16V X7R
C5204	2113743A19	100nF 16V X7R
C5205	2113740F33	18pF 5% 50V
C5208	2113743A19	100nF 16V
C5211	2113740F31	15pF 5% 50V
C5212	2113740F31	15pF 5% 50V
C5213	2113740F40	36pF 5% 50V
C5214	2113740F17	3.9pF 5% 50V
C5220	2113741F49	10nF 50V
C5221	2311049J25	TANT CP 10uF 10% 16V
C5222	2113743K15	100nF 16V
C5223	2113743E20	100nF 16V
C5224	2113741F29	1.5nF 50V
C5225	2311049J11	TANT CP 4.7uF 10% 16V
C5226	2113743K07 2113743K15	47nF 16V (12.5kHz) 100 nF 16V (20/25kHz)
C5227	2311049J11	TANT CP 4.7uF 10% 16V
C5228	2113743K15	100nF 16V
C5229	2113741F41 2113741F25	4.7nF 50V (12.5kHz) 1nF 50V (20/25kHz)
C5230	2113741F49	10nF 50V
C5231	2311049A07	TANT CP 1uF 10% 16V
C5232	2113740F51	100pF 5% 50V
C5233	2113740F51	100pF 5% 50V
C5234	2113743K15	100nF 16V
C5235	2113740F51	100pF 5% 50V
C5236	2113740F51	100pF 5% 50V

Circuit Ref	Motorola Part No.	Description
C5237	2113743K15	100nF 16V
C5238	2113743K15	100nF 16V Y5V
C5239	2113740F44	51pF 5% 50V
D5201	4880154K03	Dual Schottky SOT23
FL5201	9180098D04 9180098D06	Filter CER 4-EL 455kHz (12.5kHz) Filter CER 3WR (20/25kHz)
FL5202	9180097D04 9180097D06	Filter CER 6-EL 455kHz (12.5kHz) Filter CER 6-EL (20/25kHz)
L5201	2462587N69	CHIP IND 1200 NH
L5203	2483411T74	Inductor Chip Shielded
L5211	2483411T74	Inductor Chip Shielded
Q5201	4813827A07	Transistor NPN
R5201	0662057A73	10k 1/16W 5%
R5202	0662057A85	33k 1/16W 5%
R5203	0662057A69	6k8 1/16W 5%
R5204	0662057A25	100 1/16W 5%
R5205	0662057A56	2k 1/16W 5%
R5207	0662057B47	0 1/16W
R5211	0662057A47	820 1/16W 5%
R5212	0662057A67	5k6 1/16W 5%
R5216	0662057A73 0662057A69	10k 1/16W 5% (12.5kHz) 6k8 1/16W 5% (20/25kHz)
R5221	0662057B02 0662057B05	150k 1/16W (12.5kHz) 200k 1/16W 5% (20/25kHz)
R5222	0662057A93	68k 1/16W 5%
R5223	0662057A69 0662057A63	6k8 1/16W 5% (12.5kHz) 3k9 1/16W 5% (20/25kHz)
R5224	0662057A76	13k 1/16W 5%

Circuit Ref	Motorola Part No.	Description
R5225	0662057A25 0662057A61	100 1/16W 5% (12.5kHz) 3k3 1/16W 5% (20/25kHz)
U5201	5180207R01	IF IC
Y5201	9102651Y01 9102652Y01	XTAL FLTR 45.1MHZ 12.5KHz 80dB XTAL FLTR 45.1MHZ 20/25KHz 80dB
Y5202	9102651Y02 9102652Y02	XTAL FLTR 45.1MHZ 12.5KHz 60dB XTAL FLTR 45.1MHZ 20/25KHz 80dB
Y5211	4802653Y01	XTAL OSC 44.645MHZ


<http://www.myradio168.net>




VHF Main Board Component Side
PCB No. 8485669Z01



VHF Main Board Solder Side
PCB No. 8405669Z01



VHF GM950i, Controller Schematic Diagram
1 of 2



VHF GM950i, Controller_IO Schematic Diagram
2 of 2

VHF GM950i Main Board - Controller

Circuit Ref	Motorola Part No.	Description
C0101	2113743K15	100nF 16V
C0102	2113741F17	470pF 50V
C0103	2311049A42	TANT CP 3.3uF 10% 6V
C0104	2113741F49	10nF 50V
C0105	2113743K15	100nF 16V
C0109	2113741F17	470pF 50V
C0110	2113741F17	470pF 50V
C0111	2113741F17	470pF 50V
C0112	2113741F25	1nF 50V
C0114	2113740A41	33pF 5% 50V
C0115	2113740A37	22pF 5% 50V
C0116	2113740G16	Ceramic Chip 3.6 P
C0117	2113740A41	33pF 5% 50V
C0118	2113741F17	470pF 50V
C0119	2113741F17	470pF 50V
C0121	2113743K05	39nF 16V
C0122	2113741F41	4.7nF 50V
C0125	2113743K15	100nF 16V
C0126	2113743K15	100nF 16V
C0127	2113743K15	100nF 16V
C0131	2113743K15	100nF 16V
C0132	2113743K15	100nF 16V
C0133	2113743K15	100nF 16V
C0134	2113743K15	100nF 16V
C0137	2113741F49	10nF 50V
C0141	2311049J26	TANT CP 10uF 20% 16V
C0142	2113743A19	100nF 16V
C0145	2113741F25	1nF 50V
C0148	2113741F17	470pF 50V

Circuit Ref	Motorola Part No.	Description
C0149	2113740F39	33pF 5% 50V
C0150	2311049A05	TANT CP 470nF 10% 25V
C0151	2113741F17	470pF 50V
C0152	2311049A07	TANT CP 1uF 10% 16V
C0153	2113743K15	100nF 16V
C0154	2113743K15	100nF 16V
C0155	2113740F39	33pF 5% 50V
C0157	2113741F17	470pF 50V
C0161	2113743K15	100nF 16V
C0162	2113743K15	100nF 16V
C0163	2113743K15	100nF 16V
C0164	2113741F41	4.7nF 50V
C0170	2311049A07	TANT CP 1uF 10% 16V
C0171	2311049J23	TANT CP 10uF 10% 6V
C0172	2311049A07	TANT CP 1uF 10% 16V
C0173	2311049A07	TANT CP 1uF 10% 16V
C0174	2113743K15	100nF 16V
C0175	2113741F25	1nF 50V
C0176	2311049A42	TANT CP 3.3 UF 10% 6V
C0181	2113743K15	100nF 16V
C0182	2113743K15	100nF 16V
C0184	2311049A07	TANT CP 1uF 10% 16V
C0185	2113740F51	100pF 5% 50V
C0191	2113743K15	100nF 16V
C0194	2113741F17	470pF 50V
C0196	2113741F17	470pF 50V
C0197	2113741F17	470pF 50V
C0198	2113741F17	470pF 50V
C0199	2113741F17	470pF 50V

VHF GM950i Main Board - Controller

Circuit Ref	Motorola Part No.	Description
C0401	2113743A19	100nF 16V
C0402	2113741F37	3.3nF 50V
C0404	2311049A99	TANT CP 47uF 20% 10V
C0405	2113741F25	1nF 50V
C0406	2113741F25	1nF 50V
C0407	2109720D14	CER LOW DIST 100nF
C0411	2113741F49	10nF 50V
C0412	2113741F17	470pF 50V
C0413	2113741F49	10nF 50V
C0414	2113741F17	470pF 50V
C0419	2113741F25	1nF 50V
C0420	2113741F25	1nF 50V
C0421	2113741F17	470pF 50V
C0422	2113741F17	470pF 50V
C0431	2113741F17	470pF 50V
C0435	2113741F49	10nF 50V
C0436	2113741F17	470pF 50V
C0438	2113741F49	10nF 50V
C0439	2113741F17	470pF 50V
C0441	2113741F49	10nF 50V
C0442	2113741F17	470pF 50V
C0444	2113741F17	470pF 50V
C0445	2311049A05	TANT CP 470nF 10% 25V
C0446	2113741F17	470pF 50V
C0450	2311049A99	TANT CP 47uF 20% 10V
C0451	2113741F17	470pF 50V
C0454	2113741F17	470pF 50V
C0455	2113741F17	470pF 50V
C0461	2113741F49	10nF 50V
C0462	2113741F17	470pF 50V
C0463	2113741F49	10nF 50V
C0464	2113741F17	470pF 50V
C0471	2113741F17	470pF 50V

Circuit Ref	Motorola Part No.	Description
C0472	2113741F17	470pF 50V
D0101	4813833C02	DIODE DUAL SOT MMBD6100
J0101	0902636Y01	Connector Flex Side Entry
J0102	0904424J06	Connector double row 8pin
J0103	0904424J06	Connector double row 8pin
J0400	2804503J01	Accessory Connector 16
L0114	2460578C43	INDUCTOR CHIP 33.0UH
L0170	2462587K26	CHIP IND 33000 NH
L0194	2462587Q40	COIL CHIP 270nH
L0195	2462587Q40	COIL CHIP 270nH
L0401	2484657R01	Ferrite Bead
L0402	2484657R01	Ferrite Bead
Q0114	4880214G02	TSTR NPN 40V .2A
Q0137	4880048M01	TSTR NPN DIG 47k/47k
Q0138	4880048M01	TSTR NPN DIG 47k/47k
Q0161	4880214G02	TSTR NPN 40V .2A
Q0401	4880214G02	TSTR NPN 40V .2A
Q0411	4880214G02	TSTR NPN 40V .2A
Q0412	4880048M01	TSTR NPN DIG 47k/47k
Q0421	4880048M01	TSTR NPN DIG 47k/47k
Q0431	4880048M01	TSTR NPN DIG 47k/47k
Q0432	4880048M01	TSTR NPN DIG 47k/47k
Q0433	4880214G02	TSTR NPN 40V .2A
Q0442	4880052M01	TSTR NPN DRLNGTN
Q0461	4880048M01	TSTR NPN DIG 47k/47k
Q0462	4880214G02	TSTR NPN 40V .2A
Q0471	4880048M01	TSTR NPN DIG 47k/47k
R0101	0662057A73	10k 1/16W 5%
R0102	0662057A65	4k7 1/16W 5%
R0103	0662057A73	10k 1/16W 5%
R0104	0662057A85	33k 1/16W 5%
R0105	0662057A73	10k 1/16W 5%


Circuit Ref	Motorola Part No.	Description
R0106	0662057A57	2k2 1/16W 5%
R0107	0662057A25	100 1/16W 5%
R0108	0662057A89	47k 1/16W 5%
R0109	0662057A89	47k 1/16W 5%
R0110	0662057A73	10k 1/16W 5%
R0111	0662057A85	33k 1/16W 5%
R0112	0662057A93	68k 1/16W 5%
R0113	0662057A73	10k 1/16W 5%
R0114	0662057A65	4k7 1/16W 5%
R0115	0662057B28	1.8M 1/16W 5%
R0116	0662057C61	270 1/16W 5%
R0117	0662057C61	270 1/16W 5%
R0118	0662057A65	4k7 1/16W 5%
R0119	0662057A49	1k 1/16W 5%
R0120	0662057A73	10k 1/16W 5%
R0121	0662057B03	160k 1/16W 5%
R0122	0662057A93	68k 1/16W 5%
R0123	0662057A97	100k 1/16W (not used)
R0124	0662057A69	6k8 1/16W 5%
R0125	0662057B05	200k 1/16W
R0126	0662057B05	200k 1/16W
R0127	0662057B05	200k 1/16W
R0128	0662057A73	10k 1/16W 5%
R0134	0662057A73	10k 1/16W 5%
R0135	0662057A89	47k 1/16W 5%
R0136	0662057A85	33k 1/16W 5%
R0137	0662057A89	47k 1/16W 5%
R0138	0662057A65	4k7 1/16W 5%
R0139	0662057B07	240k 1/16W
R0141	0662057A25	100 1/16W 5%
R0142	0662057A49	1k 1/16W 5%
R0143	0662057A89	47k 1/16W 5%
R0144	0662057A89	47k 1/16W 5%

Circuit Ref	Motorola Part No.	Description
R0145	0662057A84	30k 1/16W 5%
R0147	0662057B04	180k 1/16W 5%
R0148	0662057B14	470k 1/16W 5%
R0149	0662057B47	0 1/16W
R0150	0662057A90	51k 1/16W 5%
R0151	0662057A73	10k 1/16W 5%
R0152	0662057A73	10k 1/16W 5%
R0154	0662057A73	10k 1/16W 5%
R0155	0662057A93	68k 1/16W 5%
R0156	0662057B47	0 1/16W
R0157	0662057A77 0662057A84	15k 1/16W 5% (12.5kHz) 30k 1/16W 5% (20/25kHz)
R0161	0662057A97	100k 1/16W
R0162	0662057A73	10k 1/16W 5%
R0163	0662057A97	100k 1/16W
R0165	0662057A89	47k 1/16W 5%
R0166	0662057A73	10k 1/16W 5%
R0167	0662057A89	47k 1/16W 5%
R0171	0662057R92	47.5k .1W 1%
R0172	0662057R92	47.5k .1W 1%
R0175	0662057B02	150k 1/16W
R0181	0662057A84	30k 1/16W 5%
R0182	0662057A73	10k 1/16W 5%
R0183	0662057A73	10k 1/16W 5%
R0184	0662057A84	30k 1/16W 5%
R0186	0662057A83 0662057A90	27k 1/16W 5% (12.5kHz) 51k 1/16W 5% (20/25kHz)
R0189	0662057A95	82k 1/16W 5%
R0401	0662057A65	4k7 1/16W 5%
R0402	0662057A49	1k 1/16W 5%
R0404	0662057A73	10k 1/16W 5%
R0405	0662057A73	10k 1/16W 5%
R0406	0662057A81	22k 1/16W 5%


VHF GM950i Main Board - Controller

Circuit Ref	Motorola Part No.	Description
R0407	0662057A77	15k 1/16W 5%
R0411	0662057A73	10k 1/16W 5%
R0412	0662057A65	4k7 1/16W 5%
R0413	0662057A89	47k 1/16W 5%
R0414	0662057C61	270 1/16W 5%
R0422	0662057A73	10k 1/16W 5%
R0425	0662057A73	10k 1/16W 5%
R0426	0662057A89	47k 1/16W 5%
R0427	0662057B47	0 1/16W
R0431	0662057A89	47k 1/16W 5%
R0432	0662057A65	4k7 1/16W 5%
R0435	0662057C61	270 1/16W 5%
R0436	0662057A89	47k 1/16W 5%
R0437	0662057A65	4k7 1/16W 5%
R0438	0662057A73	10k 1/16W 5%
R0441	0662057A73	10k 1/16W 5%
R0443	0662057A65	4k7 1/16W 5%
R0444	0662057C61	270 1/16W 5%
R0446	0662057A97	100k 1/16W
R0450	0662057A43	560 1/16W 5%
R0451	0662057A97	100k 1/16W
R0454	0662057A49	1k 1/16W 5%
R0455	0662057B47	0 1/16W
R0461	0662057A89	47k 1/16W 5%
R0462	0662057A65	4k7 1/16W 5%
R0463	0662057C61	270 1/16W 5%
R0464	0662057A73	10k 1/16W 5%
R0472	0662057B47	0 1/16W
R0474	0662057A89	47k 1/16W 5%
R0475	0662057A65	4k7 1/16W 5%
R0476	0662057C61	270 1/16W 5%
U0101	5102898X66	PROC350 PLAT S/W R010000 A3

Circuit Ref	Motorola Part No.	Description
U0102	5113805A30	IC 10F8 DCDR/REMUX 74HC138
U0103	5102227J35	CHIP CAR TEST 27J35
U0104	5105492X36	74AC08 4 AND GATES
U0105	5183222M49	IC QUAD OPAMP_3403_
U0106	5183222M49	IC QUAD OPAMP_3403_
U0107	5184704M60	IC MUX/DEMUX TRIPLE 2-CHNL
U0108	5105462G78	IC FEPR0M 1&K SPEI CMOS
U0401	5109699X01	AUDIO PA TDA1915C
VR0118	4880140L06	DIODE 5.1V 5% 225mW
VR0411	4813830A27	DIODE 14V 5% 225mW
VR0421	4813830A27	DIODE 14V 5% 225mW
VR0422	4880140L06	DIODE 5.1V 5% 225mW
VR0431	4813830A27	DIODE 14V 5% 225mW
VR0435	4813830A27	DIODE 14V 5% 225mW
VR0441	4813830A40	SOC23 AUTO SDN
VR0444	4880140L06	DIODE 5.1V 5% 225mW
VR0445	4813830A27	DIODE 14V 5% 225mW
VR0450	4813830A27	DIODE 14V 5% 225mW
VR0454	4813830A27	DIODE 14V 5% 225mW
VR0464	4813830A27	DIODE 14V 5% 225mW
VR0471	4813830A40	SOC23 AUTO SDN
Y0114	4880113R01	CRYSTAL 7.9488



VHF GM950E, Controller Schematic Diagram
1 of 2



VHF GM950E, Controller_IO Schematic Diagram
2 of 2

VHF GM950E Main Board - Controller

Circuit Ref	Motorola Part No.	Description
C0101	2113743K15	100nF 16V
C0102	2113741F17	470pF 50V
C0103	2311049A42	TANT CP 3.3uF 10% 6V
C0104	2113741F49	10nF 50V
C0105	2113743K15	100nF 16V
C0109	2113741F17	470pF 50V
C0110	2113741F17	470pF 50V
C0111	2113741F17	470pF 50V
C0112	2113741F25	1nF 50V
C0114	2113740A41	33pF 5% 50V
C0115	2113740A37	22pF 5% 50V
C0116	2113740G16	CERAMIC CHIP 3.6 P
C0117	2113740A41	33pF 5% 50V
C0118	2113741F17	470pF 50V
C0119	2113741F17	470pF 50V
C0121	2113743K05	39nF 16V
C0122	2113741F41	47nF 50V
C0125	2113743K15	100nF 16V
C0126	2113743K15	100nF 16V
C0127	2113743K15	100nF 16V
C0131	2113743K15	100nF 16V (not used)
C0132	2113743K15	100nF 16V
C0133	2113743K15	100nF 16V (not used)
C0134	2113743K15	100nF 16V
C0137	2113741F49	10nF 50V
C0141	2311049J26	TANT CP 10uF 20% 16V
C0145	2113741F25	1nF 50V
C0148	2113741F17	470pF 50V
C0149	2113740F39	33pF 5% 50V

Circuit Ref	Motorola Part No.	Description
C0150	2311049A05	TANT CP 470nF 10% 25V
C0151	2113741F17	470pF 50V
C0152	2311049A07	TANT CP 1uF 10% 16V
C0153	2113743K15	100nF 16V
C0154	2113743K15	100nF 16V
C0155	2113740F39	33pF 5% 50V
C0157	2113741F17	470pF 50V
C0161	2113743K15	100nF 16V
C0162	2113743K15	100nF 16V
C0163	2113743K15	100nF 16V
C0164	2113741F41	4.7nF 50V
C0170	2311049A07	TANT CP 1uF 10% 16V
C0171	2311049J23	TANT CP 10uF 10% 6V
C0172	2311049A07	TANT CP 1uF 10% 16V
C0173	2311049A07	TANT CP 1uF 10% 16V
C0174	2113743K15	100nF 16V
C0175	2113741F25	1nF 50V
C0176	2311049A42	TANT CP 3.3 uF 10% 6V
C0181	2113743K15	100nF 16V
C0182	2113743K15	100nF 16V
C0194	2113741F17	470pF 50V
C0196	2113741F17	470pF 50V
C0197	2113741F17	470pF 50V
C0198	2113741F17	470pF 50V
C0199	2113741F17	470pF 50V
C0401	2113743A19	100nF 16V
C0402	2113741F37	3.3nF 50V
C0404	2311049A99	TANT CP 47uF 20% 10V
C0405	2113741F25	1nF 50V

VHF GM950E Main Board - Controller


Circuit Ref	Motorola Part No.	Description
C0406	2113741F25	1nF 50V
C0407	2109720D14	CER LOW DIST 100nF
C0419	2113741F25	1nF 50V
C0420	2113741F25	1nF 50V
C0421	2113741F17	470pF 50V
C0422	2113741F17	470pF 50V
C0431	2113741F17	470pF 50V
C0444	2113741F17	470pF 50V
C0454	2113741F17	470pF 50V
C0455	2113741F17	470pF 50V
D0101	4813833C02	DUAL SOT MMBD6100
J0101	0902636Y01	Connector Flex Side Entry
J0102	0904424J06	Connector double row 8pin
J0103	0904424J06	Connector double row 8pin
J0400	2804503J01	Accessory Connector 16
L0114	2460578C43	Inductor CHIP 33.0UH 1
L0170	2462587K26	CHIP IND 33000 NH
L0194	2462587Q40	COIL CHIP 270nH
L0195	2462587Q40	COIL CHIP 270nH
L0401	2484657R01	Ferrite Bead
L0402	2484657R01	Ferrite Bead
Q0114	4880214G02	NPN 40V
Q0137	4880048M01	NPN DIG 47k/47k
Q0138	4880048M01	NPN DIG 47k/47k
Q0161	4880214G02	NPN 40V
Q0401	4880214G02	NPN 40V
Q0421	4880048M01	NPN DIG 47k/47k
Q0431	4880048M01	NPN DIG 47k/47k
R0101	0662057A73	10k 1/16W 5%
R0102	0662057A65	4k7 1/16W 5%
R0103	0662057A73	10k 1/16W 5%
R0104	0662057A85	33k 1/16W 5%
R0105	0662057A73	10k 1/16W 5%

Circuit Ref	Motorola Part No.	Description
R0106	0662057A57	2k2 1/16W 5%
R0107	0662057A25	100 1/16W 5%
R0108	0662057A89	47k 1/16W 5%
R0109	0662057A89	47k 1/16W 5%
R0110	0662057A73	10k 1/16W 5%
R0111	0662057A85	33k 1/16W 5%
R0112	0662057A93	68k 1/16W 5%
R0113	0662057A73	10k 1/16W 5%
R0114	0662057A65	4k7 1/16W 5%
R0115	0662057B28	1.8M 1/16W 5%
R0116	0662057C61	270 1/16W 5%
R0117	0662057C61	270 1/16W 5%
R0118	0662057A65	4k7 1/16W 5%
R0119	0662057A49	1k 1/16W 5%
R0120	0662057A73	10k 1/16W 5%
R0121	0662057B03	160k 1/16W 5%
R0122	0662057A93	68k 1/16W 5%
R0123	0662057A97	100k 1/16W (not used)
R0124	0662057A69	6k8 1/16W 5%
R0125	0662057B05	200k 1/16W
R0126	0662057B05	200k 1/16W
R0127	0662057B05	200k 1/16W
R0128	0662057A73	10k 1/16W 5%
R0130	0662057B47	0 1/16W
R0134	0662057A73	10k 1/16W 5%
R0137	0662057A89	47k 1/16W 5%
R0138	0662057A65	4k7 1/16W 5%
R0139	0662057B07	240k 1/16W
R0141	0662057A25	100 1/16W 5%
R0142	0662057A49	1k 1/16W 5%
R0145	0662057A84	30k 1/16W 5%
R0146	0662057B47	0 1/16W
R0147	0662057B04	180k 1/16W 5%

Circuit Ref	Motorola Part No.	Description
R0148	0662057B14	470k 1/16W 5%
R0149	0662057B47	0 1/16W
R0150	0662057A90	51k 1/16W 5%
R0153	0662057A65	4k7 1/16W 5%
R0154	0662057A73	10k 1/16W 5%
R0155	0662057A93	68k 1/16W 5%
R0156	0662057B47	0 1/16W
R0157	0662057A77 0662057A84	15k 1/16W 5% (12.5kHz) 30k 1/16W 5% (20/25kHz)
R0161	0662057A97	100k 1/16W
R0162	0662057A73	10k 1/16W 5%
R0163	0662057A97	100k 1/16W
R0165	0662057A89	47k 1/16W 5%
R0166	0662057A73	10k 1/16W 5%
R0167	0662057A89	47k 1/16W 5%
R0171	0662057R92	47.5k .1W 1%
R0172	0662057R92	47.5k .1W 1%
R0175	0662057B02	150k 1/16W
R0181	0662057A84	30k 1/16W 5%
R0182	0662057A73	10k 1/16W 5%
R0183	0662057A73	10k 1/16W 5% (not used)
R0184	0662057A84	30k 1/16W 5%
R0401	0662057A65	4k7 1/16W 5%
R0402	0662057A49	1k 1/16W 5%
R0404	0662057A73	10k 1/16W 5%
R0405	0662057A73	10k 1/16W 5%
R0406	0662057A81	22k 1/16W 5%
R0407	0662057A77	15k 1/16W 5%
R0413	0662057A89	47k 1/16W 5%
R0415	0662057B47	0 1/16W 5%
R0421	0662057B47	0 1/16W (not used)
R0422	0662057A73	10k 1/16W 5%
R0425	0662057A73	10k 1/16W 5%

Circuit Ref	Motorola Part No.	Description
R0426	0662057A89	47k 1/16W 5%
R0427	0662057B47	0 1/16W
R0431	0662057A89	47k 1/16W 5%
R0432	0662057A65	4k7 1/16W 5%
R0436	0662057A89	47k 1/16W 5%
R0439	0662057B47	0 1/16W
R0444	0662057C61	270 1/16W 5%
R0454	0662057A49	1k 1/16W 5%
R0461	0662057A89	47k 1/16W 5%
R0465	0662057B47	0 1/16W
R0471	0662057B47	0 1/16W
R0472	0662057B47	0 1/16W
R0474	0662057A89	47k 1/16W 5%
U0101	5102898X67	PROC350 PLAT S/W R010000 A2
U0102	5113805A30	IC 10F8 DCDR/REMUX 74HC138
U0103	5102227J35	CHIP CAR TEST 27J35
U0104	5105492X36	74AC08 4 AND GATES
U0105	5183222M49	IC QUAD OPAMP __3403__
U0401	5109699X01	AUDIO PA TDA1915C
VR0118	4880140L06	DIODE 5.1V 5% 225mW
VR0421	4813830A27	DIODE 14V 5% 225mW
VR0422	4880140L06	DIODE 5.1V 5% 225mW
VR0431	4813830A27	DIODE 14V 5% 225mW
VR0444	4880140L06	DIODE 5.1V 5% 225mW
VR0454	4813830A27	DIODE 14V 5% 225mW
Y0114	4880113R01	CRYSTAL 7.9488

<http://www.myradio168.net>




0102725B36 Supply Voltage
GEPD5449-1

VHF Main Board - Supply Voltage

Circuit Ref	Motorola Part No.	Description
C0601	2113741F17	470pF 50V
C0602	2109720D14	100nF LOW DIST
C0603	2380090M24	LYT 10uF 50V 20%
C0604	2311049A97	33uF 20% 16V
C0605	2109720D14	100nF LOW DIST
C0611	2311049A99	TANT CP 47uF 20% 10V
C0612	2113743K15	100nF 16V
C0613	2113741F17	470pF 50V
C0621	2113741F17	470pF 50V
C0622	2311049A99	TANT CP 47uF 20% 10V
C0631	2109720D14	100nF LOW DIST
C0632	2311049A97	33uF 20% 16V
C0633	2113743E07	22nF 16V
C0634	2311049A99	47uF 20% 10V
C0635	2109720D14	100nF LOW DIST
C0641	2113743K15	100nF 16V
D0611	4813833C02	DUAL SOT MMBD6100
D0621	4813833C02	DUAL SOT MMBD6100
D0631	4813833C02	DUAL SOT MMBD6100
Q0601	4880214G02	NPN 40V
Q0611	4805123M27	PNP SOT89
Q0612	4880214G02	NPN 40V
R0601	0662057A73	10k 1/16W 5%
R0602	0660076E70	FILM 7500
R0603	0660076E51	FILM 1200
R0604	0662057A49	1k 1/16W 5%
R0605	0662057A69	6k8 1/16W 5%
R0606	0662057B47	0 1/16W
R0611	0662057A51	1k2 1/16W 5%

Circuit Ref	Motorola Part No.	Description
R0612	0662057C87	3300 5 1/8
R0613	0662057C87	3300 5 1/8
R0614	0662057A73	10k 1/16W 5%
R0615	0662057A73	10k 1/16W 5%
R0616	0662057A73	10k 1/16W 5%
R0617	0662057C87	3300 5 1/8
R0621	0662057A57	2k2 1/16W 5%
R0631	0662057A01	10 1/16W 5%
R0632	0662057A01	10 1/16W 5%
R0641	0662057A84	30k 1/16W 5%
R0642	0662057A73	10k 1/16W 5%
U0601	5105625U25	9.3V REG 2941
U0631	5105469E65	VLTG REGLTR LP2951C
VR0621	4880140L06	5.1V 5% 225mW
VR0641	4880140L06	5.1V 5% 225mW

<http://www.myradio168.net>



VHF Power Control Schematic Diagram


0102725B13 VHF PWR CNTL
GEPD5436-1

VHF Main Board - Power Control

Circuit Ref	Motorola Part No.	Description
C0701	2113740F51	100pF 5% 50V
C0702	2113740F51	100pF 5% 50V
C0703	2113743K15	100nF 16V Y5V
C0711	2113741A59	CL2 X7R REEL
C0712	2113740F42	43pF 5% 50V
C0713	2113740F51	100pF 5% 50V
C0714	2113743A19	100nF 16V
C0716	2113741A59	CL2 X7R REEL
C0721	2113740F51	100pF 5% 50V
C0722	2113740F51	100pF 5% 50V
C0723	2113740F51	100pF 5% 50V
C0731	2113743K15	100nF 16V Y5V
C0732	2113740F51	100pF 5% 50V
C0733	2113743A23	220nF 16V
C0741	2113740F51	100pF 5% 50V
D0721	4813833C02	DIODE DUAL
D0731	4813833C02	DIODE DUAL
D0732	4813833C02	DIODE DUAL
Q0711	4880214G02	NPN 40V .2A
Q0731	4880048M01	NPN DIG 47k/47k
Q0741	4880048M01	NPN DIG 47k/47k
Q0742	4805128M27	PNP SOT89
R0701	0662057A97	100k 1/16W
R0702	0662057A97	100k 1/16W
R0703	0662057A61	3k3 1/16W 5%
R0704	0662057A93	68k 1/16W 5%
R0711	0662057A81	22k 1/16W 5%
R0712	0662057A37	330 1/16W 5%
R0713	0662057A61	3k3 1/16W 5%

Circuit Ref	Motorola Part No.	Description
R0714	0662057A81	22k 1/16W 5%
R0715	0662057A81	22k 1/16W 5%
R0716	0662057B16	560k 1/16W 5%
R0717	0662057A85	33k 1/16W 5%
R0718	0662057A93	68k 1/16W 5%
R0719	0662057A93	68k 1/16W 5%
R0721	0662057A69	6k8 1/16W 5%
R0722	0662057A81	22k 1/16W 5%
R0723	0662057A89	47k 1/16W 5%
R0724	0662057A73	10k 1/16W 5%
R0725	0662057A73	10K 1/16W 5%
R0731	0662057A73	10k 1/16W 5%
R0732	0662057A65	4k7 1/16W 5%
R0733	0662057A89	47k 1/16W 5%
R0734	0662057R92	47.5k .1W 1%
R0735	0662057C01	0 1/10W 5%
R0741	0662057A49	1k 1/16W 5%
R0742	0662057A49	1k 1/16W 5%
U0701	5183222M49	IC QUAD OPAMP __3403__
U0731	5113811G02	IC D/A CONV & BIT 4 CHAN

<http://www.myradio168.net>



VHF Power Amplifier 5-25W Schematic Diagram

VHF Main Board - Power Amplifier 5-25W


Circuit Ref	Motorola Part No.	Description
C3501	2113740F25	8.2pF 5% 50V
C3502	2113741F17	470pF 50V
C3511	2113740F29	12pF 5% 50V
C3512	2113740F37	27pF 5% 50V
C3513	2113741F17	470pF 50V
C3514	2113741F25	1nF 50V
C3520	2111078B32	39pF 5%
C3521	2111078B42	100pF 5%
C3523	2111078B36	56pF 5%
C3524	2111078B49	180pF 5% (not used)
C3525	2111078B52	240pF 5%
C3526	2111078B49	180pF 5% (not used)
C3527	2111078B59	470pF 5%
C3530	2111078B48	160pF 5%
C3531	2111078B49	180pF (not used)
C3532	2111078B34	47pF
C3533	2111078B36	56pF 5%
C3534	2111078B16	13pF 5%
C3535	2111078B38	68pF 5% (not used)
C3551	2111078B27	30pF 5%
C3552	2111078B34	47pF 5%
C3553	2111078B29	33pF 5%
C3554	2111078B21	20pF 5%
C3555	2111078B07	5.6pF 0.25%
C3601	2380090M24	10uF 50V 20%
C3602	2113741A57	33nF 50V
C3603	2113741F49	10nF 50V
C3604	2113741F17	470pF 50V
C3605	2311049A45	TANT CP 10uF 10V 35%

Circuit Ref	Motorola Part No.	Description
C3611	2113741F25	1nF 50V
C3614	2113741F49	10nF 50V
C3621	2113741A57	33nF 50V
C3622	2113741A57	33nF 50V
C3623	2113740A67	330pF 5% 50V
C3631	2113741A57	33nF 50V
C3632	2111078B59	470pF 5%
C3633	2113743A23	220nF 16V
C3634	2311049A08	TANT CP 1 uF 10V 35%
C3641	2113741F49	10nF 50V
C3642	2113741F17	470pF 50V
C3643	2113741F49	10nF 50V
C3644	2113741F49	10nF 50V
C3645	2113741F49	10nF 50V
C3646	2113741F29	1.5nF 50V
C3651	2113740A67	330pF 5% 50V
C3652	2113740F33	18pF 5% 50V
C3653	2111078B59	470pF 5%
C3654	2113740F47	68pF 5% 50V
C3655	2113741F25	1nF 50V
C3657	2113740F32	16pF 5% 50V
C3658	2113741F25	1nF 50V
D3551	4802482J02	DIODE PIN MA/COM
D3601	4813832B35	DIODE TRANSORB
D3651	4802482J02	DIODE PIN MA/COM
D3657	4813825A05	DIODE CHIP SCHOTTKY
J3501	0905902V01	PWR Connector 2 PIN (not used)
J3601	0905901V02	BNC Connector (not used)

VHF Main Board - Power Amplifier 5-25W

Circuit Ref	Motorola Part No.	Description
L3501	2462587T12	COIL CHIP 56nH
L3511	2460591C23	Square Coil 16nH 3T
L3521	2460591C23	Square Coil 16nH 3T
L3522	2484657R01	Ferrite Bead
L3523	2460591A01	Square Coil 4.22nH 3T (not used)
L3531	2460591X01	Coil Square
L3532	2460591L29	Coil Air Wound Inductor 16.03
L3533	2460591M77	Coil Air Wound Inductor 38.13
L3551	2460591W04	Coil Square
L3552	2460591W04	Coil Square
L3601	2484657R01	Ferrite Bead
L3621	2484657R01	Ferrite Bead (not used)
L3622	2484657R01	Inductor Bead Chip
L3623	2460591A01	Coil Square 4.22nH (not used)
L3631	2484657R01	Ferrite Bead
L3641	2462587T17	COIL CHIP 150nH
L3651	2460591W04	Coil Square
L3652	2462587T30	COIL CHIP 1uH
Q3511	4813827A26	TSTR RF NPN
Q3521	4813827A36	UHF N-CH FET 3W_5003
Q3531	4880225C22	TSTR RF PWR (not used)
Q3641	4880214C02	TSTR NPN
Q3642	4813824A17	TSTR PNP SOT
Q3643	4880048M01	TSTR NPN DIG 47k/47k
R3501	0662057A01	10 1/16W 5%
R3502	0662057A25	100 1/16W 5%
R3503	0662057A01	10 1/16W 5%
R3511	0683962T51	120 1W
R3513	0662057A01	10 1/16W 5%
R3525	0680194M07	18 1W 5%


Circuit Ref	Motorola Part No.	Description
R3526	0680194M07	18 1W 5%
R3527	0680194M07	18 1W 5%
R3551	0662057A73	10k 1/16W 5%
R3611	0680149M02	Thermistor 100K @25C
R3614	0662057A89	47k 1/16W 5%
R3615	0662057A49	1k 1/16W 5%
R3616	0680194M01	10 1W 5%
R3617	0680194M01	10 1W 5% (not used)
R3631	0680194M01	10 1W 5%
R3641	0662057A49	1k 1/16W 5%
R3642	0662057A56	2k 1/16W 5%
R3643	0662057A49	1k 1/16W 5% (not used)
R3644	0662057A37	330 1/16W 5%
R3645	0662057C19	4R7 1/10W 5%
R3646	0662057C19	4R7 1/10W 5%
R3647	0662057A56	2k 1/16W 5%
R3648	0662057A25	100 1/16W 5%
R3649	0662057A49	1k 1/16W 5%
R3651	0662057A73	10k 1/16W 5%
R3657	0683962T51	120 1W 5%
R3658	0662057A97	100k 1/16W
SH3501	2602642Y01	Heatspreader



* note 1: values are depending on channel spacing Changed by:

	R3713	C3707
0102725B15	820	.01uF
0102725B16	2K	.022uF

0102725B15	GEPD5438-3	12.5 kHz channel spacing
0102725B16	GEPD5439-3	20/25 kHz channel spacing




VHF Main Board - Synthesizer

Circuit Ref	Motorola Part No.	Description
C3701	2113740F51	100pF 5% 50V
C3702	2113741F13	330pF 50V
C3703	2113743E20	0.1uF 10V
C3704	2113741F49	10nF 50V
C3705	2113741F49	10nF 50V
C3706	2113743E20	0.1uF 10V
C3707	2113741F49 2113743E07	10nF 50V (12.5kHz) 22nF (20/25kHz)
C3708	2113740F59	220pF 5% 50V (12.5kHz) (not used)
C3709	2113743E20	0.1uF 10%
C3710	2113740F43	47pF 5% 50V (20/25kHz) (not used)
C3711	2311049A63	TANT CP 10uF 10% 10V
C3712	2311049J26	TANT CP 10uF 20% 16V
C3713	2113741F25	1nF 50V
C3715	2113740F39	33pF 5% 50V
C3716	2113743E20	0.1uF 10%
C3717	2113743E20	0.1uF 10%
C3718	2113743E20	0.1uF 10%
C3719	2311049A19	TANT CP 10uF 10% 25V
C3720	2113741F49	10nF 50V
C3722	2311049A07	1uF 10% 16V
C3723	2109720D14	100nF
C3725	2109720D14	100nF
C3726	2113741F49	10nF 50V
C3727	0811051A19	1uF 5%
D3701	4802233J09	Triple SOT143-RH (12.5kHz)
D3702	4805649Q04	Diode Varactor (20/25kHz) (not used)

Circuit Ref	Motorola Part No.	Description
E3702	2605915V01	SHLD PCB MOUNT
R3701	0662057C61	270 1/16W 5%
R3702	0662057C61	270 1/16W 5%
R3703	0662057A49	1k 1/16W 5%
R3705	0662057A89	47k 1/16W 5%
R3708	0662057B47	0 1/16W
R3709	0662057A01	10 1/16W 5%
R3711	0662057A25	100 1/16W 5%
R3712	0662057A59	2k7 1/16W 5%
R3713	0662057A47 0662057A56	820 1/16W 5% (12.5kHz) 2k 1/16W 5% (25kHz)
R3714	0662057B02	150k 1/16W
R3715	0662057A41	470 1/16W
R3716	0662057A49	1k 1/16W
R3717	0662057A25	100 1/16W 5%
R3718	0662057A25	100 1/16W 5%
R3723	0662057A73	10k 1/16W 5%
R3724	0662057B16	560k 1/16W 5%
U3701	5105457W72	FRAC-N QFP
VR3701	4813830A23	10V 5% 20mA 350mW
Y3701	4802081B71	Crystal Quartz 16.8 MHZ TEMPUS (20/25kHz) (not used)
Y3702	4809863M01	Crystal Quartz 16.8 MHZ TEMPUS (12.5kHz)

<http://www.myradio168.net>



VHF Voltage Controlled Oscillator Schematic Diagram

VHF Main Board - Voltage Controlled Oscillator


Circuit Ref	Motorola Part No.	Description
C3731	2113741F25	1nF 50V
C3733	2113740F25	8.2pF 5% 50V
C3734	2113740F07	1.5pF 5% 50V
C3735	2113741F17	470pF 50V
C3736	2113740F39	33pF 5% 50V
C3737	2113740F45	56pF 5% 50V
C3738	2113740F39	33pF 5% 50V
C3739	2113740F27	10pF 5% 50V
C3740	2113740F29	12pF 5% 50V
C3743	2113743K15	100nF 16V
C3744	2113741F25	1nF 50V
C3745	2113741F17	470pF 50V
C3751	2109720D01	LOW DIST 10nF
C3752	2113740F42	43pF 5% 50V
C3754	2113740F37	27pF 5% 50V
C3755	2113740F27	10pF 5% 50V
C3756	2113740F27	10pF 5% 50V
C3757	2113741F17	470pF 50V
C3758	2113741F25	1nF 50V
C3761	2113740F23	6.8pF 5% 50V
C3762	2113740F21	5.6pF 5% 50V
C3763	2113741F49	10nF 50V
C3764	2113740F21	5.6pF 5% 50V
C3765	2113740F29	12pF 5% 50V
C3766	2113740F51	100pF 5% 50V
C3767	2113741F49	10nF 50V X7R
C3771	2113743K15	100nF 16V
C3772	2113740F51	100pF 50V
C3773	2113740F29	12pF 5% 50V

Circuit Ref	Motorola Part No.	Description
C3774	2113740F27	10pF 5% 50V
C3775	2113741F17	470pF 50V
C3777	2113741F17	470pF 50V
C3780	2113741F25	1nF 50V
C3781	2113741F49	10nF 50V
C3782	2113740F51	100pF 50V
C3783	2113740F41	39pF 5%
C3784	2113740F27	10pF 5%
C3785	2113740F27	10pF 5% 50V
C3791	2113741F49	10nF 50V
C3792	2113741F49	10nF 50V
C3793	2113741F49	10nF 50V
C3801	2113743A23	220nF 16V
C3802	2113743E07	22nF 16V
C3803	2311049A63	TANT CP 10uF 10% 10V
D3731	4805649Q13	VCTR 1SV228 SOT23
D3732	4805649Q13	VCTR 1SV228 SOT23
D3733	4805649Q13	VCTR 1SV228 SOT23
D3739	4813825A05	SCHOTTKY
D3751	4805649Q13	VCTR 1SV228 SOT23
D3752	4805649Q13	VCTR 1SV228 SOT23
D3754	4813825A05	SCHOTTKY
E3731	2602641Y02	SHIELD VCO
E3732	2605915V01	SHLD PCB MOUNT
L3731	2462587T13	COIL CHIP 68nH
L3732	2462587T30	COIL CHIP 1uH
L3733	2462587T30	COIL CHIP 1uH
L3734	0105950T45	Helical Molded FIN .175
L3741	2462587T30	COIL CHIP 1uH

VHF Main Board - Voltage Controlled Oscillator

Circuit Ref	Motorola Part No.	Description
L3742	2462587T30	COIL CHIP 1uH
L3750	2462587T30	COIL CHIP 1uH
L3751	2462587T30	COIL CHIP 1uH
L3752	0105950T44	Helical Molded FIN .175
L3754	2462587T30	COIL CHIP 1uH
L3761	2462587T13	COIL CHIP 68nH
L3768	2462587T16	COIL CHIP 120nH
L3773	2462587T12	COIL CHIP 56nH
L3781	2462587T38	COIL CHIP 22nH
L3783	2462587T16	COIL CHIP 120nH
Q3742	4805921T09	XSTR DUAL ROHM FMG8
Q3751	4813823A05	N-CH RF JFET MMBU310LT1
Q3752	4880214G02	NPN 40V .2A
Q3760	4813827A07	NPN SML SIG MMBR9
Q3770	4813827A07	NPN SML SIG MMBR9
Q3780	4813827A07	NPN SML SIG MMBR9
Q3790	4813827A07	NPN SML SIG MMBR9
R3731	0662057A21	68 1/16W 5%
R3739	0662057A83	27k 1/16W 5%
R3740	0662057A09	22 1/16W 5%
R3741	0662057A21	68 1/16W 5%
R3742	0662057A15	39 1/16W 5%
R3743	0662057A65	4k7 1/16W 5%
R3751	0662057A83	27k 1/16W 5%
R3752	0662057A57	2k2 1/16W 5%
R3753	0662057A25	100 1/16W 5%
R3754	0662057A15	39 1/16W 5%
R3761	0662057A53	1k5 1/16W 5%
R3762	0662057A41	470 1/16W 5%
R3763	0662057A29	150 1/16W 5%
R3765	0662057C61	270 1/16W 5%
R3766	0662057A09	22 1/16W 5%


Circuit Ref	Motorola Part No.	Description
R3767	0662057C61	270 1/16W 5%
R3768	0662057A59	2k7 1/16W 5%
R3769	0662057A49	1k 1/16W 5%
R3771	0662057A29	150 1/16W 5%
R3772	0662057A25	100 1/16W 5%
R3774	0662057A01	10 1/16W 5%
R3775	0662057C61	270 1/16W 5%
R3776	0662057A15	39 1/16W 5%
R3777	0662057A29	150 1/16W 5%
R3778	0662057A59	2k7 1/16W 5%
R3779	0662057A53	1k5 1/16W 5%
R3781	0662057A25	100 1/16W 5%
R3782	0662057A25	100 1/16W 5%
R3785	0662057A01	10 1/16W 5%
R3786	0662057A29	150 1/16W 5%
R3791	0662057C61	270 1/16W 5%
R3792	0662057A59	2k7 1/16W 5%
R3793	0662057A49	1k 1/16W 5%
R3794	0662057A18	51 1/16W 5%
R3795	0662057A41	470 1/16W 5%
R3801	0662057A09	22 1/16W 5%
U3741	4813823A05	XSTR N-CH RF JFET
U3801	5105469E65	IC VLTG REGLTR



0102725B18

GEPD5441-1 DUMMY

0102725B18




VHF Main Board - RX-FE

Circuit Ref	Motorola Part No.	Description
C3300	2113741F37	3.3nF 50V
C3301	2113740F19	4.7pF 5% 50V
C3302	2113740F24	7.5pF 5% 50V
C3303	2113741F37	3.3nF 50V
C3304	2113740F45	56pF 5% 50V
C3305	2113740F51	100pF 5% 50V
C3306	2113740F39	33pF 5% 50V
C3307	2113741F37	3.3nF 50V
C3308	2113741F25	1nF 50V
C3309	2113741F13	330pF 50V
C3310	2113741F13	330pF 50V
C3311	2113741F37	3.3nF 50V
C3312	2113741F25	1nF 50V
C3313	2113740F45	56pF 5% 50V
C3314	2113740F24	7.5pF 5% 50V
C3315	2113740F45	56pF 5% 50V
C3316	2113740F51	100pF 5% 50V
C3317	2113740F42	43pF 5% 50V
C3319	2113741F25	1nF 50V
C3320	2113741F25	1nF 50V
C3321	2113740F51	100pF
C3322	2113741F49	10nF 50V
C3331	2113740F29	12pF 5% 50V
C3332	2113740F37	27pF 5% 50V
C3333	2113740F42	43pF 5% 50V
C3334	2113740F49	82pF 5% 50V
D3300	4813833C02	DUAL SOT MMBD6100
D3301	4805649Q13	VCTR 1SV228 SOT23
D3303	4880154K03	Dual Schottky SOT23

Circuit Ref	Motorola Part No.	Description
D3304	4805649Q13	VCTR 1SV228 SOT23
D3331	4880174R01	QUAD SCHOT 8 PIN
L3302	2462587T23	COIL CHIP 470nH
L3331	2462587T23	COIL CHIP 470nH
L3332	2462587T17	COIL CHIP 150nH
L3333	2462587T33	COIL CHIP 22nH 5%
L3334	2462587T38	COIL CHIP 22nH 5%
Q3301	4813827A07	NPN SML SIG MMBR9
Q3302	4813824A17	XSTR PNP 40V 0.2A
R3300	0662057A53	1k5 1/16W 5%
R3301	0662057A97	100k 1/16W
R3302	0662057A37	330 1/16W 5%
R3303	0662057A49	1k 1/16W 5%
R3304	0662057A53	1k5 1/16W 5%
R3306	0662057C61	270 1/16W 5%
R3307	0662057A21	68 1/16W 5%
R3308	0662057C61	270 1/16W 5%
R3309	0662057A97	100k 1/16W
R3311	0662057A63	3k9 1/16W 5%
R3312	0662057A53	1k5 1/16W 5%
R3313	0662057A61	3k3 1/16W 5%
R3314	0662057A07	18 1/10W 5%
R3315	0662057A01	10 1/10W 5%
R3316	0662057A29	150 1/16W 5%
R3317	0662057A29	150 1/16W 5%
R3318	0662057A13	33 1/16W 5%
R3321	0662057C61	270 1/16W 5%
R3331	0662057A18	51 1/16W 5%

Circuit Ref	Motorola Part No.	Description
T3301	2505515V03	XFMR JEDI MIXER SMD 4:1
T3302	2505515V03	XFMR JEDI MIXER SMD 4:1

<http://www.myradio168.net>




VHF Main Board - RX-IF

Circuit Ref	Motorola Part No.	Description
C5200	2113740F35	22pF 5% 50V
C5201	2113740F19	4.7pF 5% 50V
C5202	2113740F31	15pF 5% 50V
C5203	2113743A19	100nF 16V X7R
C5204	2113743A19	100nF 16V X7R
C5205	2113740F33	18pF 5% 50V
C5208	2113743A19	100nF 16V
C5211	2113740F31	15pF 5% 50V
C5212	2113740F31	15pF 5% 50V
C5213	2113740F40	36pF 5% 50V
C5214	2113740F17	3.9pF 5% 50V
C5220	2113741F49	10nF 50V
C5221	2311049J25	TANT CP 10uF 10% 16V
C5222	2113743K15	100nF 16V
C5223	2113743E20	100nF 16V
C5224	2113741F29	1.5nF 50V
C5225	2311049J11	TANT CP 4.7uF 10% 16V
C5226	2113743K07 2113743K15	47nF 16V (12.5kHz) 100 nF 16V (20/25kHz)
C5227	2311049J11	TANT CP 4.7uF 10% 16V
C5228	2113743K15	100nF 16V
C5229	2113741F41 2113741F25	4.7nF 50V (12.5kHz) 1nF 50V (20/25kHz)
C5230	2113741F49	10nF 50V
C5231	2311049A07	TANT CP 1uF 10% 16V
C5232	2113740F51	100pF 5% 50V
C5233	2113740F51	100pF 5% 50V
C5234	2113743K15	100nF 16V
C5235	2113740F51	100pF 5% 50V
C5236	2113740F51	100pF 5% 50V


Circuit Ref	Motorola Part No.	Description
C5237	2113743K15	100nF 16V
C5238	2113743K15	100nF 16V Y5V
C5239	2113740F44	51pF 5% 50V
D5201	4880154K03	Dual Schottky SOT23
FL5201	9180098D04 9180098D06	Filter CER 4-EL 455kHz (12.5kHz) Filter CER 3WR (20/25kHz)
FL5202	9180097D04 9180097D06	Filter CER 6-EL 455kHz (12.5kHz) Filter CER 6-EL (20/25kHz)
L5201	2462587N69	CHIP IND 1200 NH
L5203	2483411T74	Inductor Chip Shielded
L5211	2483411T74	Inductor Chip Shielded
Q5201	4813827A07	Transistor NPN
R5201	0662057A73	10k 1/16W 5%
R5202	0662057A85	33k 1/16W 5%
R5203	0662057A69	6k8 1/16W 5%
R5204	0662057A25	100 1/16W 5%
R5205	0662057A56	2k 1/16W 5%
R5207	0662057B47	0 1/16W
R5211	0662057A47	820 1/16W 5%
R5212	0662057A67	5k6 1/16W 5%
R5216	0662057A73 0662057A69	10k 1/16W 5% (12.5kHz) 6k8 1/16W 5% (20/25kHz)
R5221	0662057B02 0662057B05	150k 1/16W (12.5kHz) 200k 1/16W 5% (20/25kHz)
R5222	0662057A93	68k 1/16W 5%
R5223	0662057A69 0662057A63	6k8 1/16W 5% (12.5kHz) 3k9 1/16W 5% (20/25kHz)
R5224	0662057A76	13k 1/16W 5%

Circuit Ref	Motorola Part No.	Description
R5225	0662057A25 0662057A61	100 1/16W 5% (12.5kHz) 3k3 1/16W 5% (20/25kHz)
U5201	5180207R01	IF IC
Y5201	9102651Y01 9102652Y01	XTAL FLTR 45.1MHZ 12.5KHz 80dB XTAL FLTR 45.1MHZ 20/25KHz 80dB
Y5202	9102651Y02 9102652Y02	XTAL FLTR 45.1MHZ 12.5KHz 60dB XTAL FLTR 45.1MHZ 20/25KHz 80dB
Y5211	4802653Y01	XTAL OSC 44.645MHZ

<http://www.myradio168.net>




Control Head 'K'
Component Side



Control Head 'K'
Solder Side

Control Head K
PCB No. 8480573Z01




Main Board - Control Head K


Circuit Ref	Motorola Part No.	Description
C0801	2113741F17	470pF 50V X7R
C0802	2113741F17	470pF 50V X7R
C0841	2113743K15	100nF 16V Y5V
C0842	2311049J23	TANT 10uF 10% 6V
D0825	4813833C02	DUAL SOT MMBD6100
D0841	4805729G73	LED SMT YEL HP
D0842	4805729G73	LED SMT YEL HP
D0843	4805729G74	LED SMT RED HP
D0844- D0848	4805729G75	LED SMT GREEN HP
D0861- D0868	4805729G75	LED SMT GREEN HP
J0801	0902636Y01	CONN Flex Side Entry
J0802	2809926G01	CONN 1.25MM CTR SUR
J0803	2805924V01	CONNECTOR MIC
Q0825	4880048M01	NPN DIG 47k/47k
Q0841	4880048M01	NPN DIG 47k/47k
Q0842- Q0848	4813824A10	NPN 40V .2A B=50-150
Q0861	4813824A10	NPN 40V .2A B=50-150
Q0862	4813824A10	NPN 40V .2A B=50-150
R0801	0660076A35	RES CHIP 270 5 1/8
R0802	0662057A49	RES CHP 1k 1/16W 5%
R0811- R0818	0662057A65	RES CHP 4k7 1/16W 5%
R0825	0662057A65	RES CHP 4k7 1/16W 5%
R0826	0662057A65	RES CHP 4k7 1/16W 5%
R0841	0662057A73	RES CHP 10k 1/16W 5%
R0842	0662057A89	RES CHP 47k 1/16W 5%
R0843	0662057A89	RES CHP 47k 1/16W 5%
R0844	0660076A35	RES CHIP 270 5 1/8

Circuit Ref	Motorola Part No.	Description
R0845	0662057A89	RES CHP 47k 1/16W 5%
R0846	0662057A41	RES CHP 470 1/16W 5%
R0847	0662057A89	RES CHP 47k 1/16W 5%
R0848	0660076A35	RES CHIP 270 5 1/8
R0849	0662057A89	RES CHP 47k 1/16W 5%
R0850	0660076A35	RES CHIP 270 5 1/8
R0851	0662057A89	RES CHP 47k 1/16W 5%
R0852	0660076A35	RES CHIP 270 5 1/8
R0853	0662057A89	RES CHP 47k 1/16W 5%
R0854	0660076A35	RES CHIP 270 5 1/8
R0855	0662057A89	RES CHP 47k 1/16W 5%
R0856	0660076A35	RES CHIP 270 5 1/8
R0861	0662057A65	RES CHP 4k7 1/16W 5%
R0862	0662057A65	RES CHP 4k7 1/16W 5%
R0863	0662057A35	RES CHP 270 1/16W 5%
R0864	0662057A35	RES CHP 270 1/16W 5%
U0841	5113806A35	MC14094, REG, 8-Stage, SHIFT/STOREU
VR0801	4813830A14	5.1V 5% 225mW
VR0802	4813830A14	5.1V 5% 225mW
VR0803- VR0805	4813830A27	14V 5% 225MW
VR0806	4813830A14	5.1V 5% 225mW
VR0807	4813830A14	5.1V 5% 225mW

<http://www.myradio168.net>




Control Head 'P'
Component Side



Control Head 'P'
Solder Side

Control Head P
PCB No. 8480479Z01



Control Head P Schematic Diagram

Main Board - Control Head P

Circuit Ref	Motorola Part No.	Description
C0901	2113741F17	470pF 50V
C0902	2113741F17	470pF 50V
C0934	2113743K15	100nF 16V
C0935	2113741F49	10nF 50V
C0941	2113743K15	100nF 16V
C0942	2311049J23	TANT CP 10uF 10% 6V
D0925	4813833C02	DIODE DUAL SOT MMBD6100
D0941	4805729G73	LED SMT YEL
D0942	4805729G73	LED SMT YEL
D0943	4805729G74	LED SMT RED
D0944	4805729G75	LED SMT GREEN
D0951- D0970	4805729G75	LED SMT GREEN
H0931	7202631Y01	CNTL K DISPLAY
J0901	0902636Y01	CONN FLEX Side Entry
J0902	2809926G01	CONN 1.25MM CTR SUR
J0903	2805924V01	CONNECTOR MIC
Q0925	4880048M01	NPN DIG 47k/47k
Q0931	4805128M16	PNP SOT MMBT3906
Q0941	4880048M01	NPN DIG 47k/47k
Q0942	4813824A10	NPN 40V .2A B=50-150
Q0943	4813824A10	NPN 40V .2A B=50-150
Q0944	4813824A10	NPN 40V .2A B=50-150
Q0951	4813824A10	NPN 40V .2A B=50-150
Q0952	4813822A20	
R0901	0660076A35	270 5 1/8
R0902	0662057A49	1k 1/16W 5%
R0911- R0922	0662057A65	4k7 1/16W 5%

Circuit Ref	Motorola Part No.	Description
R0925	0662057A65	4k7 1/16W 5%
R0926	0662057A65	4k7 1/16W 5%
R0931	0662057A65	4k7 1/16W 5%
R0932	0662057A73	10k 1/16W 5%
R0933	0662057A97	100k 1/16W
R0941	0662057A73	10k 1/16W 5%
R0942	0662057A89	47k 1/16W 5%
R0943	0662057A89	47k 1/16W 5%
R0944	0660076A35	270 5 1/8
R0945	0662057A89	47k 1/16W 5%
R0946	0662057A41	470 1/16W 5%
R0947	0662057A89	47k 1/16W 5%
R0948	0660076A35	270 5 1/8
R0952	0662057A80	20k 1/16W 5%
R0953	0662057A73	10k 1/16W 5%
R0954	0680194M01	10 1W 5%
U0932	5105625U61	LCD DRIVR 33 SEG- MENT STATIC
U0941	5113806A35	MC14094, REG, 8- STAGE,SHIFT/STOREU
VR0901	4813830A14	5.1V 5% 225mW
VR0902	4813830A14	5.1V 5% 225mW
VR0903	4813830A27	14V 5% 225MW MMB
VR0904	4813830A27	14V 5% 225MW MMB
VR0905	4813830A27	14V 5% 225MW MMB
VR0906	4813830A14	5.1V 5% 225mW
VR0907	4813830A14	5.1V 5% 225mW
VR0908	4813830A14	5.1V 5% 225mW

<http://www.myradio168.net>

Chapter 6

216-246MHz Specific Information

Table of Contents

Chapter

- 6.1 Model Chart and Technical Specifications**
- 6.2 Radio Tuning Procedure**
- 6.3 Theory of Operation**
- 6.4 PCB/Schematic Diagrams and Parts Lists**

<http://www.myradio168.net>

<http://www.myradio168.net>

Chapter 6.1

Model Chart and Technical Specifications

Table of Contents

Paragraph		Page
1.0	Overview	1
2.0	Model Chart	1
3.0	Technical Specifications	2
3.1	General.....	2
3.2	Transmitter.....	2
3.3	Receiver.....	3

<http://www.myradio168.net>

<http://www.myradio168.net>

1.0 Overview

This chapter lists the 216-246 MHz models and technical specifications available for the GM950i mobile radio.

2.0 Model Chart

Description		Model			
GM950i 220-240MHz 20/25 kHz 10-25W D		AZM08MHF6AA2AN			
GM950i 245-246MHz 20/25 kHz 10W D		AZM08MFF6AA3AN			
GM950i 245-246MHz 12.5 kHz 10W D		AZM08MFF4AA3AN			
GM950i 216-223MHz 20/25 kHz 5W D		AZM08MFF6AA2AN			

GM950i 216-246 MHz

X = Indicates one of each required

					Item	Description
X	X	X	X		PMBN4039_	Packaging Kit
					GCN6103_	Control Head Model A2 Display
X	X	X	X		GCN6105_	Control Head Model A3 Display
X	X	X	X		GLN7324_	Low Profile Trunnion Kit
X	X	X	X		GMN6146_	Enhanced Compact Microphone
		X			PMUE1609A	GM950i 245-246MHz 20/25kHz Tanapa
X					PMUE1610A	GM950i 220-240MHz 20/25kHz Tanapa
			X		PMUE1611A	GM950i 245-246MHz 12.5kHz Tanapa
				X	PMUE1612A	GM950i 216-223MHz 20/25kHz Tanapa
X	X	X	X		GKN6270_	Power Cable
X	X	X	X		6804111J35	GM950E/GM950i User Guide

3.0 Technical Specification

3.1 General

SPECIFICATION ITEM	TYPICAL VALUE
Frequency Range	216-246 MHz
Channel Spacing	12.5 or 20/25 kHz
Frequency Stability	±3ppm
Power Supply	10.8 to 15.6V dc, negative earth
Dimensions	44x168x160 mm (HxWxD)
Weight	1030g
Operational Temperature	- 25°C to + 55°C
Storage Temperature	- 40°C to + 85°C
Antenna Connection	50Ω BNC
Environmental - Mechanical - Electrical	Vibration IEC 68/2/27 and Shock IEC 28/2/6 European Dust & Water protection IP54 ETS300-086 RF Specifications ETS300-113 Cyclic Keying Requirements ETS300-279 EMC Requirements ETS300-219 Signalling

3.2 Transmitter

SPECIFICATION ITEM	TYPICAL VALUE
Channel Spacing	12.5 or 20/25 kHz
Output Power	5-25W
Modulation Limiting	<±2.5kHz (12.5kHz); <±4kHz (20kHz); <±5kHz (25kHz)
FM hum & noise (CCITT)	>40dB (12.5kHz); >45dB (25kHz) CCITT
Conducted/Radiated Emission	<0.25uW (0.1...1000MHz); <1uW (1...4GHz)
Adjacent Channel Power	<-60dB (12.5kHz); <-70dB (25kHz)
Audio Response (300 - 3000 Hz)	Flat or pre-emphasised
Audio Distortion	<5% @ 1kHz, 60% deviation
Transmit turn on time	<25msec

3.3 Receiver

SPECIFICATION ITEM	TYPICAL VALUE
Channel Spacing	12.5 or 20/25 kHz
Sensitivity @ 12.5 kHz	< 0.35uV (12dB SINAD)
Sensitivity @ 25 kHz	< 0.35uV (12dB SINAD)
Intermodulation	>65dB ETS; >70dB with Base Option
Adjacent Channel Selectivity	>60dB (12.5kHz); >70dB (20/25kHz) ETS
Spurious Rejection	>70dB ETS
Audio Distortion @ Rated Audio	<5%
Hum and Noise (CCITT)	>40dB (12.5kHz); >45dB (20/25kHz) CCITT
Audio Response (300 - 3000 Hz)	Flat or De-Emphasised
Co-channel Rejection	<12dB (12.5kHz) ; <8dB (20/25kHz) ETS
Conducted /Radiated Emission	<2nW (0.1..1000MHz); <20nW (1..4GHz)
Receive after transmit time	<25msec
Audio Output Power	4W (internal speaker); <13W external

<http://www.myradio168.net>

Chapter 6.2

Radio Tuning Procedure

Table of Contents

Paragraph		Page
1.0	216-246 MHz Tuning Procedure	1
1.1	General	1
1.2	PA Bias Voltage	3
1.3	Battery Threshold	3
1.4	Transmitter Power	4
1.5	Reference Oscillator	4
1.6	Front-End Filter	5
1.7	Rated Volume	6
1.8	Squelch	6
1.9	Transmit Deviation Limit	7
1.10	Transmit Modulation Balance (Compensation)	7

<http://www.myradio168.net>

1.0 216-246MHz Tuning Procedure

1.1 General

The recommended hardware platform is a 386 or 486 DX 33 PC (personal computer) with 8 MBytes RAM, MS-DOS™ 5.0, Windows™3.1, and RSS (Radio Service Software). These are required to align the radio. Refer to your RSS Installation Manual for installation and setup procedures for the required software; the user manual is accessed (and can be printed if required) via the RSS.

To perform the alignment procedures, the radio must be connected to the PC, RIB (Radio Interface Box), and Universal Test Set as shown in figure 6.2-1.




Figure 6.2-1 Radio Alignment Test Setup.

All tuning procedures are performed from the Service menu.

Before going into the Service menu, the radio must first be read using the File / Read Radio menu (if the radio has just been programmed with data loaded from disk or from a newly created codeplug, then it must still be read so that the RSS will have the radio's actual tuning values).

All Service windows read and program the radio codeplug directly; you do NOT have to use the RSS Read Radio / Write Radio functions to program new tuning values.

CAUTION:



DO NOT switch radios in the middle of any Service procedure. Always use the Program or Cancel key to close the tuning window before disconnecting the radio. Improper exits from the Service window may leave the radio in an improperly configured state and result in seriously degraded radio or system performance.

The Service windows introduce the concept of the “Softpot”, an analog SOFTWARE controlled POTentiometer used for adjusting all transceiver alignment controls. A softpot can be selected by clicking with the mouse at the value or the slider or by hitting the TAB key until the value or the slider is highlighted.

Each Service window provides the capability to increase or decrease the ‘softpot’ value with the mouse, the arrow keys or by entering a value with the keyboard. The window displays the minimum, maximum, and step value of the softpot. In addition transmitter tuning windows indicate the transmitter frequency and whether the radio is keyed.

Adjusting the softpot value sends information to the radio to increase (or decrease) a DC voltage in the corresponding circuit. For example, increasing the value in the Reference Oscillator tune window instructs the radio microprocessor to increase the voltage across a varactor in the reference oscillator to increase the frequency. Clicking the Program button stores all the softpot values of the current window permanently in the radio.

In ALL cases, the softpot value is just a relative number corresponding to a D/A (Digital-to-Analog) generated voltage in the radio. All standard measurement procedures and test equipment are similar to previous radios.

Refer to the RSS on-line help for information on the tuning software.

Perform the following procedures in the sequence indicated.

Note: All tuning procedures must be performed at a supply voltage of 13.2V unless otherwise stated. The Modulation Analyser to measure the deviation should be set to frequency modulation with de-emphasis switched off and all high pass filters switched off.

1.2 PA Bias Voltage

Adjustment of the PA Bias is critical for proper radio operation. Improper adjustment will result in poor operation and may damage the PA FET device. For this reason, the PA bias must be set before the transmitter is keyed the first time.

Note: For certain radio models there are two bias voltage settings. For these radios both ' Bias 1 Voltage ' and ' Bias 2 Voltage ' need to be adjusted when aligning the PA Bias. For models that only have one bias voltage setting, the ' Bias 2 Voltage ' will be shown in grey on the service menu.

1. From the Service menu, select Tx Alignments.
2. Select Bias Voltage to open the bias voltage tuning window. If the control voltage is out of range, an error message will be displayed. In this case the radio hardware has a problem and tuning must be stopped immediately.
3. Click the Toggle Bias button to set the quiescent current temporarily to 0 mA. The status bar will indicate that the bias is switched off.
4. Measure the DC current of the radio. Note the measured value and add the specified quiescent current shown in table 6.2-1. The result is the tuning target.
5. Click the Toggle Bias button to switch on the quiescent current again.
6. Adjust the current per the target calculated in step 4.
7. Click the Program button to store the softpot value.

Table 6.2-1 Quiescent Current Alignment.

RF Band	Target
216-246MHz	150mA±15%

1.3 Battery Threshold

The radio uses 2 battery threshold levels Tx High and Tx Low to determine the battery condition.

The Program buttons must only be activated when the power supply is set to the indicated voltage. If the RSS detects that the voltage is not within the expected range for the threshold in question then a message will be displayed to warn that the radio may not be set up correctly for the alignment operation.

CAUTION: Inadvertant Use Of The Program Buttons May Result In Radio Failure.

1. From the Service menu, select Tx Alignments.
2. Select Battery Thresholds to open the battery thresholds tuning window.
3. Set the supply voltage to the value indicated for Tx High.
4. Click the Tx High Program button to store the softpot value for Tx High.
5. Set the supply voltage to the value indicated for Tx Low.
6. Click the Tx Low Program button to store the softpot value for Tx Low.
7. Close the window by clicking Cancel.

1.4 Transmitter Power

The radio has two power level settings, a high power level setting, and a low power level setting.

IMPORTANT: To set the transmitter power for customer applications use the Per Radio window under the Edit menu and set the “Power 1” and “Power 2” powers to the desired values. Only if the transmitter components have been changed or the transmitter does not transmit with the power set in the Per Radio window, should the following procedure be performed.

The advanced power setting technology employed in the radio makes use of two reference power level settings along with parameters describing the circuit behaviour. To determine these parameters the RSS requires the power values measured for two different settings.

1. From the Service menu, select Tx Alignments.
2. Select RF Power to open the RF power tuning window. The window will indicate the transmit test frequencies to be used.
3. Select the Point 1 value of the first frequency.
4. Click the Toggle PTT button to key the radio. The status bar will indicate that the radio is transmitting.
5. Measure the transmitter power on your power meter.
6. Enter the measured value in the box Point 1.
7. Select the Point 2 value of the first frequency.
8. Measure the transmitter power on your power meter.
9. Enter the measured value in the box Point 2.
10. Click the Toggle PTT button to dekey the radio.
11. Repeat steps 3 - 10 for all test frequencies shown in the window.
12. Click the Program button to store the softpot values.

1.5 Reference Oscillator

Adjustment of the reference oscillator is critical for proper radio operation. Improper adjustment will not only result in poor operation, but also a misaligned radio that will interfere with other users operating on adjacent channels. For this reason, the reference oscillator should be checked every time the radio is serviced. The frequency counter used for this procedure must have a stability of 0.1ppm (or better).

1. From the Service menu, select Tx Alignments.
2. Select Reference Oscillator to open the reference oscillator tuning window. The tuning window will indicate the target transmit frequency.
3. Click the Toggle PTT button to key the radio. The status bar will indicate that the radio is transmitting.
4. Measure the transmit frequency on your frequency counter.
5. Adjust the reference oscillator softpot in the tuning window to achieve a transmit frequency within the limits shown in table 6.2-2.
6. Click the Toggle PTT button again to dekey the radio and then click the Program button to store the softpot value.

Table 6.2-2 Reference Oscillator Alignment.

RF-Band	Target
All bands	±150 Hz

1.6 Front-End Filter

Alignment of the front-end pre-selector is normally not required on these radios. Only if the radio has poor receiver sensitivity or the pre-selector parts have been replaced the following procedure should be performed. The softpot value sets the control voltage of the pre-selector. Its value needs to be set at 7 frequencies across the frequency range. If the radio supports 20 or 25 kHz channel spacing selection, use the parameters for 25 kHz channel spacing.

1. Set the test box (GTF180) meter selection switch to the "Audio PA" position and connect a SINAD meter to the "METER" port.
2. From the Service menu, select Rx Alignments.
3. Select Front End Filter to open the pre-selector tuning window. The window will indicate the receive test frequencies to be used.
4. Select the first test frequency shown, and set the corresponding value to the start value shown in table 6.2-4.
5. Set the RF test generator to the receive test frequency, and set the RF level to 10 μ V modulated with a 1kHz tone at the normal test deviation shown in table 6.2-3.
6. Measure the RSSI voltage at accessory connector pin 15 with a dc voltmeter capable of 1mV resolution and at least 1Mohm input impedance.
7. Change the softpot value by the stepsize shown in table 6.2-4 and note the RSSI voltage. The target softpot value is achieved when the measured RSSI voltage change between step 6 and step 7 is lower than the tuning target for the first time. The tuning target, shown in table 6.2-4, is expressed as the percentage of the measured RSSI voltage and must be recalculated for every tuning step. If the measured RSSI voltage decreases before the target value has been achieved, approximation should be stopped and the current softpot value should be used as target value. Set test box (GTF180) audio switch to the "SPKR" position. The 1 kHz tone must be audible at the target value to make sure the radio is receiving.
8. Repeat steps 4- 7 for all test frequencies shown in the window.
9. Click the Program button to store the softpot values.

Table 6.2-3 Normal Test Deviation.

Channel Spacing	Deviation
12.5 kHz	1.5 kHz
20 kHz	2.4 kHz
25 kHz	3 kHz

Table 6.2-4 Start Value for Front-End Pre-selector Tuning.

RF-Band	Target	Stepsize	Start Value
216-246MHz	0.29%	+4	Minimum

1.7 Rated Volume

The rated volume softpot sets the maximum volume at normal test modulation.

1. Set test box (GTF180) meter selection switch to the "AUDIO PA" position and the speaker load switch to the "MAXAR" position. Connect an AC voltmeter to the test box meter port.
2. From the Service menu, select Rx Alignments.
3. Select Rated Volume to open the rated volume tuning window. The screen will indicate the receive test frequency to be used.
4. Set the RF test generator to the receive test frequency, and set the RF level to 1mVolt modulated with a 1kHz tone at the normal test deviation shown in table 6.2-3. Set test box (GTF180) audio switch to the "SPKR" position. The 1kHz tone must be audible to make sure the radio is receiving.
5. Adjust the value of the softpot to obtain rated audio volume (as close to 3.87 V_{rms})
Note: The voltage at the meter port of the test box GTF180 is only half the voltage at the speaker.
6. Click the Program to store the softpot value.

1.8 Squelch

The squelch softpots set the signal to noise ratio at which the squelch opens. The squelch value needs to be set at 7 frequencies across the frequency range. If the radio supports 20 or 25 kHz channel spacing selection, the radio stores separate tuning data for 20 kHz and 25 kHz channel spacing. Therefore, both sets of tuning data should be tuned independently.

1. Set the test box (GTF180) meter selection switch to the "Audio PA" position and connect a SINAD meter to the "METER" port.
2. From the Service menu, select Rx Alignments.
3. Select 'Squelch' to open the squelch tuning window. This window is used to set the values for 12.5kHz radios and the 25kHz data for 20/25kHz radios. The window will indicate the receive test frequencies to be used.
4. Select the first test frequency shown, and set the corresponding value to 0.
5. Set the RF test generator to the test frequency and modulate the signal generator at the normal test deviation shown in table 6.2-3, with 1kHz tone. Adjust the generator for a 8-10 dB SINAD level (weighted with psophometric filter).
6. Adjust the softpot value until the squelch just closes.
7. Monitor for squelch chatter; if chatter is present, repeat step 6.
8. When no chatter is detected, select the next softpot and repeat steps 4 - 7 for all test frequencies shown in the window.
9. Click the Program button to store the softpot values.
10. If the radio supports 20 or 25kHz channel spacing selection, repeat steps 2-9 for 20kHz channel spacing using the 'Squelch (20kHz)' window.

1.9 Transmit Deviation Limit

The transmit deviation limit softpot sets the maximum deviation of the carrier. The deviation limit needs to be set at 7 frequencies across the frequency range. Unlike other radios, the deviation limit for 216-246MHz is set using low frequency (PL) rather than the usual 1 kHz tone. No audio signal must be injected, the radio generates a 82.5 Hz tone while the deviation limit alignment window is open. This tone is used to set the maximum deviation. If the radio supports 20 or 25 kHz channel spacing selection, the radio stores separate tuning data for 20 kHz and 25 kHz channel spacing. Therefore, both sets of tuning data should be tuned independently

1. From the Service menu, select Tx Alignments.
2. Select 'Deviation Limit' to open the deviation limit tuning window. This window is used to set the values for 12.5 kHz radios and the 25 kHz data for 20/25 kHz radios. The window will indicate the transmit test frequencies to be used.
3. Select the first test frequency shown in the window.
4. Click the Toggle PTT button to key the radio. The status bar will indicate that the radio is transmitting.
5. Adjust the transmitter deviation to the value shown in table 6.2-5.
6. Click the Toggle PTT button to dekey the radio.
7. Repeat steps 3-6 for the remaining test frequencies.
8. Click the Program button to store the softpot values.
9. If the radio supports 20 or 25 kHz channel spacing selection repeat steps 1- 8 for 20 kHz channel spacing using the 'Deviation Limit (20 kHz)' window.

Table 6.2-5 Transmitter Deviation Limit Alignment Target.

Channel Spacing	Deviation
12.5 kHz	375 kHz
20 kHz	600 kHz
25 kHz	750 kHz

1.10 Transmit Modulation Balance (Compensation)

Compensation alignment balances the modulation sensitivity of the VCO and reference modulation (synthesizer low frequency port) lines. Compensation algorithm is critical to the operation of signalling schemes that have very low frequency components (e.g. PL) and could result in distorted waveforms if improperly adjusted. The compensation value needs to be set at 7 frequencies across the frequency range and for every channel spacing supported by the radio.

1. From the Service menu, select Tx Alignments.
2. Select Modulation Balance to open the deviation balance tuning window. This window is used to set the values for 12.5 kHz radios and the 25 kHz data for 20/25 kHz radios. The window will indicate the transmit test frequencies to be used.
3. Set the Test Box (GTF180) meter selector switch to the „GEN“ position, and inject a 2 kHz (two kilohertz) tone at 800 mVrms (eight-hundred millivolts) into the "Audio In" port.
4. Connect an AC meter to the meter port to ensure the proper input signal level.
5. Select the first test frequency shown in the window.

6. Click the Toggle PTT button to key the radio. The status bar will indicate that the radio is transmitting.
7. Measure the transmitter deviation.
8. Adjust the transmitter deviation to the value shown in table 6.2-6.
9. Click the Toggle PTT button to dekey the radio.
10. Repeat steps 5 - 9 for the remaining test frequencies.
11. Click the Program button to store the softpot values.
12. If the radio supports 20 or 25 kHz channel spacing selection repeat steps 1- 11 for 20 kHz channel spacing using the 'Modulation Balance (20kHz)' window.

Table 6.2-6 Transmitter Deviation.

Channel Spacing	Deviation
12.5 kHz	2.2-2.3 kHz
20 kHz	3.4-3.6 kHz
25 kHz	4.3-4.6 kHz

Chapter 6.3

Theory of Operation

Table of Contents

Paragraph	Page
1.0 Overview	1
2.0 Controller	2
2.1 General	2
2.2 Voltage Regulators	2
2.3 Electronic On/Off	3
2.4 Mechanical On/Off	3
2.5 Ignition	3
2.6 Hook	4
2.7 Microprocessor Clock Synthesizer	4
2.8 Serial Peripheral Interface (SPI)	4
2.9 SBEP Serial Interface	5
2.10 General Purpose Input/Output	5
2.11 Normal Microprocessor Operation	5
2.12 Control Head Model A2 or A3	6
Controller Board Audio and Signalling Circuits	
3.0 General	7
3.1 Audio Filter IC (AFIC)	7
3.2 Audio Ground	7
4.0 Transmit Audio Circuits	7
4.1 Mic Input Path	7
4.2 External Mic Path	8
4.3 PTT Sensing and TX Audio Processing	8
4.4 Option Board only (GM950i only)	9

Paragraph	Page
5.0 Transmit Signalling Circuits	10
5.1 Sub-audible Data (PL/DPL)	10
5.2 High Speed Data and DTMF	11
6.0 Receive Audio Circuits	12
6.1 Squelch Detect	12
6.2 Audio Processing and Digital Volume Control.....	13
6.3 Audio Amplification Speaker (+) Speaker (-)	13
6.4 Handset Audio	14
6.5 Filtered Audio	14
6.6 Discriminator Audio (Unfiltered).....	14
6.7 Option Board Audio	14
7.0 Receive Signalling Circuits	15
7.1 Sub-audible Data Decoder (PL/DPL)	15
7.2 High Speed Data Decoder.....	15
7.3 Alert Tone Circuits	16
216-246MHz Specific Circuit Description	
8.0 Receiver Front-End	17
8.1 Front-End Band-Pass Filter & Pre-Amplifier.....	17
8.2 Mixer and Intermediate Frequency (IF) Section	17
8.3 IF IC (U5201).....	18
9.0 Transmitter Power Amplifier (PA) 5-25W	18
9.1 Power Controlled Stage.....	18
9.2 PA Stages.....	19
9.3 Directional Coupler	19
9.4 Antenna Switch.....	19
9.5 Harmonic Filter	20
9.6 Power Control.....	20
10.0 Frequency Synthesis	22
10.1 Reference Oscillator	22
10.2 Fractional-N Synthesizer (U3701)	22
10.3 Voltage Controlled Oscillator (VCO).....	22
10.4 Synthesizer Operation	23

1.0 Overview

This section provides a detailed theory of operation for the radio and its components.

The main radio is designed to accept one additional option board. This may provide functions such as secure voice/or a signalling decoder.

The control head is mounted directly on the front of the radio. The control head contains a speaker, LED indicators, a microphone connector, buttons and dependant of radio type, a display. These provide the user with interface control over the various features of the radio.

In addition to the power cable and antenna cable, an accessory cable can be attached to a connector on the rear of the radio. The accessory cable provides the necessary connections for items such as external speaker, foot operated PTT, ignition sensing, etc.

<http://www.myradio168.net>

2.0 Controller

2.1 General

The radio controller consists of 4 main subsections:

- Digital Control
- Audio Processing
- Power Control
- Voltage Regulation

The digital control section of the radio board is based upon a closed architecture controller configuration.

The digital section consists of a microprocessor, support memory, support logic, signal MUX ICs, the On/Off circuit, and general purpose Input/Output circuitry.

The closed architecture controller uses the Motorola 68HC11E9 (U0101) for a GM950E radio and the 68HC11E20 for a GM950i radio. In this configuration RAM and ROM are contained within the microprocessor itself. The only external memory device in the closed architecture controller is an EEPROM (2KByte for GM950i radio).

Note: From this point on the 68HC11E9 or E20 microprocessor will be referred to as E9/20 μ P or μ P. References to a Control Head will be to radio model A3 (Display radio).

2.2 Voltage Regulators

Voltage regulation for the controller is provided by 3 separate devices; U0631 (LP2951CM) +5V, U0601 (LM2941T) +9.3V, and UNSW 5V (a combination of R0621 and VR0621). An additional regulator is located in the RF section.

Voltage regulation providing 5V for the digital circuitry is done by U0631. Input and output capacitors (C0631/0632 and C0633-0635) are used to reduce high frequency noise and provide proper operation during battery transients. This regulator provides a reset output (pin 5) that goes to 0 volts if the regulator output goes out of regulation. This is used to reset the controller to prevent improper operation. Diode D0631 prevents discharge of C0632 by negative spikes on the 9V3 voltage

Regulator U0601 is used to generate the 9.3 volts required by some audio circuits, the RF circuitry and power control circuitry. Input and output capacitors (C0601-0603 and C0604/0605) are used to reduce high frequency noise. R0602/R0603 sets the output voltage of the regulator. If the voltage at pin 1 is greater than 1.3 volts the regulator output decreases and if the voltage is less than 1.3 volts the regulator output increases. This regulator output is electronically disabled by a 0 volt signal on pin 2. Q0601 and associated circuitry (R0601/0604/0605 and C0606) are used to disable the regulator when the radio is turned off.

UNSW 5V is only used in a few areas which draw low current and requires 5 V while the radio is off.

UNSW 5V CL is used to buffer the internal RAM. C0622 allows the battery voltage to be disconnected for a couple of seconds without losing RAM parameters. Diode D0621 prevents radio circuitry from discharging this capacitor.

The voltage 9V3 SUPP is only used in the VHF radio to supply the drain current for the RF MOS FET in the PA.

The voltage SW B+ is monitored by the μ P through the voltage divider R0641/R0642. Diode VR0641 limits the divided voltage to 5.1V to protect the μ P.

Diode D5601 (UHF) / D3601 (VHF) located on the PA section acts as protection against transients and wrong polarity of the supply voltage.

2.3 Electronic On/Off

The radio has circuitry which allows radio software and/or external triggers to turn the radio on or off without direct user action. For example, automatic turn on when ignition is sensed and off when ignition is off.

Q0611 is used to provide SW B+ to the various radio circuits. Q0611 acts as an electronic on/off switch controlled by Q0612. The switch is on when the collector of Q0612 is low. When the radio is off Q0612 is cutoff and the voltage at Q0611-base is at A+. This effectively prevents current flow through Q0611 from emitter to collector. When the radio is turned on the voltage at the base of Q0612 is high (about 0.6V) and Q0612 switches on (saturation) and pulls down the voltage at Q0611-base. With Transistor Q0611 now enabled current flows through the device. This path has a very low impedance (less than 1 ohm) from emitter to collector. This effectively provides the same voltage level at SWB+ as at A+.

The electronic on/off circuitry can be enabled by the microprocessor (through AFIC port GCB1, line B+ CONTROL), the mechanical On/Off button on the control head (line ON OFF CONTROL), or the ignition sense circuitry (line IGNITION CONTROL). If any of the 3 paths cause a low at the collector of Q0612, the electronic ON is engaged.

2.4 Mechanical On/Off

This refers to the on/off button, located on the control head, and which turns the radio on and off. If the radio is turned off and the on/off button is pressed, line ON OFF CONTROL goes high and switches the radio on as long as the button is pressed. The microprocessor is alerted through line ANALOG 3 which is pulled to low by Q0925 (Control Head Model A3) while the on/off button is pressed. If the software detects a low state it asserts B+ CONTROL via AFIC pin 39 low which keeps Q0612 and Q0611, and in turn the radio switched on.

If the on/off button is pressed and held while the radio is on, the software detects the line ANALOG 3 changing to low and switches the radio off by setting B+ CONTROL to low.

2.5 Ignition

Ignition sense is used to prevent the radio from draining the vehicle's battery because the engine is not running.

When the IGNITION input (J0400- 10) goes above 6 volts Q0421 and Q0612 turn on. This turns on SW B+ by turning on Q0611 via line IGNITION CONTROL and Q0612 and the microprocessor starts execution. The software reads the line IGNITION SENSE, determines from the level that the IGNITION input is active and sets the B+ CONTROL output of the AFIC pin 39 to high to latch on SW B+.

When the IGNITION input goes below 6 volts, Q0421 switches off and R0426, R0427 pull line IGNITION SENSE high. The software is alerted by line IGNITION SENSE to switch off the radio by setting B+ CONTROL to low. The next time the IGNITION input goes above 6 volts the above process will be repeated.

2.6 Hook

The HOOK input is used to inform the μ P when the Microphone's hang-up switch is engaged. The signal is routed from J0101-3 and transistor Q0137 to the E9/20 μ P U0101-56. The voltage range of HOOK in normal operating mode is 0-5V. If a rear GP input line is set as HOOK then the front HOOK signal is overridden.

2.7 Microprocessor Clock Synthesizer

The controller uses the oscillator in the microprocessor E9/20 μ P along with some external components (C0115-C0117, L0114, R0115, Y0114) to generate the clock. Q0114 is used to alter the clock frequency slightly under software control if there is a possibility of harmonics of this clock source interfering with the desired radio receive frequency.

2.8 Serial Peripheral Interface (SPI)

The μ P communicates to many of the IC's through its SPI port. This port consists of SPI TRANSMIT DATA (MOSI) (E9/20 μ P:U0101-52), SPI RECEIVE DATA (MISO) (E9/20 μ P:U0101-51), SPI CLK (E9/20 μ P:U0101-53) and chip select lines going to the various IC's, connected on the SPI PORT (BUS). This BUS is a synchronous bus, in that the timing clock signal CLK is sent while SPI data (SPI TRANSMIT DATA or SPI RECEIVE DATA) is sent. Therefore, whenever there is activity on either SPI TRANSMIT DATA or SPI RECEIVE DATA there should be a uniform signal on CLK. The SPI TRANSMIT DATA is used to send serial from a μ P to a device, and SPI RECEIVE DATA is used to send data from a device to a μ P. The only device from which data can be received via SPI RECEIVE DATA is the EEPROM (U0108).

On the controller there are three IC's on the SPI BUS, AFIC (U103-33), EEPROM (U0108-1) and D/A (U0731-6). In the RF sections there is one IC on the SPI BUS, the FRAC-N Synthesizer. The SPI TRANSMIT DATA and CLK lines going to the RF section are filtered by L0194/L0195 to minimize noise. The chip select lines for the IC's are decoded by the address decoder U102.

The SPI BUS is also used for the control head. U0104-1,2 buffer the SPI TRANSMIT DATA and CLK lines to the control head. U0104-3 switches off the CLK signal for the LCD display if it is not selected via LCD CE.

When the μ P needs to program any of these IC's it brings the chip select line for that IC to a logic 0 and then sends the proper data and clock signals. The amount of data sent to the various IC's are different, for example the FRAC-N can receive up to 13 bytes (97 bits) while the DAC can receive up to 3 bytes (24 bits). After the data has been sent the chip select line is returned to a logic 1.

The Option board interfaces are different in that the μ P can also read data back from devices connected.

The timing and operation of this interface is specific to the option connected, but generally follows the pattern:

- 1) an option board device generates the interrupt,
- 2) main board asserts a chip select for that option board device,
- 3) the main board μ P generates the CLK, and
- 4) when data transfer is complete the main board terminates the chip select and CLK activity.

2.9 SBEP Serial Interface

The SBEP serial interface allows the radio to communicate with the Radio Service Software (RSS). This interface connects to the Microphone connector (J0903/J0803) via Control Head connector (J0101) and comprises BUS+ (J0101-15). The line is bi-directional, meaning that either the radio or the RSS can drive the line.

When the RSS needs to communicate with the radio, an interrupt is generated by the BUS+ signal through R0104. The μ P then starts serial data communication on BUS+ by sending data from pin 50 through D0101 and receiving data at pin 47 through R0104. While the radio is sending serial data at pin 50 it receives an "echo" of the same data at pin 47.

2.10 General Purpose Input/Output

The Controller provides six general purpose lines (GP1 through GP6) available on the accessory connector J0400 to interface to external options. Lines GP1,4 are inputs, GP2 is an output and GP3,5,6 are bidirectional. The software and the hardware configuration of the radio model define the function of each port. Some ports are not connected on the 4ch radio, refer to appendix B.

GP1 can be used as external PTT input or others, set by the RSS.

GP2 can be used as normal output (Q0441 placed) or external alarm output (Q0442 placed). The voltage range can be set by R0442 (0-5V) or R0443 (0 - supply voltage).

GP4 can be used as normal input (D0471, R0477 not placed) or emergency input (D0471, R0477 placed).

GP3,5,6 are bidirectional and use the same circuit configuration. Each port uses an output transistor controlled by μ P port PB5,4,7 and an input transistor read by μ P port PC2,5,3. To use one of the GP's as input the μ P must turn off the corresponding output transistor.

In addition the signals from GP3-6 are fed to the option board connectors J0102, J0103.

The 470pF and 10nF capacitors serve to filter out any AC noise which may ride on the GP lines.

2.11 Normal Microprocessor Operation

The E9/20 μ P (U0101) contains internal 12 (E9) or 20 (E20) Kilobytes ROM, 512 (E9) or 768 (E20) bytes SRAM and 512 bytes EEPROM.

The E9/20 μ P RAM is always powered to maintain parameters such as the last operating mode. This is achieved by maintaining 5V at U0101-25. Under normal conditions, when the radio is off UNSW +5V is formed by FLT A+ running to D0621.

C0622 allows the battery voltage to be disconnected for a couple of seconds without losing RAM parameters. Diode D0621 prevents radio circuitry from discharging this capacitor.

U0101-22 is the high reference voltage for the A/D ports on the E9/20 μ P. Resistor R0105 and capacitor C0105 filter the +5V reference. If this voltage is lower than +5V the A/D readings will be incorrect. Likewise U0101-21 is the low reference for the A/D ports. This line is normally tied to ground. If this line is not connected to ground, the A/D readings will be incorrect.

The MODB (U0101-25) input of the E9/20 μ P must be at a logic 1 for it to start executing correctly. The XIRQ (U0101-45) and the IRQ (U0101-46) pins should also be at a logic 1.

Optional external EEPROM (U0108) is available on some radio models. The external EEPROM is accessed through a serial connection. The E9/20 μ P generates SPI CLK (U0101-53), SPI TRANSMIT DATA (MOSI) (U0101-52) and SPI RECEIVE DATA (MISO) (U0101-51) to read or write EEPROM. On a read of EEPROM the E9/20 μ P continues generating the clock and the EEPROM places the requested data on the SPI RECEIVE DATA (MISO) line. On a write the message is followed by the data to be written to the EEPROM.

2.12 Control Head Model A2 or A3

Two Control Head versions (A2 or A3) are available for user interface. Both Control Heads contain the internal speaker, the microphone connector, several buttons to operate the radio and several indicator LEDs to inform the user about the radio status. Additionally the Control Head model A3 uses a 3 digit, 7 segment, LCD display for the channel number.

The On/Off button when pressed switches the voltage regulators on by pulling ON OFF CONTROL to high and connects the base of Q0925(A3), Q0825(A2) to FLT A+. This transistor pulls the line ANALOG 3 to low to inform the μ P that the On/Off button is pressed. If the radio is switched off, the μ P will switch it on and vice versa. All other buttons work the same way. If a button is pressed, it will connect one of the 3 lines ANALOG 1,2,3 to a resistive voltage divider connected to +5V. The voltages of the lines are A/D converted inside the μ P and specify the pressed button.

All the back light and indicator LEDs are driven by current sources and controlled by the μ P via SERIAL PERIPHERAL INTERFACE (SPI) interface. The LED status is stored in shiftregister U0941(A3), U0841(A2). Line LED CE enables the serial write process via Q0941(A3), Q0841(A2) while line LED CLCK BUF shifts the data of line SPI DATA BUF into the shiftregister.

In addition Control Head Model A3 contains the LCD display H0931. The display data of line SPI DATA BUF is shifted into the display driver by clock signal LCD CLCK BUF.

CONTROLLER BOARD AUDIO AND SIGNALLING CIRCUITS

3.0 General

3.1 Audio Filter IC (AFIC)

The AFIC (U0103) used in the controller performs RX/TX audio shaping, i.e. filtering, amplification, attenuation.

The AFIC is programmable through the SPI BUS (U0103-30/31/33), normally receiving 6 bytes. This programming sets up various paths within the AFIC to route audio signals through the appropriate filtering, gain and attenuator blocks. The AFIC also has 4 General Control Bits: GCB1,3-5 which are CMOS level outputs. GCB1 is used to switch the radio on and off under μ P control via line B+ CONTROL. GCB3 is used to switch the audio PA on and off (AUDIO PA ENABLE). GCB4 selects between the UNATTEN RX OUT audio signal and the unfiltered DET AUDIO signal. GCB5 HIGH LOW BAND can be used to switch between band splits.

3.2 Audio Ground

VAG is the dc bias used as an audio ground for the Op-amps that are external to the Audio Filter IC (AFIC). U0105-1 forms this bias by dividing 9.3V with resistors R0171, R0172 and buffering the 4.65V result with a voltage follower. VAG emerges at pin 1 of U0105-1. C0172 is a bypass capacitor for VAG. The AFIC generates its own 2.5 V bias for its internal circuitry. C0153 is the bypass for the AFIC's audio ground dc bias. Note that while there are AFIC VAG, and BOARD VAG (U0105-1) each of these are separate. They do not connect together.

4.0 Transmit Audio Circuits

Refer to Figure 6.3-1 for reference for the following sections.


4.1 Mic Input Path

The radio supports 2 distinct microphone paths known as internal and external mic and an auxiliary path (FLAT TX AUDIO). The microphones used for the radio require a DC biasing voltage provided by a resistive network.

These two microphone audio inputs are connected together. Following the internal mic path; the microphone is plugged into the radio control head and is connected to the controller board via J0101-16. From here the signal is routed to C0142. R0141 and R0142 provide the 9.3VDC bias. R0142 and C0141 provide a 1k Ω AC path to ground that sets the input impedance for the microphone and determines the gain based on the emitter resistor in the microphone's amplifier circuit.

The MIC signal is routed to the AFIC's TX IN input (U0103-10) through R0146 and R0145 (GM950E radio) or through Op-amp buffer U0106-2 and option board connector J0103-3,1 (GM950i radio). The audio signal at the output of U0106-2 should be approximately 80mV deviation with 25kHz channel spacing.

The FLAT TX AUDIO signal from accessory connector U0400-5 is buffered by Op-amp U0106-1 and fed to the AFIC U0103-13 through gate U0107-1. Gate U0107-1 is controlled by the μ P port PC7 (U0101-42) and selects between FLAT TX AUDIO or signalling signal created by the μ P.



GEPD 5427-1

Figure 6.3-1 Transmit Audio Paths

4.2 External Mic Path

The external microphone signal enters the radio on accessory connector J0400 pin 2 and connects to the standard microphone input through R0421.

4.3 PTT Sensing and TX Audio Processing

Mic PTT is sensed by the μ P U0101 pin 22. An external PTT can be generated by grounding pin 3 on the accessory connector if this input is programmed for PTT.

The MIC signal is routed to the AFIC (U0103) through R0146 and R0145 (GM950E radio) or through Op-amp buffer U0106-2 and option board connector J0103-3,1 (GM950i radio). R0145, C0145, the amplifier inside the AFIC (pins 9,10) and gain setting resistor R0147 pre-emphasise the MIC audio signal. After further limiting and filtering the modulation signal emerges from the AFIC at U0103-19/20. Both signals are weighted by resistors R0181, R0182 and add up to signal MOD IN.

4.4 Option Board Audio (GM950i only)

The audio coming from the microphone (J0101-16) or the external microphone (J0400-2) is routed through Op-amp buffer U0106-2 (GM950i only) to the option board connector J0103-3. After option board processing the signal emerges at J0103-1. The source resistor of the option board output and C0145, the amplifier inside the AFIC (U0103-9,10) and gain setting resistor R0147 pre-emphasise the signal. Inside the AFIC the signal follows a path identical to conventional transmit audio. The modulation signal emerges from the AFIC at J0103-19/20. Both signals are weighted by resistors R0181, R0182 and add up to signal MOD IN.


<http://www.myradio168.net>

5.0 Transmit Signalling Circuits

Refer to Figure 6.3-2 for reference for the following sections. From a hardware point of view, there are three types of signalling:

1. Sub-audible data (PL / DPL / Connect Tone) that gets summed with transmit voice or signalling,
2. DTMF data for telephone communication in trunked and conventional systems, and
3. Audible signalling including Select 5, MPT-1327, MDC, Single Tones.

All three types are supported by the hardware while the radio software determines which signalling type is available. Currently only PL/DPL and Single tones are supported in the software.



GEPD 5432-1

Figure 6.3-2 Transmit Signalling Paths

5.1 Sub-audible Data (PL/DPL)

Sub-audible data implies signalling whose frequency is below 300Hz. Although it is referred to as "sub-audible data," the actual frequency spectrum of these waveforms may be as high as 250 Hz, which is audible to the human ear. However, the radio receiver filters out any audio below 300Hz, so these tones are never heard in the actual system.

Only one type of sub-audible data can be generated by U0103 (AFIC) at any one time. The process is as follows. using the SPI BUS, the μ P programs the AFIC to set up the proper low-speed data deviation and select the PL or DPL filters. The μ P then generates a square wave which strobes the AFIC PL / DPL encode input PL CLOCK STROBE U0103-32 at twelve times the desired data rate. For example, for a PL frequency of 103Hz, the frequency of the square wave would be 1236Hz.

This drives a tone generator inside U0103 which generates a staircase approximation to a PL sine wave or DPL data pattern. This internal waveform is then low-pass filtered and summed with voice or data. The resulting summed waveform then appears on U0103-19,20 (MOD IN), where it is sent to the RF board as previously described for transmit audio.


5.2 High Speed Data and DTMF

The High Speed Data and DTMF waveforms are created by the μ P U0101 using summer U0105-3. Op-amp U0105-3 and resistors R0121-R0124 add up the three signals coming from the μ P pins 58, 59 and 62. The output signal of U0105-3 is routed to the AFIC (U0103-13) through gate U0107-1. Inside the AFIC the signal enters the conventional transmitter audio path at the splatter filter input. Gate U0107-1 controlled by μ P port PC7 (U0101-42) selects between data signal and FLAT TX AUDIO signal. Microphone audio is muted during High Speed Data signalling.

<http://www.myradio168.net>

6.0 Receive Audio Circuits

Refer to Figure 6.3-3 for reference for the following sections.



GEPD 5429-1

Figure 6.3-3 Receive Audio Paths.

6.1 Squelch Detect

The IF IC controls the squelch characteristics of the radio. With a few external parts (R5222, C5229, C5230, R5223) the squelch tail, hysteresis, attack and delay are optimized for the radio. To set the squelch threshold the signal from IF IC pin 23 (line SQ ATT IN) is routed to the squelch attenuator input of the AFIC (U0103-16). The attenuated signal (line SQ ATT OUT) from the AFIC (U0103-18) enters the IF IC at pin 20 and is used to create a squelch indicator signal available at pin 15 (line CSQ DET).

The microprocessor controlled ADAPT signal at pin 22 activates the fast squelch indicator signal at IF IC pin 18 (FAST SQ). Both squelch indicator signals CSQ DET (pin 15) and FAST SQ (pin 18) are combined, weighted by resistors R0111 / R0112 and fed to one of the microprocessor's ADCs (U0101-15) for interpretation. From the voltage weighted by the resistors the μ P determines whether CSQ DET, FAST SQ or both are active.

6.2 Audio Processing and Digital Volume Control

The receiver audio signal enters the controller section from the IF IC (U5201-28) on DET AUDIO. The signal is AC coupled by C0181 and enters the AFIC via the RX IN pin U0103-7.

Inside the AFIC the signal entering RX IN (U0103-7) goes through the audio path while the signal entering PL DPL IN (U0103-8) via C0182 goes through the PL/DPL path.

The audio path has a programmable amplifier, whose setting is based on the channel bandwidth being received, then a LPF filter to remove any frequency components above 3000Hz and then an HPF to remove any sub-audible data below 300Hz. Next, the recovered audio passes through a de-emphasis filter if it is enabled (to compensate for Pre-emphasis which is used to reduce the effects of FM noise). The IC then passes the audio through the 8-bit programmable attenuator whose level is set depending on the value of the volume control. Finally, the filtered audio signal passes through an output buffer within the AFIC. The audio signal exits the AFIC at RX AUDIO U0103-23.

The μ P programs the attenuator, using the SPI BUS, based on the volume setting. The minimum/maximum settings of the attenuator are set by codeplug parameters.

Since sub-audible signalling is summed with voice information on transmit, it must be separated from the voice information before processing. Any sub-audible signalling enters the AFIC from the IF IC at PL DPL IN U0103-8. Once inside it goes through the PL/DPL path. The signal first passes through one of 2 low pass filters, either PL low pass filter or DPL/LST low pass filter. Either signal is then filtered and goes through a limiter and exits the AFIC at PL DPL DECODER OUT U0103-27. At this point the signal will appear as a square wave version of the sub-audible signal which the radio received. The microprocessor (U0101-64) will decode the signal directly to determine if it is the tone/code which is currently active on that mode.

6.3 Audio Amplification Speaker (+) Speaker (-)

The output of the AFIC's digital volume pot, U0103-23 is routed through a voltage divider formed by R0401 and R0402 to set the correct input level to the audio PA (U0401). This is necessary because the gain of the audio PA is 46 dB, and the AFIC output is capable of overdriving the PA unless the maximum volume is limited.

The audio then passes through C0401 which provides AC coupling and low frequency roll-off. C0402 provides high frequency roll-off as the audio signal is routed to pins 1 and 9 of the audio power amplifier U0401.

The audio power amplifier has one inverted and one non-inverted output that produces the differential audio output SPK+ / SPK- (U0401-4/6). The inputs for each of these amplifiers are pins 1 and 9 respectively; these inputs are both tied to the received audio. The audio PA's DC biases are not activated until the audio PA is enabled at pin 8.

The audio PA is enabled via AUDIO PA ENABLE signal from the AFIC (U0103-40). When the base of Q0401 is low, the transistor is off and U0401-8 is high, using pull up resistor R0406, and the Audio PA is ON. The voltage at U0401-8 must be above 8.5VDC to properly enable the device. If the voltage is between 3.3 and 6.4V, the device will be active but has its input (U0401-1/9) off. R0404 ensures that the base of Q0401 is high on power up. Otherwise there may be an audio pop due to R0406 pulling U0401-8 high before the software can switch on Q0401.

The SPK+ and SPK- outputs of the audio PA have a DC bias which varies proportionately with FLT A+ (U0401-7). FLT A+ of 11V yields DC offset of 5V, and FLT A+ of 17V yields a DC offset of 8.5V. If either of these lines is shorted to ground, it is possible that the audio PA will be damaged. SPK+ and SPK- are routed to the accessory connector (J400-16 and 1) and to the control head (connector J0101-1 and 2).

6.4 Handset Audio

Certain hand held accessories have a speaker within them which require a different voltage level than that provided by U0401. For those devices HANDSET AUDIO is available at J0101-14.

The received audio from the output of the AFIC's digital volume attenuator is also routed to U0105-4 pin 9 where it is amplified 15 dB; this is set by the 10k/68k combination of R0154 and R0155. This signal is routed from the output of the Op-amp U0105-4 pin 8 to J0101-14. The control head sends this signal directly out to the microphone jack. The maximum value of this output is 6.6Vp-p.

6.5 Filtered Audio

The AFIC has an audio whose output at U0103-22 has been filtered and de-emphasized, but has not gone through the digital volume attenuator. From AFIC U0103-22 the signal is routed through gate U0107-2 and AC coupled to U0106-4. The gate controlled by AFIC port GCB4 (U0103-2) selects between the filtered audio signal from the AFIC or the unfiltered discriminator signal from the IF IC U5201. The output at U0106-4 is then routed to J0400-11. Note that any volume adjustment of the signal on this path must be done by the accessory.

6.6 Discriminator Audio (Unfiltered)

Note that discriminator audio DET AUDIO from the IF IC U5201, in addition to being routed to the AFIC, is also routed to the option connector J0103-5 (See Secure Rx description blocks for further information).

6.7 Option Board Audio

Discriminator or filtered audio, enters the option board at connector J0103-5 and J0103-4. On the option board, the signal may be processed and then fed back through (J0103-2) to AUX RX IN of the AFIC (U0103-6). From then on it follows a path identical to conventional receive audio, where it is filtered (0.3 - 3kHz) and de-emphasized.

7.0 Receive Signalling Circuits

Refer to Figure 6.3-4 for reference for the following sections.




Figure 6.3-4 Receive Signalling Path.

7.1 Sub-audible Data Decoder (PL/DPL)

The receiver audio signal entering the AFIC U0103 at pin 8 first passes through the Tone PL filter or the Digital PL filter, depending on the PL option selected for the current operating mode. Filtered PL is then coupled to the PL detector circuit, with detected PL output at U0103-27. At this point the signal will appear as a square wave version of the sub-audible signal which the radio received. The microprocessor U0101-64 will decode the signal directly to determine if it is the tone / code which is currently active on that mode.

7.2 High Speed Data Decoder

The unattenuated receiver audio signal from U0103-22 is AC coupled to the input of centre slicer circuit U0105-2. The non-inverting input of Op-amp U0105-2 is fed through resistor R0162. Capacitor C0164 sets a low-pass corner frequency of 3.3kHz. The inverting input of Op-amp U0105-2 is fed through resistor R0163. Capacitor C0163 sets a low-pass corner frequency of 16Hz.

During operation, R0163 / C0163 establish an average DC offset level at U0105-2 pin 6 dependent on the average DC level of the undetected signal to set the "trigger" threshold of U0105-2. R0162 / C0164 provide high audio frequency roll-off to improve falsing immunity, but passes 600 or 1200 baud signals. The detected output from the centre slicer circuit is buffered and inverted by Q0161 and then coupled to the μ P U0101-1 where algorithms perform the final decoding.

7.3 Alert Tone Circuits

When the software determines that it needs to give the operator an audible feedback (for a good key press, or for a bad key press), or radio status , it sends an alert tone to the speaker.

It does so by sending SPI BUS data to U0103 which sets up the audio path to the speaker for alert tones. The alert tone itself is generated by the AFIC.

The allowable internal alert tones are 410, 820, and 1640Hz. In this case a code contained within the SPI BUS load to the AFIC sets up the path and determines the tone frequency, and at what volume level to generate the tone. (It does not have to be related to the voice volume setting).

Inside the AFIC, this signal is routed to the alert tone generator; the output of the generator is summed into the audio chain just after the RX audio de-emphasis block. Inside U0103 the tone is amplified and filtered, then passed through the 8-bit digital volume attenuator, which is typically loaded with a special value for alert tone audio. The tone exits at U0103-23 and is routed to the audio PA like receive audio.

<http://www.myradio168.net>

216-246MHz SPECIFIC CIRCUIT DESCRIPTION

8.0 Receiver Front-End

The receiver is able to cover the range from 216 to 246 MHz. It consists of four major blocks: front-end, mixer, first IF section and IF IC. Antenna signal pre-selection is performed by two varactor tuned bandpass filters. A double balanced schottky diode mixer converts the signal to the first IF at 45.1 MHz.

Two crystal filters in the first IF section and two ceramic filters in the second IF section provide the required selectivity. The second IF at 455 kHz is mixed, amplified and demodulated in the IF IC. The processing of the demodulated audio signal is performed by an audio processing IC located in the controller section.

8.1 Front-End Band-Pass Filter and Pre-Amplifier

A two pole pre-selector filter tuned by the dual varactor diode D3301 pre-selects the incoming signal (PA RX) from the antenna switch to reduce spurious effects to following stages. The tuning voltage (FE CNTL VLTG) ranging from 2 volts to 8 volts is controlled by a Digital to Analog (D/A) converter (U0731-11) in the controller section. A dual hot carrier diode (D3303) limits any inband signal to 0dBm to prevent damage to the pre-amplifier.

The RF pre-amplifier is an SMD device (Q3301) with collector base feedback to stabilize gain, impedance, and intermodulation. The collector current of approximately 11-16 mA, drawn from the voltage 9V3, is controlled by a current source composed of Q3302, R3302, R3300, and R3311 - R3313. In transmit mode the high K9V1 signal fed through diode D3300 switches off the current source and in turn the pre-amplifier. In receive mode K9V1 must be low to switch on the current source. A 3 dB pad (R3306 - R3308 and R3316 - R3318) stabilizes the output impedance and intermodulation performance.

A second two pole varactor tuned bandpass filter provides additional filtering to the amplified signal. The dual varactor diode D3313 and D3314 are controlled by the same signal which controls the pre-selector filter.

If the radio is configured for a base station application, R3318 is not placed and TP3301 and TP3302 are shorted.

8.2 Mixer and Intermediate Frequency (IF) Section

The signal coming from the front-end is converted to the first IF (45.1 MHz) using a double balanced schottky diode mixer (D3331). Its ports are matched for incoming RF signal conversion to the 45.1MHz IF using high side injection. The injection signal (VCO MIXER) coming from the mixer buffer (Q3770) is filtered by the lowpass consisting of (L3333, L3334, C3331 - C3333) and has a level of approximately 10 dBm.

The mixer IF output signal (RX IF) from transformer T3301 pin 2 is fed to the first two pole crystal filter Y5201. The filter output in turn is matched to the following IF amplifier.

The IF amplifier Q5201 is actively biased by a collector base feedback (R5201, R5202) to a current drain of approximately 5 mA drawn from the voltage 5V STAB. The output impedance is matched to the second two pole crystal filter Y5202. A dual hot carrier diode (D5201) limits the filter output voltage swing to reduce overdrive effects at RF input levels above -27 dBm.

8.3 IF IC (U5201)

The first IF signal from the crystal filters feeds the IF IC (U5201) at pin 6. Within the IF IC the 45.1MHz first IF signal mixes with the second local oscillator (LO) at 44.645MHz to the second IF at 455 kHz. The second LO uses the external crystal Y5211. The second IF signal is amplified and filtered by two external ceramic filters (FL5201, FL5202). Back in the IF IC the signal is demodulated in a phase-lock detector and fed from IF IC pin 28 to the audio processing circuit AFIC U0103 located in the controller section (line DET AUDIO).

The IF IC also controls the squelch characteristics of the radio. With a few external parts (R5222, C5229, C5230, R5223) the squelch tail, hysteresis, attack and delay were optimized for the radio. To set the squelch threshold the signal from IF IC pin 23 (line SQ ATT IN) is attenuated by a microprocessor controlled audio processing IC AFIC (U0103) located in the controller section. The attenuated signal from the AFIC (line SQ ATT OUT) enters the IF IC at pin 20 and is used to create a squelch indicator signal available at pin 15 (CSQ DET).

The microprocessor controlled ADAPT signal at pin 22 activates the fast squelch indicator signal at IF IC pin 18 (FAST SQ). Both squelch indicator signals CSQ DET (pin 15) and FAST SQ (pin 18) are combined, weighted by R0111 / R0112 and fed to the microprocessor U0101 pin 15 for interpretation. From the voltage weighted by the resistors the μ P determines whether CSQ DET, FAST SQ or both are active.

At IF IC pin 11 an RSSI signal is available with a dynamic range of 70 dB. The RSSI signal is buffered by op-amp U0106-3 and available at accessory connector J0400-15.

9.0 Transmitter Power Amplifier (PA) 5-25W

The transmitter is able to cover the range from 216 to 246 MHz.

The radio's 5-25 W PA is a four stage amplifier used to amplify the output from the exciter to the radio transmit level. It consists of four stages in the line-up. The first (Q8510) is a bipolar stage that is controlled via the PA control line. It is followed by another bipolar stage (Q8520), a MOS FET stage (Q8530, Q8531) and a final bipolar stage (Q8540). Devices Q8510, Q8520, Q8530 and Q8531 are surface mounted. Bipolar Transistor Q8540 is directly attached to the heat sink.

9.1 Power Controlled Stage

The first stage (Q8510) amplifies the RF signal from the VCO (line EXCITER PA) and controls the output power of the PA. The output power of the transistor Q8510 is proportional to its collector current which is adjusted by a voltage controlled current source consisting of Q8612 and Q8621.

The collector current of Q8510 causes a voltage drop across the resistors R8623 and R8624. Transistor Q8612 adjusts the voltage drop across R8621 through PA control line (PWR CNTL). The current source Q8621 adjusts the collector current of Q8510 by modifying its base voltage until the voltage drop across R8623 and R8624 plus VBE (0.6V) equals the voltage drop across R8621 plus VBE (0.6V) of Q8611. If the voltage of PWR CNTL is raised, the base voltage of Q8612 will also rise causing more current to flow to the collector of Q8612 and a higher voltage drop across R8621. This in turn results in more current driven into the base of Q8510 by Q8621 so that the current of Q8510 is increased. The collector current settles when the voltage over the series configuration of R8623 and R8624 plus VBE of Q8621 equals the voltage over R8621 plus VBE (0.6V) of Q8611.

By controlling the output power of Q8510 and in turn the input power of the following stages the ALC loop is able to regulate the output power of the transmitter. Q8611 is used for temperature compensation of the PA output power.

9.2 PA Stages

The bipolar transistor Q8520 is driven by Q8510. To reduce the collector-emitter voltage and in turn the power dissipation of Q8510 its collector current is drawn from the antenna switch circuit.

In transmit mode the base of Q8520 is slightly positive biased by a divided K9V1 signal. This bias along with the RF signal from Q8510 allows a collector current to be drawn from the antenna switch circuit and in turn switches the antenna switch to transmit, while in receive mode the low K9V1 signal with no RF signal present cuts off the collector current and in turn switches the antenna switch to receive.

The following stage uses two enhancement mode N-Channel MOS FET devices (Q8530, Q8531) and requires for each device a positive gate bias and a quiescent current flow for proper operation. The voltages of the lines BIAS VLTG and BIAS VLTG 2 are set in transmit mode by two Digital to Analog (D/A) converters (U0731-4, U0731-11) and fed to the gates of Q8531 and Q8530 via two resistive dividers. The bias voltages are tuned in the factory. If one or both transistor are replaced, the bias voltages must be tuned with the Service Software (RSS). Care must be taken, not to damage any device by exceeding the maximum allowed bias voltage. The collector currents are drawn from the supply voltage A+ via L8531 and L8532.

The final stage uses the bipolar device Q8540 and operates off the A+ supply voltage. For class C operation the base is DC grounded by two series inductors (L8533, L8534). A matching network consisting of C8541-C8544 and two striplines transform the impedance to 50 Ohms and feed the directional coupler.

9.3 Directional Coupler

The directional coupler is a microstrip printed circuit which couples a small amount of the forward power off the RF power from Q8541. The coupled signal is rectified to an output power proportional negative DC voltage by the diode D8553 and sent to the power control circuit in the controller section via the line PWR DETECT for output power control. The power control circuit holds this voltage constant, thus ensuring the forward power out of the radio to be held to a constant value.

9.4 Antenna Switch

The antenna switch is switched synchronously with the K9V1 voltage and feeds either the antenna signal coming through the harmonic filter to the receiver or the transmitter signal coming from the PA to the antenna via the harmonic filter.

In transmit mode, this K9V1 voltage is high and biases Q8520 and, along with the RF signal from Q8510, allows a collector current to be drawn. The collector current of Q8520 drawn from A+ flows via L8542, L8541, directional coupler, D8551, L8551, D8631, L8631, R8616, R8617 and L8611 and switches the PIN diodes D8551 and D8631 to the low impedance state.

D8551 leads the RF signal from the directional coupler to the harmonic filter. The low impedance of D8631 is transformed to a high impedance at the input of the harmonic filter by the resonant circuit formed by L8551, C8633 and the input capacitance of the harmonic filter.

In receive mode the low K9V1 and no RF signal present from Q8510 turn off the collector current of Q8520. With no current drawn by Q8520 and resistor R8615 pulling the voltage at PIN diode D8631 to A+ both PIN diodes are switched to the high impedance state. The antenna signal, coming through the harmonic filter, is channelled to the receiver via L8551, C8634 and line PA RX.

A high impedance resonant circuit formed by D8551 in off state and L8554, C8559 prevents an influence of the receive signal by the PA stages. The high impedance of D8631 in off state doesn't influence the receiver signal.

9.5 Harmonic Filter

The transmitter signal from the antenna switch is channelled through the harmonic filter to the antenna connector J8501. The harmonic filter is formed by inductors L8552, L8553, and capacitors C8551 through C8554. This network forms a low-pass filter to attenuate harmonic energy of the transmitter to specifications level. R8550 is used for electro-static protection.

9.6 Power Control

The power control loop regulates transmitter power with an automatic level control (ALC) loop and provides protection features against excessive control voltage and high operating temperatures.

MOS FET device bias, power and control voltage limit are adjusted under microprocessor control using a Digital to Analog (D/A) converter (U0731). The microprocessor writes the data into the D/A converter via serial interface (SRL) composed of the lines SPI CLCK SRC (clock), SPI DATA SRC (data) and DAC CE (chip enable). The D/A adjustable control voltage limit increases transmitter rise time and reduces adjacent channel splatter as it is adjusted closer to the actual operating control voltage.

The microprocessor controls K9V1 ENABLE (U0101-6) to switch on the first and the second PA stage via transistors Q0741, Q0742 and signal K9V1. The antenna switch is turned on by the collector current of the second PA stage. In TX mode the front-end control D/A (U0731-11) is used for BIAS VOLTAGE 2 (via R0736) and K9V1 ENABLE pulls signal FE CNTL VLTG to ground via Q0743. PA DISABLE, also microprocessor controlled (U0101-54), sets BIAS VLTG (U0731-4) and VLTG LIMIT SET (U0731-13) via D0731 and BIAS VLTG 2 via D0733 in receive mode to low to switch off the biases of the MOS FET devices Q8530, Q8531 and to switch off the power control voltage (PWR CNTL).

Through an Analog to Digital (A/D) input (VLTG LIMIT) the microprocessor can read the PA control voltage (PWR CNTL) during the tuning process.

The ALC loop regulates power by adjusting the PA control line PWR CNTL to keep the forward power voltage PWR DETECT at a constant level.

Op-amp U0701-2 and resistors R0701 to R0703 and R0731 subtract the negative PWR DETECT voltage from the PA PWR SET D/A output U0731 pin 2. The result is connected to Op-amp inverting input U0701-4 pin 9 which is compared with a 4.6 volt reference VAG present at noninverting input U0701-4 pin 10 and controls the output power of the PA via pin 8 and control line PWR CNTL. The 4.6 volt reference VAG is set by a resistive divider circuit (R0171, R0172) which is connected to ground and 9.3 volts, and buffered by Op-amp U0105-1.

During normal transmitter operation the voltages at the Op-amp inputs U0701-4 pins 9 and 10 should be equal to 4.6 volts and the PA control voltage output at pin 8 should be between 4 and 7 volts. If power falls below the desired setting, PWR DETECT becomes less negative, causing the output at U0701-2 pin 7 to decrease and the Op-amp output U0701-4 pin 8 to increase.

A comparator formed by U0701-4 increases the PA control voltage PA CNTL until PWR DETECT is at the desired level. The power set D/A output voltage PA PWR SET (U0731-2) at U0701-2 pin 5 adjusts power in steps by adjusting the required value of PWR DETECT. As PA PWR SET (U0731-2) decreases, transmitter power must increase to make PWR DETECT more negative and keep the inverting input U0701-4 pin 9 at 4.6 volts.

Loop frequency response is controlled by Op-amp feedback components R0712 and C0711. Op-amp U0701-3 compares the power control voltage PWR CNTL divided by resistors R0717 to R0719 with the voltage limit setting VLTG LIMIT SET from the D/A converter (U0731-13) and keeps the control voltage constant via Q0711 if the control voltage, reduced by the resistive divider (R0717 to R0719), approaches the voltage of VLTG LIMIT SET (U0731-13).

Rise and fall time of the output power during transmitter keying and dekeying is controlled by the comparator formed by Op-amp U0701-3.

During normal transmitter operation the voltage at U0701-3 pin 13 is higher than the voltage at pin 12 causing the output at pin 14 being low and switching off transistor Q0711. Diode D0732 reduces the bias voltages BIAS VLTG, BIAS VLTG 2 for low control voltage levels.

The temperature of the PA area is monitored by Op-amp U0701-1 using thermistor R8641 (located in the PA section). If the temperature increases, the resistance of the thermistor decreases, decreasing the voltage PA TEMP. The inverting amplifier formed by U0701-1 amplifies the PA TEMP voltage and if the voltage at Op-amp pin 1 approaches 4.6 V plus the voltage (ON) across D0721, U0701-1 simulates an increased power which in turn decreases the power control voltage until the voltage at U0701-4 pin 9 is 4.6V again. During normal transmitter operation the output voltage of Op-amp U0701-1 pin 1 is below 4.6V. Diode D8601 located in the PA section acts as protection against transients and wrong polarity of the supply voltage.

10.0 Frequency Synthesis

The complete synthesizer subsystem consists of the Reference Oscillator (Y3702 or Y3701), the Fractional-N synthesizer (U3701), the Voltage Controlled Oscillator (Q3741, Q3751), the RX and TX buffer stages (Q3760, Q3770, Q3780) and the feedback amplifier (Q3790).

10.1 Reference Oscillator

The Reference Oscillator (Y3702) contains a temperature compensated crystal oscillator with a frequency of 16.8 MHz. An analog to digital (A/D) converter internal to U3701 and controlled by the microprocessor via serial interface (SRL) sets the voltage at the warp output of U3701 pin 16 to set the frequency of the oscillator. The output of the oscillator (pin 2 of Y3702) is applied to pin 14 (XTAL1) of U3701 via a RC series combination.

In applications where less frequency stability is required the oscillator inside U3701 is used along with an external crystal Y3701, the varactor diode D3702, C3708, C3710 and R3704.

10.2 Fractional-N Synthesizer (U3701)

The FRAC-N synthesizer IC (U3701) consists of a pre-scaler, a programmable loop divider, control divider logic, a phase detector, a charge pump, an A/D converter for low frequency digital modulation, a balance attenuator to balance the high frequency analog modulation and low frequency digital modulation, a 13V positive voltage multiplier, a serial interface for control, and finally a super filter for the regulated 9.3 volts.

A voltage of 9.3V applied to the super filter input (U3701 pin 22) supplies an output voltage of 8.6 VDC at pin 18. It supplies the VCO (Q3741 / Q3751), VCO modulation bias circuit (R3714) and the synthesizer charge pump resistor network (R3723, R3724). The synthesizer supply voltage is provided by the 5V regulator U3801.

In order to generate a high voltage to supply the phase detector (charge pump) output stage at pin VCP (U3701-32), a voltage of 13 VDC is being generated by the positive voltage multiplier circuitry (D3701-1-3, C3716, C3717). This voltage multiplier is basically a diode capacitor network driven by two (1.05 MHz) 180 degrees out of phase signals (U3701-9 and -10).

Output LOCK (U3701-2) provides information about the lock status of the synthesizer loop. A high level at this output indicates a stable loop. IC U3701 divides the 16.8 MHz reference frequency down to 2.1 MHz and provides it at pin 11. This signal is used as clock signal by the controller.

The serial interface (SRL) is connected to the microprocessor via the data line SPI DATA (U3701-5), clock line SPI CLK (U3701-6), and chip enable line FRACN CE (U3701-7).

10.3 Voltage Controlled Oscillator (VCO)

The Voltage Controlled Oscillator (VCO) uses 2 colpitts oscillators, FET Q3741 for transmit and FET Q3751 for receive. The appropriate oscillator is switched on or off by FRAC-N IC output AUX3 (U3701-1) using transistors Q3742 and Q3752. In RX mode AUX3 is nearly at ground level and Q3742 enables a current flow from the source of FET Q3751 while Q3752 is switched off. In TX mode AUX3 is about 5V DC and Q3742 is switched off. Q3752 is switched on and enables a current flow from the source of FET Q3741 while Q3751 is switched off. When switched on the FETs draw a drain current of 8 mA from the FRAC-N IC super filter output. The frequency of the receive oscillator is mainly determined by L3752, C3752, C3754 - C3756 and varactor diodes D3751 / D3752.

Diode D3754 controls the amplitude of the oscillator. The frequency of the transmit oscillator is mainly determined by L3734, C3736 - C3740 and varactor diodes D3732 / D3733. Diode D3739 controls the amplitude of the oscillator. With a steering voltage from 3V to 10V at the varactor diodes the RX frequency range from 181.1 MHz to 219.1 MHz and the TX frequency range from 136 MHz to 174 MHz are covered. In TX mode the modulation signal coming from the FRAC-N synthesizer IC (U3701 pin 28) modulates the TX VCO via varactor diode D3731.

Both oscillator outputs are combined and buffered by the VCO Buffer Q3760. Q3760 draws a collector current of 13 mA from the stabilized 5V (U3801) and drives the Mixer Buffer Q3770. Q3770 draws a collector current of 17 mA from the 9V3 voltage and drives the PA Buffer Q3780 (Pout = 13dBm) and the Pre-scaler Buffer Q3790. Q3790 draws a collector current of 8 mA from the stabilized 5V (U3801) and drives the pre-scaler internal to the FRAC-N IC. In transmit mode Q3780 is switched on by the K9V1 signal and draws a collector current of 19 mA from the K9V1 voltage. The injection signal VCO MIXER with a level of 10dBm feeds the mixer through R3774. The buffer stages Q3760, Q3770, Q3780 and the feedback amplifier Q3790 provide the necessary gain and isolation for the synthesizer loop.

10.4 Synthesizer Operation

The complete synthesizer subsystem works as follows. The combined output signal of the RX VCO (Q3751) and TX VCO (Q3741) is buffered by VCO Buffer Q3760, Mixer Buffer Q3770 and Pre-scaler Buffer Q3790. To close the synthesizer loop, the collector of Q3790 is connected to the PREIN port of synthesizer U3701 (pin 20). The output of (Q3770) also provides signals for the mixer (via VCO MIXER) and the PA Buffer (Q3780).

The pre-scaler in the synthesizer (U3701) is basically a dual modulus pre-scaler with selectable divider ratios. This divider ratio of the pre-scaler is controlled by the loop divider, which in turn receives its inputs via the SRL. The output of the pre-scaler is applied to the loop divider. The output of the loop divider is connected to the phase detector, which compares the loop divider's output signal with the reference signal. The reference signal is generated by dividing down the signal of the reference oscillator (Y3702).

The output signal of the phase detector is a pulsed DC signal which is routed to the charge pump. The charge pump outputs a current at pin 29 (I OUT of U3701). The loop filter (which consists of R3715 - R3717, C3723 - C3725, C3727) transforms this current into a voltage that is applied to the varactor diodes D3732, D3733 (TX), D3751, D3752 (RX) and alters the output frequency of the TX VCO (Q3741) and RX VCO (Q3751). The current can be set to a value fixed in the FRAC-N IC or to a value determined by the current flowing into CPBIAS 1 (U3701-27). The current is set by the value of R3723 and R3724. The selection of the two different bias sources is done by software programming.

To reduce synthesizer lock time when new frequency data has been loaded into the synthesizer the magnitude of the loop current is increased by enabling the IADAPT line (U3701-31) for a certain software programmable time (Adapt Mode). The adapt mode timer is started by a low to high transient of the FRACN CE line. When the synthesizer is within the lock range the current is determined only by the resistors connected to CPBIAS 1 or the internal current source.

A settled synthesizer loop is indicated by a high level of signal LOCK DET (U3701-2). This signal is routed to μ P U0101-17 for further processing.

In order to modulate the PLL the two spot modulation method is utilized. Via pin 8 (MODIN) on U3701 the audio signal is applied to both the A/D converter (low freq path) as well as the balance attenuator (high freq path). The A/D converter converts the low frequency analog modulating signal into a digital code that is applied to the loop divider, thereby causing the carrier to deviate.

The balance attenuator is used to adjust the VCO's deviation sensitivity to high frequency modulating signals. The output of the balance attenuator is present at the MODOUT port (U3701-28) and connected to the VCO modulation diode D3731.

<http://www.myradio168.net>

Chapter 6.4

PCB/Schematic Diagrams and Parts Lists

Table of Contents


Description	Page
216-246MHz Diagrams and Parts Lists	
PCB Layout Component Side	1
PCB Layout Solder Side	2
80ch Model, Closed Controller Schematic Diagram <i>1 of 2</i>	3
80ch Model, Closed Controller_IO Schematic Diagram <i>2 of 2</i>	5
Parts List	4/6
Supply Voltage Schematic Diagram	7
Parts List	8
Power Control Schematic Diagram	9
Parts List	10
Power Amplifier 5-25W Schematic Diagram	11
Parts List	12
Synthesizer Schematic Diagram	13
Parts List	14
Voltage Controlled Oscillator Schematic Diagram	15
Parts List	16
RX-FE Schematic Diagram	17
Parts List	18
RX-IF Schematic Diagram	19
Parts List	20

<http://www.myradio168.net>




GM950EI008-A

216-246MHz Main Board Component Side
PCB No. 8485664Z02



GM950E1007-O

216-246MHz Main Board Solder Side
PCB No. 8485664Z02



GM950E1006-O

216-246MHz 80ch Closed Controller Schematic Diagram
1 of 2

Controller Parts List


Circuit Ref	Motorola Part No.	Description
C0101	2113743E20	0.1uF, 10%
C0102	2113741F17	470pF 50V
C0103	2311049A42	TANT CP 3.3uF 10% 6V
C0104	2113741F49	10nF 50V
C0105	2113743E20	0.1uF, 10%
C0109	2113741F17	470pF 50V
C0110	2113741F17	470pF 50V
C0111	2113741F17	470pF 50V
C0112	2113741F25	1nF 50V
C0114	2113740A41	33pF 5% 50V
C0115	2113740A37	22pF 5% 50V
C0116	2113740G16	Ceramic Chip 3.6 P
C0117	2113740A41	33pF 5% 50V
C0118	2113741F17	470pF 50V
C0119	2113741F17	470pF 50V
C0121	2113743K05	39nF 16V
C0122	2113741F41	4700pF
C0125	2113743E20	0.1uF, 10%
C0126	2113743E20	0.1uF, 10%
C0127	2113743E20	0.1uF, 10%
C0131	2113743E20	0.1uF, 10%
C0132	2113743E20	0.1uF, 10%
C0133	2113743E20	0.1uF, 10%
C0134	2113743E20	0.1uF, 10%
C0137	2113741F49	10nF 50V
C0141	2311049J26	TANT CP 10uF 20% 16V
C0142	2113743A19	100nF 16V
C0145	2113741F25	1nF 50V
C0148	2113741F17	470pF 50V
C0149	2113740F39	33pF 5% 50V
C0150	2311049A05	TANT CP 470nF 10% 25V

Circuit Ref	Motorola Part No.	Description
C0151	2113741F17	470pF 50V
C0152	2311049A07	TANT CP 1uF 10% 16V
C0153	2113743E20	0.1uF, 10%
C0154	2113743E20	0.1uF, 10%
C0155	2113740F39	33pF 5% 50V
C0157	2113741F17	470pF 50V
C0161	2113743E20	0.1uF, 10%
C0162	2113743E20	0.1uF, 10%
C0163	2113743E20	0.1uF, 10%
C0164	2113741F41	4.7nF 50V
C0170	2311049A07	TANT CP 1uF 10% 16V
C0171	2311049J23	TANT CP 10uF 10% 6V
C0172	2311049A07	TANT CP 1uF 10% 16V
C0173	2311049A07	TANT CP 1uF 10% 16V
C0174	2113743E20	0.1uF, 10%
C0175	2113741F25	1nF 50V
C0181	2113743E20	0.1uF, 10%
C0182	2113743E20	0.1uF, 10%
C0184	2311049A07	TANT CP 1uF 10% 16V
C0185	2113740F51	100pF 5% 50V
C0191	2113743E20	0.1uF, 10%
C0194	2113741F17	470pF 50V
C0196	2113741F17	470pF 50V
C0197	2113741F17	470pF 50V
C0198	2113741F17	470pF 50V
C0199	2113741F17	470pF 50V

Controller_IO Parts List

Circuit Ref	Motorola Part No.	Description
C0401	2113743A19	100nF 16V
C0402	2113741F37	3.3nF 50V
C0404	2311049A99	47uF
C0405	2113741F25	1nF 50V
C0406	2113741F25	1nF 50V
C0407	2109720D14	CER LOW DIST 100nF
C0411	2113741F49	10nF 50V
C0412	2113741F17	470pF 50V
C0413	2113741F49	10nF 50V
C0414	2113741F17	470pF 50V
C0419	2113741F25	1nF 50V
C0420	2113741F25	1nF 50V
C0421	2113741F17	470pF 50V
C0422	2113741F17	470pF 50V
C0431	2113741F17	470pF 50V
C0435	2113741F49	10nF 50V
C0436	2113741F17	470pF 50V
C0438	2113741F49	10nF 50V
C0439	2113741F17	470pF 50V
C0441	2113741F49	10nF 50V
C0442	2113741F17	470pF 50V
C0444	2113741F17	470pF 50V
C0445	2311049A05	TANT CP 470nF 10% 25V
C0446	2113741F17	470pF 50V
C0450	2311049A99	47uF
C0451	2113741F17	470pF 50V
C0454	2113741F17	470pF 50V
C0455	2113741F17	470pF 50V
C0461	2113741F49	10nF 50V
C0462	2113741F17	470pF 50V
C0463	2113741F49	10nF 50V

Circuit Ref	Motorola Part No.	Description
C0464	2113741F17	470pF 50V
C0471	2113741F17	470pF 50V
C0472	2113741F17	470pF 50V
D0101	4813833C02	DIODE DUAL SOT MMBD6100
J0101	0902636Y01	Connector Flex Side Entry
J0102	0904424J06	CONNECTOR, DOUBLE ROW
J0103	0904424J06	CONNECTOR, DOUBLE ROW
J0400	2804503J01	Accessory Connector 16
L0114	2460578C43	INDUCTOR CHIP 33.0UH
L0170	2462587K26	CHIP IND 33000 NH
L0194	2462587Q40	COIL CHIP 270nH
L0195	2462587Q40	COIL CHIP 270nH
L0401	2484657R01	Ferrite Bead
L0402	2484657R01	Ferrite Bead
Q0114	4880214G02	MMBT3904
Q0137	4880048M01	TSTR NPN DIG 47k/47k
Q0138	4880048M01	TSTR NPN DIG 47k/47k
Q0161	4880214G02	MMBT3904
Q0401	4880214G02	MMBT3904
Q0411	4880214G02	MMBT3904
Q0412	4880048M01	TSTR NPN DIG 47k/47k
Q0421	4880048M01	TSTR NPN DIG 47k/47k
Q0431	4880048M01	TSTR NPN DIG 47k/47k
Q0432	4880048M01	TSTR NPN DIG 47k/47k
Q0433	4880214G02	MMBT3904
Q0442	4880052M01	TSTR NPN DRLNGTN
Q0461	4880048M01	TSTR NPN DIG 47k/47k
Q0462	4880214G02	MMBT3904
Q0471	4880048M01	TSTR NPN DIG 47k/47k
R0101	0662057A73	10k 1/16W 5%
R0102	0662057A65	4k7 1/16W 5%




216-246MHz 80ch Closed Controller_IO Schematic Diagram
2 of 2

Circuit Ref	Motorola Part No.	Description
R0103	0662057A73	10k 1/16W 5%
R0104	0662057A85	33k 1/16W 5%
R0105	0662057A73	10k 1/16W 5%
R0106	0662057A57	2k2 1/16W 5%
R0107	0662057A25	100 1/16W 5%
R0108	0662057A89	47k 1/16W 5%
R0109	0662057A89	47k 1/16W 5%
R0110	0662057A73	10k 1/16W 5%
R0111	0662057A85	33k 1/16W 5%
R0112	0662057A93	68k 1/16W 5%
R0113	0662057A73	10k 1/16W 5%
R0114	0662057A65	4k7 1/16W 5%
R0115	0662057B28	1.8M 1/16W 5%
R0116	0662057A35	270 1/16W 5%
R0117	0662057A35	270 1/16W 5%
R0118	0662057A65	4k7 1/16W 5%
R0119	0662057A49	1k 1/16W 5%
R0120	0662057A73	10k 1/16W 5%
R0121	0662057B03	160k 1/16W 5%
R0122	0662057A93	68K
R0123	0662057A97	100k 1/16W
R0124	0662057A69	6k8 1/16W 5%
R0125	0662057B05	200k 1/16W
R0126	0662057B05	200k 1/16W
R0127	0662057B05	200k 1/16W
R0128	0662057A73	10k 1/16W 5%
R0134	0662057A73	10k 1/16W 5%
R0135	0662057A89	47k 1/16W 5%
R0136	0662057A85	33K 1/16W 5%
R0137	0662057A89	47k 1/16W 5%
R0138	0662057A65	4k7 1/16W 5%
R0139	0662057B07	240k 1/16W
R0141	0662057A25	100 1/16W 5%

Circuit Ref	Motorola Part No.	Description
R0142	0662057A49	1k 1/16W 5%
R0143	0662057A89	47k 1/16W 5%
R0144	0662057A89	47k 1/16W 5%
R0145	0662057A84	30k 1/16W 5%
R0147	0662057B04	180k 1/16W 5%
R0148	0662057B14	470k 1/16W 5%
R0149	0662057B47	0 1/16W
R0150	0662057A90	51k 1/16W 5%
R0151	0662057A73	10k 1/16W 5%
R0152	0662057A73	10k 1/16W 5%
R0154	0662057A73	10k 1/16W 5%
R0155	0662057A93	68k 1/16W 5%
R0156	0662057B47	0 1/16W
R0157	0662057A77 0662057A84	15k 1/16W 5% (12.5kHz) 30k 1/16W 5% (20/25kHz)
R0161	0662057A97	100k 1/16W
R0162	0662057A73	10k 1/16W 5%
R0163	0662057A97	100k 1/16W
R0165	0662057A89	47k 1/16W 5%
R0166	0662057A73	10k 1/16W 5%
R0167	0662057A89	47k 1/16W 5%
R0171	0662057R92	47.5k .1W 1%
R0172	0662057R92	47.5k .1W 1%
R0175	0662057B02	150k 1/16W
R0181	0662057A84	30k 1/16W 5%
R0182	0662057A73	10k 1/16W 5%
R0183	0662057A73	10k 1/16W 5%
R0184	0662057A84	30k 1/16W 5%
R0186	0662057A83 0662057A90	27k 1/16W 5% (12.5kHz) 51k 1/16W 5% (20/25kHz)
R0189	0662057A95	82K
R0401	0662057A65	4k7 1/16W 5%
R0402	0662057A49	1k 1/16W 5%
R0404	0662057A73	10k 1/16W 5%

Circuit Ref	Motorola Part No.	Description
R0405	0662057A73	10k 1/16W 5%
R0406	0662057A81	22k 1/16W 5%
R0407	0662057A77	15k 1/16W 5%
R0411	0662057A73	10k 1/16W 5%
R0412	0662057A65	4k7 1/16W 5%
R0413	0662057A89	47k 1/16W 5%
R0414	0662057A35	270 1/16W 5%
R0422	0662057A73	10k 1/16W 5%
R0425	0662057A73	10k 1/16W 5%
R0426	0662057A89	47k 1/16W 5%
R0427	0662057B47	0 1/16W
R0431	0662057A89	47k 1/16W 5%
R0432	0662057A65	4k7 1/16W 5%
R0435	0662057A35	270 1/16W 5%
R0436	0662057A89	47k 1/16W 5%
R0437	0662057A65	4k7 1/16W 5%
R0438	0662057A73	10k 1/16W 5%
R0441	0662057A73	10k 1/16W 5%
R0443	0662057A65	4k7 1/16W 5%
R0444	0662057A35	270 1/16W 5%
R0446	0662057A97	100k 1/16W
R0450	0662057A43	560 1/16W 5%
R0451	0662057A97	100k 1/16W
R0454	0662057A49	1k 1/16W 5%
R0455	0662057B47	0 1/16W
R0461	0662057A89	47k 1/16W 5%
R0462	0662057A65	4k7 1/16W 5%
R0463	0662057A35	270 1/16W 5%
R0464	0662057A73	10k 1/16W 5%
R0472	0662057B47	0 1/16W
R0474	0662057A89	47k 1/16W 5%
R0475	0662057A65	4k7 1/16W 5%
U0101	5102898X66	64MC68HC711E20

Circuit Ref	Motorola Part No.	Description
U0102	5113805A30	IC 10F8 DCDR/REMUX 74HC138
U0103	5105165R77	CHIP CAR 40 PIN W/63G
U0104	5105492X36	74AC08 4 AND GATES
U0105	5183222M49	IC QUAD OPAMP_3403_
U0106	5183222M49	IC QUAD OPAMP_3403_
U0107	5184704M60	IC-CMOS 04M60 ANALOS
U0108	5105462G78	IC EEPROM !&K SPEI CMOS
U0401	5109699X01	AUDIO PA TDA1915C
VR0118	4813830A14	DIODE 5.1V 5% 225mW
VR0411	4813830A27	DIODE 14V 5% 225mW
VR0421	4813830A27	DIODE 14V 5% 225mW
VR0422	4813830A14	DIODE 5.1V 5% 225mW
VR0431	4813830A27	DIODE 14V 5% 225mW
VR0435	4813830A27	DIODE 14V 5% 225mW
VR0441	4813830A40	SOC23 AUTO SDN
VR0444	4813830A14	DIODE 5.1V 5% 225mW
VR0445	4813830A27	DIODE 14V 5% 225mW
VR0450	4813830A27	DIODE 14V 5% 225mW
VR0454	4813830A27	DIODE 14V 5% 225mW
VR0464	4813830A27	DIODE 14V 5% 225mW
VR0471	4813830A40	SOC23 AUTO SDN
Y0114	4880113R01	CRYSTAL 7.9488




GM950EI010-O

216-246MHz Supply Voltage Schematic Diagram

Supply Voltage Parts List

Circuit Ref	Motorola Part No.	Description
C0601	2113741F17	470pF 50V
C0602	2113741B69	0.1uF
C0603	2380090M24	LYT 10uF 50V 20%
C0604	2311049A97	33uF
C0605	2113743E20	0.1uF, 10%
C0611	2311049A99	47uF
C0612	2113743K15	100nF 16V
C0613	2113741F17	470pF 50V
C0621	2113741F17	470pF 50V
C0622	2311049A99	47uF
C0631	2113743E20	0.1uF, 10%
C0632	2311049A97	33uF
C0633	2113743E07	22nF 16V
C0634	2311049A99	47uF
C0635	2113743E20	0.1uF, 10%
C0641	2113743E20	0.1uF, 10%
D0611	4813833C02	DUAL SOT MMBD6100
D0621	4813833C02	DUAL SOT MMBD6100
D0631	4813833C02	DUAL SOT MMBD6100
Q0601	4880214G02	MMBT3904
Q0611	4805921T02	FMC2A
Q0612	4813824A10	NPN 40V
R0601	0662057A73	10k 1/16W 5%
R0602	0660076E70	FILM 7500
R0603	0660076E51	FILM 1200
R0604	0662057A49	1k 1/16W 5%
R0605	0662057A69	6k8 1/16W 5%
R0606	0662057B47	0 1/16W
R0611	0662057A51	1k2 1/16W 5%
R0612	0660076A61	3300 5 1/8
R0613	0660076A61	3300 5 1/8

Circuit Ref	Motorola Part No.	Description
R0614	0662057A49	1k 1/16W 5%
R0615	0662057A73	10k 1/16W 5%
R0616	0662057A73	10k 1/16W 5%
R0617	0660076A61	3300 5 1/8
R0621	0662057A57	2k2 1/16W 5%
R0631	0662057A01	10 1/16W 5%
R0632	0662057A01	10 1/16W 5%
R0641	0662057A84	30k 1/16W 5%
R0642	0662057A73	10k 1/16W 5%
U0601	5105625U25	IC 9.3V REG 2941
U0631	5105469E65	IC VLTG REGLTR LP2951C
VR0621	4813830A14	5.1V 5% 225mW
VR0641	4813830A14	5.1V 5% 225mW




GM950EI005-O

216-246MHz Power Control Schematic Diagram

Power Control Parts List

Circuit Ref	Motorola Part No.	Description
C0701	2113740F51	100pF 5% 50V
C0702	2113740F51	100pF 5% 50V
C0703	2113743E20	0.1uF, 10%
C0711	2113741A59	CL2
C0712	2113740F42	43pF 5% 50V
C0713	2113740F51	100pF 5% 50V
C0714	2113743A19	100nF 16V
C0716	2113741F33	2200pF
C0721	2113740F51	100pF 5% 50V
C0722	2113740F51	100pF 5% 50V
C0723	2113740F51	100pF 5% 50V
C0731	2113743E20	0.1uF, 10%
C0732	2113740F51	100pF 5% 50V
C0733	2113743A23	220nF 16V
C0736	2113743A23	220nF 16V
C0741	2113740F51	100pF 5% 50V
C0742	2113743E20	0.1uF, 10%
D0721	4813833C02	DIODE DUAL SOT MMBD6100
D0731- D0733	4813833C02	DIODE DUAL SOT MMBD6100
Q0711	4880214G02	MMBT3904
Q0731	4880048M01	TSTR NPN DIG 47k/47k
Q0732	4805921T02	TSTR DUAL ROHM FMC2
Q0741	4880048M01	TSTR NPN DIG 47k/47k
Q0742	4805128M27	TSTR PNP SOT89 BSR33
R0701	0662057A93	68k 1/16W 5%
R0702	0662057A89	47k 1/16W 5%
R0703	0662057A73	10k 1/16W 5%
R0704	0662057A89	47k 1/16W 5%
R0711	0662057A81	22k 1/16W 5%
R0712	0662057B47	0 1/16W

Circuit Ref	Motorola Part No.	Description
R0713	0662057A61	3k3 1/16W 5%
R0714	0662057A75	12k 1/16W
R0715	0662057A81	22k 1/16W 5%
R0716	0662057B16	560k 1/16W 5%
R0717	0662057A85	33k 1/16W 5%
R0718	0662057A93	68k 1/16W 5%
R0719	0662057A93	68k 1/16W 5%
R0721	0662057A73	10k 1/16W 5%
R0722	0662057A81	22k 1/16W 5%
R0723	0662057A89	47k 1/16W 5%
R0724	0662057A97	100k 1/16W
R0725	0662057A73	10k 1/16W 5%
R0731	0662057A81	22k 1/16W 5%
R0732	0662057A65	4k7 1/16W 5%
R0733	0662057A89	47k 1/16W 5%
R0734	0662057A65	4k7 1/16W 5%
R0735	0662057A73	10k 1/16W 5%
R0736	0662057A77	15k 1/16W 5%
R0738	0662057A89	47k 1/16W 5%
R0741	0662057A49	1k 1/16W 5%
R0742	0662057A49	1k 1/16W 5%
U0701	5183222M49	IC QUAD OPAMP __3403__
U0731	5113811G02	IC D/A CONV & BIT 4 CHAN W/SPI



216-246MHz Power Amplifier 5-25W Schematic Diagram


**Power Amplifier 5-25W
Parts List**

Circuit Ref	Motorola Part No.	Description
C8501	2113740F34	20pF 5% 50V
C8502	2113741F49	10nF 50V
C8503	2113741F49	10nF 50V
C8512	2113740F41	36pF 5% 50V
C8514	2113741A33	3.3nF 50V
C8521	2113740A40	30pF 5% 50V
C8522	2113741F49	10nF 50V
C8523	2113741F49	10nF 50V
C8524	2113741F25	1nF 50V
C8525	2113740A50	62pF 5% 50V
C8527	2113740A50	62pF 5% 50V
C8528	2113741F25	1nF 50V
C8529	2113740A55	100pF
C8530	2311049A01	TANT CP 100nF 10% 35V
C8531	2113741F49	10nF 50V
C8532	2113740A67	330pF 5% 50V
C8534	2111078B31	36pF
C8535	2113740A59	150pF 5% 50V
C8536	2111078B39	HQ 75pF 5%
C8537	2111078B41	HQ 91pF 5%
C8538	2113741A59	CL2
C8539	2111078B05	HQ 4.7pF 5%
C8542	2111078B44	HQ 120pF 5%
C8543	2111078B39	HQ 75pF 5%
C8544	2111078B25	27pF
C8546	2113741A33	3.3nF 50V
C8547	2111078B49	HQ 180pF 5%
C8548	2113741F49	10nF 50V
C8551	2111078B36	56pF
C8552	2111078B21	HQ 20pF 5%
C8553	2111078B22	HQ 22pF 5%

Circuit Ref	Motorola Part No.	Description
C8554	2111078B18	HQ 15pF 5%
C8556	2113741F25	1nF 50V
C8558	2113740F20	5.1pF 5% 50V
C8600	2113740A67	330pF 5% 50V
C8602	2113740F51	100pF 5% 50V
C8603	2113741F25	1nF 50V
C8604	2311049A45	TANT CP 10uF 10% 35V
C8611	2113741F49	10nF 50V
C8612	2113741F49	10nF 50V
C8615	2113741F25	1nF 50V
C8617	2113740A67	330pF 5% 50V
C8618	2311049A08	TANT CP 1uF
C8619	2113740F51	100pF 5% 50V
C8620	2113740F29	12pF
C8621	2113741F25	1nF 50V
C8622	2113741F49	10nF 50V
C8623	2113740F51	100pF 5% 50V
C8631	2113741F25	1nF 50V
C8632	2111078B44	120pF
C8633	2113740F36	24pF
C8634	2113740F51	100pF 5% 50V
C8642	2113741F25	1nF 50V
D8551	4802482J02	DIODE PIN MA/COM
D8553	4813825A05	MMBD301
D8601	4813832B35	DIODE TRANSORB
D8631	4802482J02	DIODE PIN MA/COM
J8501	0905901V02	RF CONNECTOR
J8601	0905902V04	POWER CONNECTOR
L8501	2462587N48	39nH
L8503	2462587T38	COIL CHIP 22nH 5%
L8531	2460591C23	SQUARE COIL 16nH 3T
L8532	2484657R01	Ferrite Bead
L8533	2460591C23	SQUARE COIL 16nH 3T

Circuit Ref	Motorola Part No.	Description
L8534	2484657R01	Ferrite Bead
L8539	2460591M77	COIL SQUARE 38nH
L8541	2460591X01	COIL SQUARE
L8542	2484657R01	Ferrite Bead
L8551-L8553	2460591M77	COIL SQUARE 38nH
L8600	2484657R01	Ferrite Bead
L8601	2484657R01	Ferrite Bead
L8611	2484657R01	Ferrite Bead
L8631	2462587T23	COIL CHIP 470nH
Q8510	4813827A26	TSTR RF NPN MRF8372
Q8520	4813827D13	4pin MRF557T
Q8530	4813827A36	TSTR MRF 5003
Q8531	4813827A36	TSTR MRF 5003
Q8540	4880225C30	TS TR MRF650
Q8611	4813824A17	TSTR PNP 40V .2A
Q8612	4880214G02	MMBT3904
Q8621	4813824A17	TSTR PNP 40V .2A
R8501	0662057C19	4R7 1/10W 5%
R8502	0662057A21	68 1/16W 5%
R8511	0662057A01	10 1/16W 5%
R8512	0662057A01	10 1/16W 5%
R8513	0662057A57	2k2 1/16W 5%
R8514	0662057C55	CHIP RES 150 5%
R8515	0662057C44	51 1/10W 5%
R8522	0662057A49	1k 1/16W 5%
R8523	0662057A49	1k 1/16W 5%
R8525	0662057C19	4R7 1/10W 5%
R8527	0662057C19	4R7 1/10W 5%
R8528	0662057A89	47k 1/16W 5%
R8529	0662057A89	47k 1/16W 5%
R8531	0680194M01	10 1W 5%
R8532-R8535	0683962T51	120 1W 5%

Circuit Ref	Motorola Part No.	Description
R8541	0680194M01	10 1W 5%
R8550	0662057A73	10k 1/16W 5%
R8551	0662057A73	10k 1/16W 5%
R8552	0662057A18	51 1/16W 5%
R8553	0683962T51	120 1W 5%
R8611	0662057A73	10k 1/16W 5%
R8612	0662057A56	2k 1/16W 5%
R8613	0662057A49	1k 1/16W 5%
R8614	0662057A18	51 1/16W 5%
R8615	0662057A65	4k7 1/16W 5%
R8616	0680194M01	10 1W 5%
R8617	0680194M01	10 1W 5%
R8621	0662057A41	470 1/16W 5%
R8623	0662057C19	4R7 1/10W 5%
R8624	0662057C19	4R7 1/10W 5%
R8641	0680149M02	Thermistor 100K @25C
SH8501	2602642Y01	Heat Spreader




216-246MHz Synthesizer Schematic Diagram



Synthesizer Parts List

Circuit Ref	Motorola Part No.	Description
C3701	2113740F51	100pF 5% 50V
C3702	2113741F13	330pF 50V
C3703	2113743E20	0.1uF, 10%
C3704	2113741F49	10nF 50V
C3705	2113741F49	10nF 50V
C3706	2113743E20	0.1uF, 10%
C3707	2113741F49	10nF 50V (12.5kHz)
C3708	2113740F59	220pF 5% 50V (12.5kHz)
C3709	2113743K15 2113740F13	100nF 16V (12.5kHz) 2.7pF 5% 50V (20/25kHz)
C3710	2113740F43	47pF 5% 50V (20/25kHz)
C3711	2311049J23	TANT CP 10uF 10% 6V
C3712	2311049J26	TANT CP 10uF 20% 16V
C3713	2113741F25	1nF 50V
C3716	2113743K15	100nF 16V
C3717	2113743K15	100nF 16V
C3718	2113743K15	100nF 16V
C3719	2311049A19	TANT CP 10uF 10% 25V
C3720	2113741F49	10nF 50V
C3722	2311049A07	1uF 10% 16V
C3723	2109720D14	100nF
C3725	2109720D14	100nF
C3726	2113741F49	10nF 50V
C3727	0811051A19	1uF 5%
D3701	4802233J09	Triple SOT143-RH (12.5kHz)
D3702	4805649Q04	Diode Varactor (20/25kHz)
E3702	2605915V01	SHLD PCB MOUNT
R3701	0662057A35	270 1/16W 5%
R3702	0662057A35	270 1/16W 5%
R3703	0662057A49	1k 1/16W

Circuit Ref	Motorola Part No.	Description
R3705	0662057A73 0662057A89	10k 1/16W 5% (12.5kHz) 47k 1/16W 5% (20/25kHz)
R3708	0662057B47	0 1/16W
R3709	0662057A01	10 1/16W 5%
R3711	0662057A25	100 1/16W 5%
R3712	0662057A59	2k7 1/16W 5%
R3713	0662057A67	5.6k 1/16W
R3714	0662057B02	150k 1/16W
R3715	0662057A41	470 1/16W
R3716	0662057A49	1k 1/16W
R3717	0662057A25	100 1/16W 5%
R3718	0662057A25	100 1/16W 5%
R3723	0662057A73	10k 1/16W 5%
R3724	0662057B16	560k 1/16W 5%
U3701	5105457W72	CC CONT 5105191W59
VR3701	4813830A23	10V 5% 20mA 350mW
Y3701	4802081B71	Crystal Quartz 16.8 MHZ TEMPUS (20/25kHz)
Y3702	4809863M01	Crystal Quartz 16.8 MHZ TEMPUS (12.5kHz)



GM950EI002-A




216-246MHz Voltage Controlled Oscillator Schematic Diagram

Voltage Controlled Oscillator Parts List

Circuit Ref	Motorola Part No.	Description
C3731	2113741F25	1nF 50V
C3733	2113740F25	8.2pF 5% 50V
C3734	2113740F03	1pF 5% 50V
C3735	2113741F17	470pF 50V
C3736	2113740F33	18pF 5% 50V
C3737	2113740F03	1pF 5% 50V
C3738	2113740F40	36pF 5% 50V
C3739	2113740F21	5.6pF 5% 50V
C3740	2113740F21	5.6pF 5% 50V
C3743	2113743K15	100nF 16V
C3744	2113741F25	1nF 50V
C3745	2113741F17	470pF 50V
C3751	2109720D01	LOW DIST 10nF
C3752	2113740F34	20pF 5% 50V
C3754	2113740F36	24pF 5% 50V
C3755	2113740F27	10pF 5% 50V
C3756	2113740F27	10pF 5% 50V
C3757	2113741F17	470pF 50V
C3758	2113741F25	1nF 50V
C3761	2113740F23	6.8pF 5% 50V
C3762	2113740F21	5.6pF 5% 50V
C3763	2113741F49	10nF 50V
C3764	2113740F21	5.6pF 5% 50V
C3765	2113740F29	12pF 5% 50V
C3766	2113740F51	100pF 5% 50V
C3767	2113741F49	10nF 50V X7R
C3771	2113743K15	100nF 16V
C3772	2113740F51	100pF 5% 50V
C3773	2113740F29	12pF 5% 50V
C3774	2113740F30	13pF 5% 50V
C3775	2113741F17	470pF 50V

Circuit Ref	Motorola Part No.	Description
C3777	2113741F17	470pF 50V
C3780	2113741F25	1nF 50V
C3781	2113741F49	10nF 50V
C3782	2113740F51	100pF 5% 50V
C3783	2113740F30	13pF 5%
C3784	2113740F27	10pF 5%
C3785	2113740F24	7.5pF 5%
C3790	2113740F32	16pF 5%
C3791	2113741F49	10nF 50V
C3792	2113741F49	10nF 50V
C3793	2113741F49	10nF 50V
C3801	2113743A23	220nF 16V
C3802	2113743E07	22nF 16V
C3803	2311049A63	TANT CP 10uF 10% 10V
D3731	4805649Q13	VCTR 1SV228 SOT23
D3732	4805649Q13	VCTR 1SV228 SOT23
D3733	4805649Q13	VCTR 1SV228 SOT23
D3739	4813825A05	MMBD301
D3751	4805649Q13	VCTR 1SV228 SOT23
D3752	4805649Q13	VCTR 1SV228 SOT23
D3754	4813825A05	MMBD301
E3731	2602641Y02	SHIELD, ARIANE VCO
E3732	2605915V01	SHLD PCB MOUNT
L3731	2462587T13	COIL CHIP 68nH
L3732	2462587T30	COIL CHIP 1uH
L3733	2462587T30	COIL CHIP 1uH
L3734	2462587N45	79 IDCTR, 22nH
L3741	2462587T30	COIL CHIP 1uH
L3742	2462587T30	COIL CHIP 1uH
L3750	2462587T30	COIL CHIP 1uH
L3751	2462587T30	COIL CHIP 1uH
L3752	2484562T11	AIR COIL 12.5nH
L3754	2462587T30	COIL CHIP 1uH

Circuit Ref	Motorola Part No.	Description
L3761	2462587T13	COIL CHIP 68nH
L3768	2462587T16	COIL CHIP 120nH
L3773	2462587N47	COIL CHIP 33nH
L3781	2462587T38	16 IDCTR, 22nH
L3783	2462587N50	COIL CHIP 56nH
Q3742	4805921T09	XSTR DUAL ROHM FMG8
Q3751	4813823A05	N-CH RF JFET MMBU310LT1
Q3752	4880214C02	MMBT3904
Q3760	4813827A07	NPN SML SIG MMBR9
Q3770	4813827A07	NPN SML SIG MMBR9
Q3780	4813827A07	NPN SML SIG MMBR9
Q3790	4813827A07	NPN SML SIG MMBR9
R3731	0662057A21	68 1/16W 5%
R3739	0662057A83	27k 1/16W 5%
R3740	0662057A09	22 1/16W 5%
R3741	0662057A21	68 1/16W 5%
R3742	0662057A15	39 1/16W 5%
R3743	0662057A65	4k7 1/16W 5%
R3751	0662057A83	27k 1/16W 5%
R3752	0662057A57	2k2 1/16W 5%
R3753	0662057A25	100 1/16W 5%
R3754	0662057A15	39 1/16W 5%
R3761	0662057A53	1k5 1/16W 5%
R3762	0662057A41	470 1/16W 5%
R3763	0662057A29	150 1/16W 5%
R3765	0662057A35	270 1/16W 5%
R3766	0662057A09	22 1/16W 5%
R3794	NU	NU



GM950EI004-A




RX-FE Parts List

Circuit Ref	Motorola Part No.	Description
C3300	2113741F37	3.3nF 50V
C3301	2113740F28	11pF 5% 50V
C3302	2113740F24	7.5pF 5% 50V
C3303	2113741F37	3.3nF 50V
C3304	2113740F45	56pF 5% 50V
C3305	2113740F39	33pF 5% 50V
C3306	2113740F42	43pF 5% 50V
C3307	2113741F37	3.3nF 50V
C3308	2113741F25	1nF 50V
C3309	2113741F13	330pF 50V
C3310	2113741F13	330pF 50V
C3311	2113741F37	3.3nF 50V
C3312	2113741F25	1nF 50V
C3313	2113740F45	56pF 5% 50V
C3314	2113740F24	7.5pF 5% 50V
C3315	2113740F45	56pF 5% 50V
C3316	2113740F39	33pF 5% 50V
C3317	2113740F39	33pF 5% 50V
C3319	2113741F25	1nF 50V
C3320	2113741F25	1nF 50V
C3322	2113741F49	10nF 50V
C3331	2113740F29	12pF 5% 50V
C3332	2113740F37	17pF 5% 50V
C3333	2113740F42	43pF 5% 50V
C3334	2113740F49	82pF 5% 50V
C3351	2113740F28	11pF 5% 50V
C3352	2113740F28	11pF 5% 50V
C3353	2113740F28	11pF 5% 50V
C3354	2113740F28	11pF 5% 50V
C3355	2113740F28	11pF 5% 50V
D3300	4813833C02	DUAL SOT MMBD6100

Circuit Ref	Motorola Part No.	Description
D3303	4880154K03	Dual Schottky SOT23
D3311	4802245J22	VCTR IT363
D3312	4802245J22	VCTR IT363
D3313	4802245J22	VCTR IT363
D3314	4802245J22	VCTR IT363
D3331	4880174R01	QUAD SOIC 8 PIN
L3302	2462587T23	COIL CHIP 470nH
L3331	2462587T23	COIL CHIP 470nH
L3332	2462587T17	COIL CHIP 150nH
L3333	2462587N40	COIL CHIP 8.2nH 5%
L3334	2462587N41	COIL CHIP 10nH 5%
Q3301	4813827A07	NPN SML SIG MMBR9
Q3302	4813824A17	MMBT3906
R3300	0662057A55	1k8 1/16W 5%
R3301	0662057A97	100k 1/16W
R3302	0662057A37	330 1/16W 5%
R3303	0662057A49	1k 1/16W 5%
R3304	0662057A53	1k5 1/16W 5%
R3306	0662057A35	270 1/16W 5%
R3307	0662057A21	68 1/16W 5%
R3308	0662057A35	270 1/16W 5%
R3309	0662057A97	100k 1/16W
R3311	0662057A55	4k7 1/16W 5%
R3312	0662057A55	1k8 1/16W 5%
R3313	0662057A61	3k3 1/16W 5%
R3314	0662057A07	18 1/16W 5%
R3315	0662057A01	10 1/16W 5%
R3316	0662057A29	150 1/16W 5%
R3317	0662057A29	150 1/16W 5%
R3318	0662057A13	33 1/16W 5%
R3331	0662057A18	51 1/16W 5%
R3340	0662057B47	NU
R3341	0662057B47	NU

Circuit Ref	Motorola Part No.	Description
T3301	2505515V03	XFMR JEDI MIXER SMD 4:1
T3302	2505515V03	XFMR JEDI MIXER SMD 4:1



216-246MHz RX-IF Schematic Diagram

RX-IF Parts List

Circuit Ref	Motorola Part No.	Description
C5200	2113740F35	22pF 5% 50V
C5201	2113740F19	4.7pF 5% 50V
C5202	2113740F31	15pF 5% 50V
C5203	2113743A19	100nF 16V X7R
C5204	2113743A19	100nF 16V X7R
C5205	2113740F33	18pF 5% 50V
C5208	2113743A19	100nF 16V
C5211	2113740F31	15pF 5% 50V
C5212	2113740F31	15pF 5% 50V
C5213	2113740F40	36pF 5% 50V
C5214	2113740F17	3.9pF 5% 50V
C5220	2113741F49	10nF 50V
C5221	2311049A63	TANT CP 10uF
C5222	2113743A23	0.22uF
C5223	2113743E20	100nF 16V
C5224	2113741F29	1.5nF 50V
C5225	2311049J11	TANT CP 4.7uF 10% 16V
C5226	2113743K07	47nF 16V
C5227	2311049J11	TANT CP 4.7uF 10% 16V
C5228	2113743K15	100nF 16V
C5229	2113741F41	4.7nF 50V
C5230	2113741F49	10nF 50V
C5231	2311049A07	TANT CP 1uF 10% 16V
C5232	2113740F51	100pF 5% 50V
C5233	2113740F51	100pF 5% 50V
C5234	2113743K15	100nF 16V
C5235	2113740F51	100pF 5% 50V
C5236	2113740F51	100pF 5% 50V
C5237	2113743K15	100nF 16V
C5238	2113743K15	100nF 16V Y5V
C5239	2113740F44	51pF 5% 50V

Circuit Ref	Motorola Part No.	Description
D5201	4880154K03	Dual Schottky SOT23
FL5201	9180098D04	Filter CER 4-EL 455kHz
FL5202	9180097D04	Filter CER 6-EL 455kHz
L5201	2462587N69	CHIP IND 1200 NH
L5203	2483411T74	Inductor Chip Shielded
L5211	2483411T74	Inductor Chip Shielded
Q5201	4813827A07	MMBR941
R5201	0662057A73	10k 1/16W 5%
R5202	0662057A85	33k 1/16W 5%
R5203	0662057A69	6k8 1/16W 5%
R5204	0662057A25	100 1/16W 5%
R5205	0662057A56	2k 1/16W 5%
R5207	0662057B47	0 1/16W
R5211	0662057A47	820 1/16W 5%
R5212	0662057A67	5k6 1/16W 5%
R5216	0662057A73 0662057A65	10k 1/16W 5% (12.5kHz) 4k7 1/16W 5% (20/25kHz)
R5221	0662057B02	150k 1/16W
R5222	0662057A97	100k 1/16W 5%
R5223	0662057A83	27k 1/16W 5%
R5224	0662057A76	13k 1/16W 5%
R5225	0662057A25 0662057A57	100 1/16W 5% (12.5kHz) 2k2 1/16W 5% (20/25kHz)
U5201	5180207R01	IF IC
Y5201	9102651Y01 9102652Y01	XTAL FLTR 45.1MHZ 12.5KHz 80dB XTAL FLTR 45.1MHZ 20/25KHz 80dB
Y5202	9102651Y02 9102652Y02	XTAL FLTR 45.1MHZ 12.5KHz 60dB XTAL FLTR 45.1MHZ 20/25KHz 80dB
Y5211	4802653Y01	XTAL OSC 44.645MHZ

Appendix A

PL/DPL Codes

Table of Contents

Paragraph		Page
1.0	PL Codes and Digital PL (DPL) Codes	1
2.0	Self-Quiting Frequencies	1

<http://www.myradio168.net>

<http://www.myradio168.net>

1.0 PL Codes and Digital PL (DPL) Codes

The following PL Codes have been tested and are acceptable for programming into any transmit or receive frequency.

GROUP A		GROUP B		GROUP C	
Code	Freq	Code	Freq	Code	Freq
XZ	67.0	XA	71.9	WZ	69.3
XB	77.0	YZ	82.5	WA	74.4
YB	88.5	ZA	94.8	WB	79.7
1Z	100.0	1A	103.5	YA	85.4
1B	107.2	2Z	110.0	ZZ	91.5
2A	114.8	2B	118.8	ZB	97.4
3Z	123.0	3A	127.3	5B	162.2
3B	131.8	4Z	136.5	8Z	206.5
4A	141.3	4B	146.2		
5Z	151.4	5A	156.7		
6A	173.8	6Z	167.9		
7Z	186.2	6B	179.9		
M1	203.5	7A	192.8		
M3	218.1	M2	210.7		

Digital PL (DPL) Codes:

023	025	026	031	032	036
043	047	051	053	054	065
071	072	073	074	114	115
116	122	125	131	132	134
143	145	152	155	156	162
165	172	174	205	212	223
225	226	243	244	245	246
251	252	255	261	263	265
266	271	274	306	311	315
325	331	332	343	346	351
356	364	365	371	411	412
413	423	431	432	445	446
452	454	455	462	464	465
466	503	506	516	523	526
532	546	565	606	612	624
627	631	632	654	662	664
703	712	723	731	732	734
743	754				

2.0 Self-Quiting Frequencies

Self-quieting frequencies are frequencies that are also generated by the radio and cause internal interference. On these frequencies the interference caused by the self-quieter spur is great enough that a radio will not meet its receiver sensitivity specification.

The frequencies are: UHF 403.2, 420, 436.8 and 453.6MHz.

VHF 151.2 and 168.0MHz

<http://www.myradio168.net>

Appendix B

External Device Connectors

Table of Contents

Paragraph		Page
1.0	Accessory Connector Details	1
2.0	Microphone Connector	3

<http://www.myradio168.net>

<http://www.myradio168.net>

1.0 Accessory Connector Details

The 16-pin accessory connector pin functions are as follows:

Pin	Name	Type	A2 4-Channel	A3 128-Channel
1	SPKR-	Analogue output	✓	✓
2	Ext. Mic Audio	Analogue input	✓	✓
3	GP1	Digital input	✓	✓
4	GP2	Digital output	X	✓
5	Flat TX Audio	Analogue input	X	✓
6	BUS+	Digital i/o	✓	✓
7	GND	Ground	✓	✓
8	GP3	Digital i/o	X	✓
9	GP4	Digital ip. capture	X	✓
10	Ignition sense	Digital input	✓	✓
11	RX Audio	Analogue output	X	✓
12	GP5	Digital i/o	X	✓
13 *	SW B+ / GND	Analogue output	X	✓
14	GP6	Digital i/o	X	✓
15	RSSI	Analogue output	✓ (Unbuffered)	✓
16	SPKR+	Analogue output	✓	✓

* Factory default SWB+.

Pin 1. - Speaker - audio

Speaker - and Speaker + (Pin 16) are used to connect an external speaker. The audio PA is a bridge amplifier with a minimum load resistance of 3.2 ohms. The internal speaker can be disabled by removing the control head. Disconnect the internal speaker and assemble the control head back to the radio.

Pin 2. - Microphone audio

This microphone signal input is common with the microphone signal input on the microphone connector and is connected to the microphone path input of the AFIC. The nominal input level is 80mV for 60% deviation. The DC impedance is 1100 ohms and the AC impedance is 1000 ohms
Note: Only one microphone should be connected at any one time.

Pin 3. - General Purpose 1 (GP 1)

This is a digital input only. The RSS details which functions may be assigned to this pin by the codeplug. The primary use for this pin will be external PTT. (See Note 1).

Pin 4. - General purpose 2 (GP2)

This is a digital output only. The RSS details which functions may be assigned to this pin by the codeplug. The primary use for this pin is as external alarm output (See Note 3).

Pin 5. - Flat TX audio

This input is for injecting signals into the transmit path that should not be filtered, e.g. the output of a modem. The nominal input level is 150mVRMS for 60% deviation. The impedance is greater than 25kohms.

Pin 6. - BUS+

This connects to the radio's SCI serial bus which is used for programming and tuning the radio. The line is also available at the microphone connector Pin 7.

Pin 7. - Ground

Used as ground for both analogue and digital signals.

Pin 8. - General purpose 3 (GP3)

This is a digital input/output and is also available on the internal option connector (J0103:7). The RSS details which functions may be assigned to this pin by the codeplug. (See Notes 1 and 2).

Pin 9. - General purpose 4 (GP4)

This is a digital input only. It is also available on the internal option connector (J0102:7) and is used in input capture mode when a serial type option board is fitted. The RSS details which functions may be assigned to this pin by the codeplug. (See Note 1).

Pin 10.- Ignition sense

Connecting this line to the ignition line of the vehicle will automatically turn the radio on when the ignition of the vehicle is turned on. When ignition is connected, the radio cannot be turned off as long as the ignition is active. When this line is at 0V or not connected, power on/off is under manual control. Resistor R0423, 4.7k Ω , which is not fitted as standard will cause the radio to be permanently on whenever 12V is connected to the main power connector.

Pin 11.- RX Audio Discriminator/Filtered (Analogue output)

The signal routed to this pin is controlled by AFIC. There are two possible outputs; continuous discriminator audio or continuous filtered RX audio output of AFIC. The output mode can be selected by the RSS, however, this mode may be overridden during certain tuning operations. For discriminator audio, the nominal output level is 330mVRMS for 60% deviation. The impedance is 600ohms. For filtered audio, the nominal output level is 600mV for 60% deviation. The impedance is 600ohms.

Pin 12.- General purpose 5 (GP5)

This is a digital input/output and is also available on the internal option connector (J0103:8). The RSS details which functions may be assigned to this pin by the codeplug. (See Notes 1 and 2).

Pin 13.- Switched B+ / Analogue Ground

The output of this pin may be configured by a solder link within the radio. Switched B+ is the default. The current limiting resistor (R0455) default is 0 Ω , therefore extreme care must be taken to avoid short circuiting this output to ground, which will damage the radio.

CAUTION: The maximum continuous current allowed is 300mA. A suitable external fuse must be installed into the lead to pin 13 to avoid damage to the radio.

**Pin 14.- General purpose 6 (GP6)**

This is a digital input/output and is also available on the internal option connector (J0102:3). The RSS details which functions may be assigned to this pin by the codeplug. (See Notes 1 and 2).

Pin 15.- RSSI

Received Signal Strength Indication, buffered analogue voltage.

Pin 16.- Speaker+ audio

Positive output of radio's audio PA (see Pin 1).

Note 1: Digital Input

4.7 k Ω Internal Pull Up Resistor to +5V.
Maximum Input Voltage accepted as Low = 0.6V
Minimum Input Voltage accepted as High = 3.0V

Note 2: Digital Output

4.7k Ω Internal Pull Up Resistor to +5V
Maximum Current when Output Low = 10mA
Maximum Voltage when Output Low = 0.5V @ 10mA

Note 3: High Current Digital Output

4.7k Ω Internal Pull Up Resistor to B+
Maximum Current when Output Low = 200mA
Maximum Voltage when Output Low = 1.7V @200mA

2.0 Microphone Connector

The radio is fitted with an 8-pin 'Telco' connector which is connected as follows:

Pin	Name	Type	Connected To
1	-	-	-
2	-	-	-
3	Mic. Hook	Digital input	Port A7
4	GND	Ground	-
5	Mic. Audio	Analogue input	AFIC TX IN
6	Mic. PTT	Digital i/o	Port C4
7	BUS+	Digital i/o	Port D0 and Port D1
8	HANDSET	Analogue output	Buffered RX audio

Pin 1. - No connection.

Pin 2. - No connection.

Pin 3. - Microphone (or internal) Hook

This port reads '0' when the microphone is on-hook and '1' when the microphone is off-hook. It is assumed that the hook is a mechanical switch, so the software will always debounce this input.

Pin 4. - Ground

Pin 5. - Microphone audio

This microphone signal input is common with the microphone signal input on the accessory connector and is connected to the microphone path input of the AFIC.

Note: Only one microphone should be connected at any one time.

Pin 6. - Microphone (or Internal) PTT

The microphone PTT is active low and so this port reads '0' when the PTT is pressed and '1' when the PTT is released. It is assumed that this PTT is a mechanical switch, so the software will always debounce this input.

The microphone PTT line is also available at the internal connector (J0102:1) as a bi-directional line, i.e. an internal option can use the line, both to key-up the radio, and to know when the radio is already keyed-up. For this to work, microprocessor port C4 has to be reconfigured as an output and driven low whenever any other signal, other than the microphone PTT, e.g. external PTT, causes the radio to key-up.

Pin 7. - BUS+

This line carries the data for the single line serial comms system used in the radio. The RSS will program the radio through this socket. The line is also available at the accessory connector Pin 6.

Pin 8. - Handset Audio

This line provides buffered audio for a handset.

<http://www.myradio168.net>

Appendix C

Radio Conversion

Table of Contents

Paragraph		Page
1.0	How to alter the radio for Base Station Operation	1

<http://www.myradio168.net>

<http://www.myradio168.net>

1.0 How to alter the radio for Base Station Operation

UHF Radio Conversion

If the UHF radio is configured for a base station application, R5319 is not placed and TP5301 and TP5302 are shorted.

VHF Radio Conversion

If the VHF radio is configured for a base station application, R3318 is not placed and TP3301 and TP3302 are shorted.

<http://www.myradio168.net>

<http://www.myradio168.net>